

Hey there,

Congratulations on getting your very own FPods FZ100 Truly Wireless Earpods with 3C NitroFast Charge, latest BT Version V5.0, Quad Mic ENC for crystal clear calls, 10mm deep bass drivers, 40ms ultra low latency gaming mode, and IPX4 rating. You can now truly sink into your world of sound. Your musical vibe begins here.

Quick Start Guide

TRULY WIRELESS STEREO EARPODS WITH
QUAD MICS, 3C NITROFAST CHARGE AND
CRYSTAL CLEAR CALLS WITH ENVIRONMENTAL NOISE CANCELLATION

fastrack
FPods
FZ100



Included Components



Overview



Getting Started

- Place the earpods in the charging case and close the lid.
- Make sure to charge the earpods before starting the pairing process.
- Open the charging case lid and take out the buds.
- Turn ON your phone's Bluetooth settings, and search for "FPods FZ100" and tap to pair and connect.
- Your earpods are now paired and ready for you to experience.
- The earpods will automatically re-connect to a previously paired device next time you use it. Make sure the device's Bluetooth is ON.
- To charge the earpods, place them back into the case and close the lid. This will also power off the earpods.
- Use the right sized Earpods (S.M.I.) in a variety of head sizes.



Setup your FPods FZ100

Setup

- Power on: To turn on the earpods take them out of the case.
- Power off: Put the earpods in the case and close the lid to power off.
- To manually power on the earpods, press and hold the buds for 3 seconds.
- To manually power off the earpods, press and hold the buds for 5 seconds.
- To charge the earpods, place them in the charging case and close the lid.
- Please ensure to charge your earpods fully before using them. To charge the Charging Case, use the Type-C charging cable provided in the box.
- Use a standard 5V/1A adapter for charging.

Reset



- Take out the earpods from the Charging Case.
- Insert the earpods from the previously connected device.
- Tap 5 times on L/R bud.
- You will hear "Power Off" voice prompt.
- Your earpods are now reset and ready to pair again.

FCC Warning

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference. (2) This device must accept any interference received, including interference that may cause undesired operation. Any Change or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not properly shielded and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following:

Interference

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device that does not exceed the limit cannot be expected to operate. The device can be used in portable exposure condition without restriction.

FCC Warning



- Call Controls**
- Call Answer: Double tap on L/R bud
 - Call Reject: Double tap on L/R bud during the call
 - Call Reject/Decline: Press & hold on L/R bud for 2 seconds
- Music Controls**
- Play/Pause: Double tap on L/R bud
 - Increase Volume: Single tap on R bud
 - Decrease Volume: Single tap on L bud
 - Previous Track: Press & hold L bud for 2 seconds
 - Next Track: Press & hold R bud for 2 seconds

- Monopod Mode**
- You can take out any bud out of the Charging Case and start using it as Monopod.
- Call Answer: Double tap on bud
 - Call Reject: Press & hold the bud for 2 seconds
 - Call Reject: Double tap on bud
 - Music Play/Pause: Double tap on bud
 - Music volume decrease: Single tap on bud
 - Music previous track: Press & hold the bud for 2 seconds
- Call Answer: Double tap on bud
- Call Reject: Press & hold the bud for 2 seconds
- Call Reject: Double tap on bud
- Music Play/Pause: Double tap on bud
- Music volume increase: Single tap on bud
- Music next track: Press & hold the bud for 2 seconds

- Voice Assistant, Gaming Mode**
- Tap 3 times on L/R bud to activate Voice Assistant
 - Tap 4 times on L/R bud to activate Gaming Mode
- Gaming Mode**
Level up your gaming experience with the built-in ultra low latency gaming mode.
- Voice Assistant**
Your voice assistant is just a few taps away.

- Features**
- Environmental Noise Cancellation (ENC)
 - 50 Hours Playtime*
 - Premium Finish
 - IP68m Diver
 - QC Quick Charge — 10 min charge gets 200 min playtime*
 - Gaming Mode (Ultra Low Latency of 42 ms)
 - Extra Deep Bass
 - Latent BT version: S, D



- Product Specifications:**
- BT Version: BLE2
 - Driver Size: 10mm
 - Frequency Response: 20Hz — 20kHz
 - Water Resistance: IP68
 - Total Playtime with Charging Case: 50 Hours
 - Fast Charging Time: 50 min
 - Case Charging Time: 100 min
 - Charging Voltage: 5.0V
 - Transmission Distance: 10m
 - Fastrack Battery Capacity: 300mAh
 - Charging Case Battery Capacity: 450mAh

- Care & Warranty**
- The Don't's**
- Do not expose the earpods to extreme temperature/ weather conditions.
 - Don't use chemicals or detergent to clean your buds.
 - Do not keep the case on charging for a longer time once it is fully charged.
- Terms of Warranty**
- The product comes with a One year limited warranty against manufacturing defects. TSC apply. Any damage to the earpods that is not a manufacturing issue will void the product warranty. Please take care of your buds to ensure prolonged service life. If you have any queries or need to raise a complaint, please call us on 800-246-0122 or visit the nearest Fastrack store.

