

Listening to Playlists and Podcasts

Selecting Playlists and Podcasts

To change which playlist or podcast you're listening to on Mighty, press the Playlist Selector button (the circle with three lines on the top right of Mighty's face). The name of the selected playlist or podcast will be spoken through your headphones.

Shuffle Mode

You can shuffle the order of songs in your playlist by pressing and holding the Playlist Selector button for three seconds to toggle on/off shuffle mode. The shuffle mode start (on/off) will be spoken through your headphones.

Next & Previous Track

To skip to the next track in a playlist, press the Forward button once.

To go back to the previous track in a playlist, press the Back button once. If you press the Back button during the middle of a track, Mighty will return to the beginning of that track. Press the Back button once more time to go back to the previous track.

Fast Forward & Rewind

To fast forward a track or podcast, press and hold down the Forward button. You will hear chimes through your headphones to indicate the fast forward process.

To rewind a track or podcast, press and hold the Back button.

Note: If you hold down the Back/Forward button for multiple seconds, you will hear numbers spoken through your headphones. Those numbers correspond to the minute of the track or podcast that will be played if you release the Back/Forward button immediately after that number is spoken.

Play & Pause


To pause playback, press the Play button once.

To resume playback, press the Play button again.

Power On & Off

To power Mighty on, press the Play button once. Mighty's LED will solid green during the power on process (approximately 20 seconds) and will begin blinking green once playback is possible.

To power Mighty off, press and hold down the Play button for four seconds. Mighty's LED will turn solid orange.



Voiceovers

Power on: You will hear a two-tone beep to indicate that your Mighty has fully powered on. Mighty takes approximately 30 seconds to power on.

Low battery: You will hear a one-tone beep to indicate that your Mighty has 20% battery life remaining.

Power off: You will hear a two-tone beep to indicate that your Mighty is powering off. It will take your Mighty an additional 20 seconds to fully power down, during which you will not be able to power your Mighty back on.

Playlist VoiceOver: Each time you tap the playlist selector, Mighty will speak the playlist title back to you.

Bluetooth accessory connection: You will hear a two-tone beep through the Bluetooth accessory to indicate that the Bluetooth accessory was successfully paired and connected to your Mighty.

Fast forward and Rewind: For the first four seconds of holding forward, you will hear four beeps. Each beep represents a 30 second skip forward. For podcasts, you will begin to hear minute markers after the first four beeps.

Charging Mighty

1. Use the provided charging cable to charge Mighty.
2. Plug the headphone jack side of the charging cable into Mighty's headphone port and plug the USB side of the charging cable into a USB wall adapter or into your computer's USB port. Ignore any messages that appear on your computer, Mighty will charge as intended. Mighty's LED will flash white while being charged and will remain a solid white when fully charged.

Powering Mighty On

Press the Play button to turn Mighty on.

It will take up to 30 seconds for Mighty to turn on and be ready for playback. This will be indicated by the LED changing from a solid green to flashing green (if not plugged into the charger) or flashing white (if plugged into the charger).

Powering Mighty Off

Press and hold the Play button for four seconds and your Mighty's LED will turn solid orange to indicate that your Mighty is powering off.



LED Colors

- Solid white - fully charged
- ⊗ Blinking white - charging
- Solid orange - powering off
- ⊗ Blinking orange - battery low
- Blue - waiting to pair (press Play)
- Solid green - powering on
- ⊗ Blinking green - on

Battery Life

Mighty's Battery Life

Mighty typically has five or more hours of continuous playback using wired or Bluetooth headphones. Exact playback time is dependent on individual playback patterns such as outside temperature, volume level, and how often the music is paused/started.

Sleep Mode

Mighty will automatically enter sleep mode after five minutes of non-activity (no music playback, no button presses, no activity on app). While sleeping, Mighty will be in a low power mode and will not be able to play music or connect to the app. The LED will not be illuminated when Mighty is in sleep mode. To conserve battery life, Mighty will automatically power off after 45 minutes in sleep mode. To conserve battery life, we recommend manually turning Mighty off after usage by holding the play button for four seconds.

To wake Mighty up from sleep mode, tap the play/pause button once and Mighty's LED will turn solid green for 3 seconds, then the LED will blink green to indicate that Mighty is powered on. You will be able to play music and connect to the app as soon as Mighty's LED beings blinking green.



LED color

- Solid green - powering on
- ✕ Blinking green - on
- Solid orange - powering off