



PREPARE TO USE YOUR GRILLEYE® PRO+

detailed instructions at: grilleye.com/support



DOWNLOAD THE GRILLEYE® PRO APP

iOS ver. 10.0 or later Android ver. 4.4 or later




MAKE SURE YOUR GRILLEYE PRO+ IS CHARGED.

GrillEye® PRO+ runs on a powerful, rechargeable battery that can last up to 48 hrs of continuous use* (charge for $\sim\!2^{1/2}$ hrs until full). Product can be used while being charged.



SWITCH ON BLUETOOTH® ON YOUR MOBILE

GrillEye® PRO* requires Bluetooth 4.0 or higher. It is compatible to latest Bluetooth 5.0 technology to achieve even higher speeds at low energy consumption.



GrillEye® PRO+ uses WiFi® in tandem with Bluetooth® to offer unmatched range anywhere in or around your house, limited only by the range of your house's WiFi network.

1. POWER-UP YOUR GRILLEYE® PRO+



Press once the Power button.

A short "beep" will sound and the screen will light-up to display the GrillEye® logo.

Powersaving

For powersaving purposes, the device will power off automatically if idle for more than 4′. To wake, press the power button once.

2. LAUNCH THE GRILLEYE® PRO APP & PAIR



Once the app opens and detects a GrillEye PRO⁺ device near your mobile, it will connect automatically. Press the "Let's grill" button and you are ready to go!

The first 2" of pairing

- GrillEye PRO+ displays your mobile's name
- App displays your GrillEye PRO+ serial number

3. SETUP CONNECTION WITH YOUR WIFI



After pairing, the app will prompt you to select your WiFi network from a list of available networks. Select your network and enter your password to connect.

Connection to your WiFi

Connection to your WiFi ensures limitless range** in your house. If you miss initial WiFi setup, you can find the option in app Settings. In cases where WiFi may not be available (e.g. power outage) you can use only Bluetooth* (range of $\sim 10 \text{m/}30 \text{ft}$).

** range limited only to the number of your house's WiFi network

TIPS FOR PRO-GRADE RESULTS



Enjoy unmatched range anywhere in or around your house, as long as you are connected to your WiFi. GrillEye® PRO app will prompt you to connect during 1st use. You can always find the option in app Settings (e.g. for setting-up new WiFi networks).



If your mobile phone supports localisation preferences (e.g. language, temperature units of measurement etc.), the GrillEye® PRO app will detect them and setup everything automatically. If not, just visit the app Settings to adjust as needed.

EXPLOIT ULTRA CAPACITY OF 8-PORTS FOR 8x MAXIMUM ACCURACY

The GrillEye® PRO+ allows you to monitor temperature of up to 8 different sources. Want to use your 4 chambers smoker? No problem. Now you can monitor, effortlessly, all chambers' ambient temperature as well as all meats' core temperature.



CHARGE USING ANY **USB PHONE CHARGER**

GrillEye® PRO+ runs on a powerful, rechargeable battery that can last up to 48 hrs of continuous use* on a single charge. Recharge using any USB phone charger ($\sim 2^{1/2}$ hrs until full). In case you forgot to charge, you can use it while charging it.



SAFETY GUIDELINES





AVOID PROLONGED EXPOSURE TO HEAT

Heating the product, above 50°C / 122°F may damage its electronics.



KEEP AWAY FROM FIRE

If a surface is too hot to touch, it's too hot for magnetically mounting the GrillEye® PRO+.



DO NOT ATTEMPT TO OPEN OR MODIFY

Any unauthorised attempt to open the device will constitute its warranty to become void.



NOT WATER-RESISTANT / WATERPROOF

iOS: 10.0 or later | Apple Watch: 1st generation or later

Android: 4.4 (KitKat) or later

Bluetooth: 4.0 or later

The device is designed for outdoor use. Do not expose directly to condensed moisture / rain.



CAUTION! GRIP MAY BECOME HOT WHILE IN USE

When heated do not touch without protective gloves.



DO NOT EXPOSE DIRECTLY ONTO FIRE

Prolonged exposure directly onto fire (temp. > 380°C / 716°F) may cause the probe to malfunction.



NOT DISHWASHER SAFE

Avoid submersion into water. Do not put inside the dishwasher.



KEEP AWAY FROM CHILDREN

Probe tip can cause injuries to children. Keep away from their reach.



REMOVE WRAP BEFORE USING

Probe wrap is for storage purposes only. Unfold wire and remove wrap before each use.

SPECIFICATIONS

COMPATIBILITY

GrillEye®, GrillEye® PRO+ Weber iGrill series

DOCUMENTATION / CERTIFICATES grilleve.com/certificates



















G&C Itd® offers a limited warranty against manufacturing defects, in compliance with the laws and regulations of each region of distribution. For details about the warranty, visit www.grilleye.com/warranty or send an email to support@grilleve.com. Operation of the device is subject to the following conditions (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of this device.

Apple®, the Apple logo, iPad®, iPhone®, and iPod® touch are trademarks of Apple lnc., registered in the U.S. and other countries. App Store is a service mark of Apple lnc. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG Inc. Android® and Google Play are trademarks of Google Inc. WiFi® and other trademarks and trade names are those of their respective owners.



FCC Caution.

FCC Caution.

§ 15.19 Labelling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause

undesired operation.

§ 15.21 Information to user.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

§ 15.105 Information to the user.

Note: This equipment has been tested and found to comply with the limits for a Class B

digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and

on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between theequipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction.