

正面

DA: Fjernstyret gaffeltruck
EN: Remote-controlled forklift truck
JA: リモコンフォークリフト
KO: 원격 조종 지게차

Warning:
 changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.


NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different


from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.


NOTE: This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.




DA: Frem
EN: Forward
JA: 前進
KO: 전진




DA: Drej til højre
EN: Turn right
JA: 右折
KO: 우회전




DA: Tilbage
EN: Backward
JA: 後進
KO: 후진




DA: Drej til venstre
EN: Turn left
JA: 左折
KO: 좌회전



DA: Løfte/sænke-funktion
EN: Tilt/lift
JA: ティルト/リフト
KO: 기울기/올리기



DA: Bak til højre
EN: Back to the right
JA: 右後進
KO: 다시 오른쪽으로



DA: Bak til venstre
EN: Back to the left
JA: 左後進
KO: 다시 왼쪽으로



背面

DA: Gaffeltrucken bruger 3 stk. AA-batterier (ikke inkluderet) og fjernbetjeningen 2 stk. AA-batterier (ikke inkluderet).

Vigtigt:

- Kø ikke med gaffeltrucken på sand, i græs eller på støvede veje
- Kø ikke med gaffeltrucken gennem vand og lad den ikke blive våd
- Tab ikke gaffeltrucken og udsæt den ikke for hårde slag.

Elektrisk og elektronisk udstyr samt medfølgende batterier indeholder materialer, komponenter og stoffer, der kan være skadelige for menneskers sundhed og for miljøet, hvis affaldet ikke håndteres korrekt. Elektrisk og elektronisk udstyr og batterier er mærket med en overkrydset skrældepsand. Den symboliserer, at elektrisk og elektronisk udstyr og batterier ikke må bortskaffes sammen med usorteret husholdningsaffald, men skal indsamles særskilt. Nogle batterier er også mærket med den kemiske betegnelse Hg (kviksølv), Cd (cadmium) eller Pb (bly). Dette er særligt skadelige stoffer, og det er derfor vigtigt, at disse batterier bliver indsamlet. Som slutbruger er det vigtigt, at du afleverer dine udtjente batterier til de ordninger, der er etablerede. På denne måde er du med til at sikre, at batterierne genanvendes i overensstemmelse med lovgivningen og ikke unødigt belaster miljøet. Søg nærmere information hos din kommune. Gem denne information til senere brug. Zebra A/S erklærer hermed at dette elektroniske produkt er i overensstemmelse med de obligatoriske krav og andre relevante bestemmelser for Direktiv 2014/53/EU. Overensstemmelseserklæring kan erhverves hos Zebra A/S, Strandgade 71, 1401 CPH, DK.

EN: The forklift truck uses 3 pcs. AA batteries (not included) and the controller 2 pcs. AA batteries (not included).

Important:

- Do not run the forklift on sand, in grass or in dusty areas
- Do not drive the forklift through water or let it get wet
- Do not drop the forklift or subject it to hard knocks.

Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. **Warning:** Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. **NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: • Reorient or relocate the receiving antenna. • Increase the separation between the equipment and receiver. • Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. • Consult the dealer or an experienced radio TV technician for help. Shielded cables must be used with this unit to ensure compliance with the Class B FCC limits. Hotline: 1 (844) 350-0560. ZEBRA A/S: 920 BROADWAY, NEW YORK, NEW YORK 10010

JA: リモコンフォークリフト 本体単3形電池3個使用 (別売り)、リモートコントローラー単3形電池2個使用 (別売り)。

重要:

- フォークリフトを砂、芝生、埃っぽい場所で使用しないでください。
- フォークリフトを水気のある路面で走行させたり、濡らしたりしないでください。
- フォークリフトを落としたり、ぶつけたりしないでください。

ご不用になった電池は各自自治体の指示に従って破棄して下さい。

KO: 원격 조종 지게차. 지게차는 AA 건전지 3개 사용 (불포함). 조종기는 AA 건전지 2개 사용 (불포함).

주의사항.

- 모래, 잔디 위, 또는 먼지가 있는 곳에서 지게차를 조종하지 마십시오.
- 지게차를 물 속으로 조종하지 마십시오. 젖을 수 있습니다.
- 지게차를 떨어뜨리거나 거칠게 다루지 마십시오.

경고 충전, 분해, 단락, 가열하지 말 것. 누액, 파열의 우려가 있으므로 (+), (-)를 바르게 넣을 것. 다른 전지와 혼용하여 사용하지 말 것.

