

## 2.4G Keyboard

### User Manual

### Package Contents

- 1 x Wireless Keyboard
- 1 x 2.4GHz USB Receiver
- 1 x User Manual

### Keyboard Specification

|                 |                                  |
|-----------------|----------------------------------|
| Dimensions      | 373.5*129*17.56mm                |
| Power Source    | 2 x AAA Batteries (Not included) |
| Working Current | 2mA                              |
| Standby Current | 0.8mA                            |
| Sleep Time      | 5 seconds                        |
| Wake-Up Type    | Click any key                    |
| Low Voltage     | Flash per second                 |
| Sleep current   | 0.6mA                            |

### Keyboard Indicator

1. Fn Lock Indicator : Blue right ,F1-F12 will be got directly after pressing Fn+Fn Lock together
2. Numeric Indicator: Press NumLock, LED will be green, Press them again, LED will be off.
3. Caps Lock Indicator: Green light is on. ( For Android users: No Caps Lock indicator, but will still function normally.)
4. 2.4GHz pairing indicator and low voltage indicator: green light, the LED will be off after the power indicator lights up for 3 seconds.
5. Power Indicator: Green light is on.

### 2.4G Keyboard Pairing


1. Remove the 2.4G USB receiver from its location of keyboard back side, Plug the USB receiver into an available USB port of the computer. Install the 2 x AAA batteries (not included), turn on the power switch from the mouse backside.
2. Turn on the power switch of the keyboard, it will be connected within 3 seconds.



Note: If connection failure, press together to pair.

### Keys and Functions


Press and hold the "Fn" keys while pressing the blue keys ( include F1-F12 ).



## Fn Lock Key

















Normally, the function of blue letters need be got with Fn keys.

For example, we want to get “F1” , normally,we need press “ Fn+F1” together to get the function.

But if we press “Fn+” firstly, the Fn key be locked, we can press “F1” directly to get the function.

## Multimedia Function

Press directly to activate below action.

|   |   |   |                               |  |                            |
|---|---|---|-------------------------------|--|----------------------------|
|    | Esc                                       |    | Mute                          |    | Volume-                    |
|    | Volume+                                   |    | Previous track                |    | Play/pause                 |
|    | Next track                                |    | Lightness -                   |    | Lightness +                |
|    | Favorites                                 |    | Desktop switching             |    | Browser                    |
|  | Open wireless device (Windows 8 or above) |  | Settings (Windows 8 or above) |  | Share (Windows 8 or above) |
|  | Search                                    |   |                               |  |                            |

## FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency

energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the

interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.