


272mm

45mm

**Pairing the headset with a Bluetooth enabled device**

1. Plug 3.5mm wired headphones into Line In port (see locations of controls below).
2. Press and hold ON/OFF button for around 4 sec, more details refer to bluetooth pairing in function list
3. The headsets are now in pairing mode and ready to be connected to your Bluetooth device.
4. Keep the Bluetooth Audio Receiver Adapter and Bluetooth enabled device within 3 feet of each other during the pairing process.
5. Set your Bluetooth enabled device to search for Bluetooth Audio Receiver Adapter.
6. When your Bluetooth enabled device finds the Bluetooth Audio Receiver Adapter, select "BWA18W1111" from the list of found devices.
7. After a successful registration, the LED indicator light will slowly blink blue.



P5

**Troubleshooting tips**

- **I cannot turn the headset on**  
Make sure that you fully charged the headset before turning it on.
- **My mobile phone is not able to locate the Bluetooth Audio Receiver Adapter.**  
Check that the Bluetooth Audio Receiver Adapter is in pairing status (blue/red indicator light flashes quickly) delete the existing bluetooth headset name in phone, search again.  
If still cannot search Bluetooth, please restart the Bluetooth Audio Receiver Adapter and phone, try again.
- **After successfully pairing my mobile phone and Bluetooth headset, it got disconnected**  
Bluetooth Audio Receiver Adapter battery is nearly exhausted.  
Bluetooth Audio Receiver Adapter and your phone are out of the valid connection distance (10 m).  
Blocked or intermediate obstructions are between Bluetooth Audio Receiver Adapter and your phone signal.
- **When I am answering a call, I cannot hear anything**  
Check that the phone is connected with Bluetooth Audio Receiver Adapter, instead of speaker or phone when answering the call.  
Try adjust the volume on your mobile phone.  
Press the Vol+ or Vol- Buttons to adjust the volume.
- **When I am listening to the music, I cannot hear anything**  
Press the Vol+ button to adjust the volume.  
Reconnect the headset with your mobile phone.  
Make sure the media audio is open on the mobile phone.
- **I cannot charge the Bluetooth Audio Receiver Adapter**  
Make sure the charging pin and the other end are connected well.  
Make sure the charging cable is functioning well.

P6

**Note**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.


**blackweb** USER MANUAL



Model: 17LY43  
BLUETOOTH® AUDIO RECEIVER ADAPTER

P1


**In the box**



Bluetooth Audio Receiver Adapter  
User Manual  
0.45M USB Charging Cable  
Aux Cable

P2

**Location of controls**



VOL+  
ON/OFF  
PREV  
VOL-  
LED LIGHT  
NEXT  
Aux out  
USB port

P3

**Function List**

Operating	Function	
Long press	Turn on	there is three tone prompt, Blue light solid.
Long press	Turn off	there is three tone prompt.
Long press	Bluetooth pairing	Press and hold for around 4 sec, LED will flash red and blue when ready to connect, In your device's Bluetooth settings activate bluetooth and select "BWA18W1111", Blue LED flashes when connected
Short press	Answer calls Hung up calls	
Long press	Reject calls	

Press the ON/OFF button

P4

**Function List**

Function	Operating	
Low power	there are "battery low" voice prompt, Red light flash per 5s, 30 minutes prior to battery being drained.	
Charging	Solid red	
Fully charged	Red light off	
Volume control	Long/short press VOL+, VOL- button to adjust	
Play/Pause	Short press ON/OFF button	
Previous track	Short press ◀ button	
Next track	Short press ▶ button	
Maximum Volume	there is one tone prompt, Blue light flash per 5s.	
Automatic connection	Within effective communication range, when the Bluetooth receiver POWER ON, it will reconnected automatically.	
Line in	Once into the 3.5mm Earphone, it can playback music from external device.	