

Use Manual

Contents

About the Manual

CE FCC Notice of Regulation

Attention to Battery

- 1 Introduction
 - 1.1 System Requirement
 - 1.1.1 Connect mobile device
 - 1.2 Features
 - 1.3 Package
 - 1.4 Product Overview & Button Definition
 - 1.4.1 EVA Selfie Robot
 - 1.4.2 Remote Control
- 2 Starting to use
 - 2.1 Charging up EVA
 - 2.1.1 Charging by Computer
 - 2.1.2 Charging by Socket
 - 2.1.3 Charging Mobile Phone by EVA
 - 2.2 Definition to Instruction Light
 - 2.2.1 EVA
 - 2.3 Assembly
 - 2.3.1 Initial Setting
 - 2.3.2 Quick Use Instructions
- 3 Application Mode to Install EVA
 - 3.1 Application Mode to Install EVA
 - 3.2 Quick Use Instructions

Model Number: ZH-0501 (optional RF Remote Controller)

01

4 Using ADA application Mode

4.1 Definition to APP

5 Setting up the way to use

5.1.1 Function Choosing List

6 Specifications

7 Certification/Guarantee Card

About the Manual
The information in this manual is just for your reference and could be changed at any time without prior notice. Our company has made every effort to ensure the correctness and completeness of this manual.

Notice This product and its antenna must not be co-located or operated with any other antenna or transmitter in the same location.

CE Notice of Regulation
We hereby confirm that this device complies with the following EU Council Directives:
R & TTE New Directive 2014/53 / EU, LVD Directive 2014/35 / EU

FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Attention to Battery

- Charge only with our system; Improper handling of the battery may cause an explosion.
- Do not disassemble, puncture or short-circuit the battery by yourself; Keep the battery out of reach of children.
- Exposing the battery to an open flame may cause an explosion; Do not dispose of the battery in a fire.
- Disposing of used batteries in accordance with local regulations.
- Do not replace the battery by yourself; Please contact your dealer for replacement.

Attention to Safety

- Do not disassemble or remove any parts by yourself, as this will void the warranty claim.
- Keep the device away from children or pets to prevent danger of swallowing.
- If smoke or odor is detected during operation, immediately turn off the power and take it to a nearest authorized service center; Do not attempt to repair the product yourself.
- Use recommended power accessories; Use of non-recommended power accessories may result in overheating, distortion of parts, or some hazards, such as fire, leakage.
- The Bluetooth signal cannot penetrate the building, the signal distance is 10 meters.
- Bluetooth operation channel table: CHO-CN39
- This product uses wireless data communication. May interfere with, or be interfered by, adjacent devices.
- Do not use this product near microwave ovens or in any locations where magnetic waves and radio interference may occur.
- The reception of radio waves may be poor in certain circumstances.
- Please note that if other devices use the 2.4 GHz band, the processing speed of both devices may be slowed down.
- This product will be slightly hot in use; It is a normal phenomenon and does not mean malfunction.

- Your warranty will be void if you improperly use the product and cause damage to the equipment or accessories.
- The radio frequency of this product may interfere with other electronic device's radio frequency, then cause negative effect and malfunction. Wireless transmitters and circuits may also interfere with other electronic devices. Please obey the following notice:
- Airplane: If you are not allowed to use the wireless transmitter when you are on board, please turn off this product.
- Vehicle: The radio frequency emitted by this product may affect the electronic system in the motor vehicle. Please consult with the manufacturer or the agent of the motor vehicle about the problem.
- Heart Rate Regulator: To avoid potential interference with the heart rate regulator. The one who wears a heart rate regulator should keep a distance between the our product and heart rate regulator at least 15 centimeters (6 feet) away; And do not place the product in the chest pocket, if interference phenomenon happened, please immediately turn off power of this product.
- Medical Devices: If you are using any personal medical device, ask your device manufacturer or physician if your device adequately shields the radio frequency emitted by this product.

03

Medical Appliance: Hospitals and medical devices may use equipment that is sensitive to external radio frequency energy. Follow instructions when a medical practitioner or posting signs indicate that you switch off equipment which can interfere with radio frequency.

- Blasting areas and places for posting announcements: To avoid interference with blasting operations, follow all signs and instructions in the "blasting area" or "off-the-change radio" area to switch off equipment that can interfere with radio frequency.
- This product is not suitable for shooting any bar code.
- Do not expose this product to any chemical gas / liquid.
- Your warranty will be void if the product is exposed to moisture by improper handling.
- This product is intended for use only at ambient temperatures of 0 ° -40 ° C (32 ° -104 ° F) and 0-90 % RH ambient humidity.
- This product is intended for use only at ambient temperatures of 0 ° -50 ° C (32 ° -122 ° F) and 0-90 % RH.

Failure to follow the above precautions may result in equipment failure. This warranty does not cover damage due to false operational.

1 introduction

1.1 System Requirement

1.1.1 Connect mobile device to connect your mobile phone.

Please make sure your phone meets the following specifications:

iOS System:
Applicable version: 7/8 Or above
Product Name: iphone5/iphone5S/iphone6/iphone 6 Plus/iphone 7/iphone7 Plus
Android System:
Applicable version: 4.3 Or above

1.2 Features

1.2.1 Support Android/iOS App

1.2.2 Automatic photography

1.2.3 360 ° horizontal rotation

1.2.4 The remote control can operate EVA through radio

1.2.5 Face Tracking




1.2.6 Panoramic mode

1.2.7 Used for entertainment and educational purpose

05

1.3 Package

The following is the contents of the package, for any missing or damaged items, please contact dealer immediately.



1 Photography
2 Video
3 Zoom out
4 Zoom in
5 Left Button
6 Right Button
7 180 ° Rotation Shooting
8 360 ° Rotation Shooting
9 Automatic Face Tracking
10 The Front and Rear Lens Switch

Note: Press [Power] for video and stop recording.


07

2 Starting to use

2.1 Charging up EVA


2.1.1 Charging by Computer

- 1 Plug the Micro USB cable into the USB connection of the device.
- 2 Connect the other end of the Micro USB cable to your PC USB port.



2.1.2 Charging by Socket

- 1 Plug the Micro USB cable into the USB connection of the device.
- 2 Connect the other end of the Micro USB cable to the USB port of the USB power adapter, and then connect it to a power outlet.



2.2 Definition to Indicator Light

2.2.1 EVA

NO.	Items	State	LED Light
1	Indicator Light	Power On Bluetooth Connected	Solid Light Flash
		Power Off Version Update	Turn Off Red Light is on

2.3 Assembly

1 Place the phone horizontally in the groove of the silicone holder

- Notes:**
- 1 Do not use your hand to rotate and swing EVA, since it will cause damage to products and is man-made sabotage.
 - 2 Please put the mobile phone in silicone holder well, avoiding the drop of phone.
 - 3 When using the bottom tripod screw, be careful to avoid damage.



09

3 Initial Setting

3.1 Install the application of EVA

The EVA can be connected to your mobile via application. For the first time to use EVA, please install the APP for ADA on your mobile phone.

- 1 Scan the 2-D code below and download "X-Click".
- 2 Successful Install



Note: "X-Click" is placed in the [Google Play], the installation of user to scan the two-dimensional code to download and install [Google Play] program, the person who has installed this program do not need download again.

- ### 3.2 Quick Use Instructions
- 1 Press the power button for 3 seconds to turn on product.
 - 2 Turn on Bluetooth in your mobile phone.
 - 3 Open APP, touch [Power], and select ADA; connection is complete.

Notes:

- 1 The device automatically rotates when connected to Bluetooth.
- 2 When using APP, do not lock the screen direction.

4 Using ADA application Mode

4.1 Definition to APP



11

NO.	Icon	Items	Picture showed	Remarks
1	[EVA]	EVA		
	[Remote Control]	Remote Control		
2	[Single Mode]	Single Mode	[Single Mode Icon]	Face auto-detection: 1. Automatically rotate the Back, the front face should be in the center. 2. When the person in the center fixed for a few seconds (setting the time in mobile phone), then shooting automatically. 3. If the face is not detected, EVA can automatically track face (setting in the phone).
	[Couple Mode]	Couple Mode	[Couple Mode Icon]	Face auto-detection: 1. Automatically rotate the Back, the front two faces should be in the center. 2. When the person in the center fixed for a few seconds (setting the time in mobile phone), then shooting automatically. 3. If the face is not detected, EVA can automatically track face (setting in the phone).
3	[Tripod Mode]	Tripod Mode	[Tripod Mode Icon]	Face auto-detection: 1. Automatically rotate the Back to lock three or more faces and set the screen to the best position. 2. When the person in the center fixed for a few seconds (setting the time in mobile phone), then shooting automatically. 3. If the face is not detected, EVA can automatically track face (setting in the phone).
	[Only chasing no shooting mode]	Only chasing no shooting mode	[Only chasing no shooting mode Icon]	Face auto-detection: 1. Automatically rotate the Back to lock three or more faces and set the screen to the best position. 2. When the person in the center fixed for a few seconds (setting the time in mobile phone), then shooting automatically. 3. If the face is not detected, EVA can automatically track face (setting in the phone).
3	[Panoramic shooting]	Panoramic shooting	[Panoramic shooting Icon]	1. Automatically switch to the rear lens. 2. Do not support flash. 3. Can be interrupted at any time.
4	[Parallel tracking]	Parallel tracking	[Parallel tracking Icon]	360° horizontal tracking
	[Photo quality]	Photo quality	[Photo quality Icon]	
5	[Video quality]	Video quality	[Video quality Icon]	
	[Countdown Speed: (Remote control)]	Countdown Speed: (Remote control)	[Countdown Speed: (Remote control) Icon]	Fast (2 sec) / normal (3 sec) / slow (5 sec)
6	[Automatic face tracking]	Automatic face tracking	[Automatic face tracking Icon]	on/off
	[Front and back setting switch]	Front and back setting switch	[Front and back setting switch Icon]	
7	[Flashing on]	Flashing on	[Flashing on Icon]	
	[Flashing off]	Flashing off	[Flashing off Icon]	
		[Flashing automatically]	[Flashing automatically Icon]	


13

5 Remarks

5.1 Setting up the way to use

You can set the APP function as you like according to the tips shown on the right:

1. Turn on the APP
2. Click to enter the contents setted



5.1.1 Function Choosing List
For more information about content options and the available menus, please see the following table.

Contents options	Available menus
Photo quality	High / Medium / Low
Video quality	High / Medium / Low
Countdown Speed: (Remote control)	Fast (2 sec) / normal (3 sec) / slow (5 sec)
Automatic face tracking	on/off
Front and back setting switch	
Flashing on	
Flashing off	
Flashing automatically	

6 Specification

Category	Items	ADA Product Specification
Specifications	Weight	Max 200g
	Dimensions	Unlimited
	Operating temperature	0° ~ 40° C
Storage temperature		0° ~ 50° C
Machine operation	Bluetooth	Bluetooth 4.0 (low power), operating distance: 10 meters
	Audio	87 wireless remote control, operating distance: 10 meters
Battery	Capacity	120 mAh, polymer lithium-ion battery, rechargeable
	Charging hole	5V/5A
Material	Material	ABS
	Surface treatment	Two pieces, thickness to support the phone: 5-8MM
Weight	Weight	110g
	Height	Height: 73mm / Diameter: 67mm / 16g
Tripod screw	Material	Aluminum
	Software	Software: upgradeable
Language	Language	English, Traditional Chinese, Simplified Chinese
	System	Android 4.3 and above
System	OS	IOS and above
	Bluetooth	Bluetooth 4.0
Standby time	Standby time	The machine fully charged can be used for 3 hours continuously
	Standby time	The machine fully charged can be standby 10 days
Frequency		2402-2480MHz
	Channel list	CHO-CN39

15

Warranty Card

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not properly installed and used, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The distance between user and products should be no less than 20cm

Release date: _____

Inspectors: _____

Product model:	Purchase Date:
Warranty content:	Warranty Date:

Certification

Release date: _____

Inspectors: _____

17