


# Wireless Headset



E6

User's Manual

## Specifications



## Product Description

Frequency Range :	2.400 – 2.480GHz
Sensitivity :	-80db < 0.1%BER
BT Version :	V4.2
BT Chipset :	Airoha1524
Support Profiles :	HSP, HFP, AVRCP, A2DP, AAC
Working Distance :	10 meters
Music Time :	2-3 hours
Talk Time :	2-3 hours
Standby Time :	> 120 hours
Charging Time :	1-2 hours
Earphone Battery :	55mah
Backup Battery :	1000mah
Accessory :	1. Micro USB charging cable 2. User manual 3. 2 pairs of ear muff

## Earbud Description

Battery Life : (one earbud): 5-6 hours  
(two earbuds): 2-3 hours  
Wireless Range: (one earbud) about 15 meter  
(two earbuds) about 10 meter  
Charging Time : 1-2 hours

## Charging Case Description

Charging Time : 2-3 hours  
Charging Case Output : can charge the earbuds approximately 4-5 times

## Pairing ( Automated and Manual )

**Automated Pairing**

- Take out two earbuds from charging case, after waiting for 4-5 seconds, two earbuds will pairing with each other automatically.
- Go onto your device and find " HT-E6 " in your BT available devices.

**Manual Pairing**

- Press and hold the function key of two earbuds for 5 seconds ( until the indicator light is flashing blue and red ).
- Go into your device and find " HT-E6 " in your BT available devices.

Note : Pairing mode should only be used on the initial pairing of a new device OR to reset the pairing between the earbuds and device.

## Turn ON

**Automated Turn On**  
Two earbuds will turn on automatically when take out from the charging case.  
**Manual Turn On**  
Press and hold two earbuds function key for 2 seconds (until you hear " power on " or until the indicator light flashes red)

## Turn OFF

**Automated Turn Off**  
Two earbuds will turn off automatically when put in the charging case.  
**Manual Turn Off**  
Press and hold ONE of the earbuds function key for 2 seconds (until you hear " power off " or until the indicator light flashes red and then turns off ).  
Note : Earphones will turn off automatically after 10 minutes of non-connection with mobile phone or other device.

## Functions

- Start or pause audio by press the function key once, on one of the earbuds.
- Skip songs by double-pressing the function key, on one of the earbuds.
- Answer or hang up a call by pressing the function key once, on one of the earbuds.

## FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by

turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

Since the size of the earphone (intentional device) is too small, and the size of the label is larger than it, it cannot be placed, so the label can only be placed on the outer packaging.