



FCC ID: 2AKZ8-LBS070

PrimeAudio®

TEMPO



This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.



BATTERY SAFETY: This product is fitted with a Li-Polymer battery. Do not damage, open or dismantle the battery and do not use it in damp and/or corrosive conditions. Only use compatible chargers. Never dispose batteries in a fire and never expose them to high temperatures. Do not expose the product to temperatures exceeding 60°C (140°F).

BATTERY DISPOSAL: The crossed-out whee-bin symbol means that you may not dispose of this product together with general household waste; instead, take it to a recycling point for electrical and electronic equipment. For more information about local recycling points, contact your local authority, civic amenity site or the business where you purchased this product. The separate collection and recycling of used items of electrical and electronic equipment prevents any harmful substances they contain from harming human health and polluting the environment.

Please keep this information for later reference.

WARNING!
RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE.
DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

© 2024 PRIMEAUDIO
240 W. 37TH ST, NEW YORK, NY 10018
THE BLUETOOTH® WORD MARK AND LOGOS ARE REGISTERED TRADEMARKS OWNED BY BLUETOOTH SIG, INC., AND ANY USE OF SUCH MARKS BY IWorld IS UNDER LICENSE.
ALL OTHER TRADEMARKS AND TRADE NAMES ARE THOSE OF THEIR RESPECTIVE OWNERS. ACTUAL PRODUCT MAY DIFFER SLIGHTLY FROM IMAGE SHOWN. MADE IN CHINA.



Instruction Manual

Product Diagram



Instruction Manual

BLUETOOTH® WIRELESS SPEAKER

FEATURES

- Works with all Bluetooth®-enabled devices.
- Stream audio wirelessly via Bluetooth® technology in high, uncompromising quality from up to >33ft away.
- Integrated rechargeable lithium-ion battery provides hours of playing time wherever you go.

SPECIFICATIONS

- Rechargeable Battery: Li-Ion 800mah
- Wireless Capability: Up to 33ft range

CONTENTS

- 1 Wireless Speaker
- 1 USB Charging Cable
- 1 User Manual

- Supply Voltage: 3.7V
- Driver Diameter: 52 mm/4Q 5W
- Nominal Impedance: 4Q
- Frequency Response: 20Hz - 20kHz
- Sensitivity: 77 ± 3dB

CHARGING THE BATTERY

The internal Lithium-Ion battery must be fully charged before first use of the speaker.

To charge the battery:

1. Insert the smaller USB TYPE-C connector of the included USB cable into the charging input port on the back of the speaker unit
2. Insert the larger USB connector into either the USB port on a computer OR into a compatible USB DC 5V wall charger (not included) to charge through a standard wall outlet. The indicator lights will be red while charging, and will turn off when charging is complete.

WIRELESS SPEAKER OPERATION

Wireless playback Via Bluetooth:

1. Make sure the battery is charged as explained above.
2. Press and hold the M button for 3 seconds to turn the speaker on, a tone will signal to remind you to connect your Bluetooth device.
3. Activate Bluetooth function on your smartphone/computer/audio source device – it should automatically recognize the speaker unit and allow you to select it using the name "PrimeAudio". Another tone will indicate when connected successfully and you are now set to enjoy wireless audio from within a 33ft range of the audio device.
4. Press the M button to switch between Bluetooth mode and FM mode.
5. Short click the < button to move to the previous song in Bluetooth mode or search down the channel in FM mode.
6. Press and hold the the < button to lower the volume.
7. Short click the > button to move to the next song in Bluetooth mode or search up the channel in FM mode.
8. Press and hold the the > button to raise the volume.
9. Speaker will turn off Automatically after 5min without connection.
10. Press and hold the M button for 3 seconds to turn the speaker off.

CAUTION

- This is not a toy. Please keep away from small children.
- Do not overcharge the battery.
- Please keep the unit away from water and heat.
- Do not operate charge case with a damaged cable.

TECHNICAL SUPPORT

Please do not attempt to fix the product yourself. If you are experiencing any problems with the product please do not return it to the store you bought it from. You can contact our technical support representatives and they will assist you with any questions you may have. For assistance operating your product, please consult the User's Manual or feel free to contact iWorld technical support:

iWorld LLC
240 West 37th St., 10th Floor
New York, NY 10018, USA

www.iworldnyc.com
email: support@iworldnyc.com
Please keep instructions for further reference.