



ZEGAN



1:12 4WD RC Crawler instruction manual

DRIVING HINTS

It is highly recommended to read the operation instructions carefully prior to the first use. Please operate this product according to the guidelines specified in this instruction, and keep the instruction manual for future reference.

Age: 8+

WARNING

- This product contains small parts that may cause suffocation if swallowed by children under 3 years.
- Please keep this instruction manual for future reference, it contains important information of the product. Products shall be subject to any changes without additional notices;
- Please use it under the guidance of adults.
- Changes or modifications to this product not expressly approved by the party responsible for compliance may void the user's authority to operate the product.

BATTERY CAUTIONS

1. Please charge the battery prior to the first use. 8 hours charging time is required for the first two charges, then 4 hours per charge. Do not over-discharge the battery.
2. Please correctly connect the battery and charging wires, insert the charger to power outlet to recharge battery.
3. This product must only be used with the recommended battery and charger.
4. Regularly examine for damage to the plug, enclosure and other parts. In the event of any damage, the product must not be used until the damage has been repaired.
5. New and good alkaline batteries are recommended to use in this product to obtain best and maximum performance.


RC CRAWLER AND REMOTE CONTROL INSTRUCTION

RC Crawler operation hints:

- Please make sure the power switch button to "ON" position before using the car. It is non-functional if the power switch button to "OFF" position.
- When the car keep turning to left, please turn the trimming regulator to right until the car driving back to normal.
- When the car keep turning to right, please turn the trimming regulator to left until the car driving back to normal.


Remote control function introduction

- Steering wheel (turn left/right)
- Power indicator
- On/Off button
- Throttle trigger (forward/ backward)



BATTERY INSTALLATION AND CHARGING


1. Insert the batteries in the battery compartment with correct polarity.
2. Batteries are to be inserted with correct polarity as show in figure.
3. Please put the rechargeable battery in the battery compartment with correct connection. (car only)
4. Please lock the battery cover with four plastic parts as shown in figure.
5. The rechargeable battery can only be charged under the adult guardianship.




WARNING

1. Please play the product after closing the battery cover.
2. Please keep battery and car battery plug away from water.

Model B: Alkaline battery



Remote control



RC CRAWLER OPERATION INSTRUCTION

1. Turn the power switch button to "ON" position.
2. Use the remote control to control the car forward, backward, turn left, turn right.
3. The trimming regulator at the bottom of the car can be used to adjust the direction of the car if need.
4. Always switch the car and the remote control off when not operating.

BATTERY WARNING

1. The rechargeable battery can only be charged under the adult guardianship.
2. Rechargeable batteries are to be removed before being charged.
3. Exhausted batteries are to be removed from the product.
4. Make sure the power is off before install and recharging the battery.
5. Batteries are to be inserted with correct polarity.
6. Non-rechargeable batteries are not to be recharged.
7. The supply terminals are not to be short-circuited.
8. Always remove batteries from the product when it is not being used for a long period of time.
9. Do not use or leave the battery near a heat source such fire or heater, it may cause battery explosion or battery leakage.
10. Do not mix old and new batteries; Do not mix alkaline, standard(carbon-zinc) or rechargeable(nickel-cadmium) batteries.
11. Only batteries of the same or equivalent type as recommended are to be used.
12. Please check the battery regularly to avoid battery leakage.
13. Please keep this instruction manual for future reference, it contains important information of the product.

CARE AND MAINTENANCE

1. Do not submerge the product into water that can damage the electronic assemblies.(If for Amphibious car it can run on the water.)
2. Keep wire and plug away from water.
3. Wipe the product gently with a clean wet cloth.
4. Keep the product away from direct heat and wet.
5. Always remove batteries from the product when it is not being used for a long period of time.

SAFETY HINTS

•Warning! Do not touch the running car. Keep hands away from moving parts to avoid injury.



Do not play the product on the road or damage place to avoid injury.

Do not play the product in sump, sand or mud.

GENERAL TROUBLESHOOTING

Fault symptom	Fault cause	Handling method
The car is unable to drive.	1. Did not switch on the car or the remote controller. 2. Battery is not installed rightly in the remote controller. 3. Low power of the battery pack.	1. Switch on the car and the remote controller. 2. Install the battery rightly into the remote controller. 3. Charge for the battery.
The car is out of control, short remote control distance	1. Someone is using the same or close frequency nearby. 2. Power shortage of the remote control battery or rechargeable battery pack.	1. Drive in another place or wait for other people stop driving. 2. Renew the battery in the remote controller or to charge the rechargeable battery pack.

1. Warning:

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

2. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions :

- (1) this device may not cause harmful interference, and
 - (2) this device must accept any interference received, including interference that may cause undesired operation.
3. The device must not be co-located or operating in conjunction with any other antenna or transmitter.