


This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with the FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator and any part of your body.



尺寸: 110*160mm

材质工艺: 封面封底108g铜版纸, 内页书写纸
4色印刷+2专

 Pantone Grey 432 C

 Pantone 199C

 C:0 M:0 Y:0 K:15

Contents	
1.Preface	01
2.Accessories	01
3.Products	01
4.Precautions	01
5.Panel introduction	02
6.Operation instructions	03
7.LED light instructions	04
8.Main technical parameters	04
9.Solutions for simple faults	05

1. Preface
Dear users: Thank you very much for purchasing our products. In order to give full play to your player, please read this manual carefully before use and master the connection method and operation points of this system. We have explored various aspects of design, manufacturing process and user-friendly operation to meet your needs. Please keep this manual in a safe place for future reference. When you open the package, please check the following accessories carefully and keep them together to avoid loss.


2. Accessories
User's Guide X1 Type-c charging cable X1
Remote Control X1

3. Products
1. Advanced Bluetooth functionality for pairing with any Bluetooth-enabled device (Applicable to Bluetooth-enabled products).
2. Support TWS pairing connection.
3. Support high quality MP3 music files.
4. Strong power speaker, 3D digital audio technology, sound quality shock.
5. Connect with external audio devices with Bluetooth function.

4. Precautions
First of all, thank you for using our digital audio products! Before use, please read this manual for proper use of this product. For better service, the contents of this manual may change without notice due to changes in product performance and features. To maintain better performance, do not use the product in places that are too cold, too hot, dusty or humid.
To maintain better performance, do not use the product in places that are too cold, too hot, dusty or humid, and avoid the following conditions:
1. Wet or underwater environments
2. Heater or high temperature working environments
3. Directly exposed to sunlight
4. Easy to fall off
5. Do not disassemble the combo stereo by yourself, otherwise the warranty is invalidated.
WARNING: Please note that the product is waterproof, no dripping or splashing liquid items, such as vases, should not be placed on top of the unit to prevent accidents.
2. To avoid fire, electric shock and other accidents, please check whether the charging voltage is exactly the same as that required by the unit. The charging voltage is exactly the same as that required by this equipment.


EN I 01

5. Panel introduction
Introduction of buttons and holes: There is 1 button and hole, defined as follows:



1. Switch on/off 2. Indicator light
3. Type-C charging

Remote-control unit



1. Switch On/Off 2. Mode 3. Volume+ 4. Previous Song
5. Next Song 6. Volume- 7. 3D Mode 8. EQ Mode
9. Play/Pause 10. TWS Mode 11. Mute Mode

4. Operation instructions
Bluetooth mode
1. Long press the power button to turn off the device, the device will enter the Bluetooth mode by default and wait for pairing, short press twice to enter the TWS connection.
2. Turn on the Bluetooth function on the device, the device will start to search for Bluetooth devices.
3. Select "ON" from the list of found devices and choose pairing.
4. After successfully pairing with the device, the blue light will be lit.
5. After power on without Bluetooth connection, it will shut down automatically in 5 minutes.
Note: Bluetooth playback is controlled by your device and the buttons on the remote control.

7. LED Light Indications Description
1. Blue light: power on/blue light: fast flash, waiting to connect Bluetooth device, slow flash or long light continuous connection device successfully.
2. red light: red light is on when charging, full light is off, fast flashing low battery prompt, 3-5 seconds after the automatic shutdown.

EN I 02

8. Main technical parameters

Output Power	40W-60W
Power Supply	7.4V/(6000mAh-8000mAh)
Speaker Frequency	80HZ-20KHZ
Bluetooth Version	5.0
Bluetooth Range	Up to 10 meters

9. Simple troubleshooting solutions

Trouble	Solutions
Low volume or distortion	1. Check the audio volume and adjust it to the right size. 2. Check if audio sound quality is normal.
Indicator light is off	1. Check if the device is powered on properly.
Music discontinuity	1. There is an obstacle between the mobile device and the Bluetooth device, please remove the obstacle. 2. Exceed the effective connection distance.
Pairing failure	1. Check whether the cell phone is in pairing status. 2. The speaker has been paired with other devices successfully, first un-pairing other devices. 3. Delete the original device name by your cell phone and re-pairing.

This product has been manufactured and sold under the responsibility of MAXTALENT INDUSTRIAL LIMITED. THOMSON and the THOMSON logo are trademarks used under license by MAXTALENT INDUSTRIAL LIMITED. All other products, services, companies, trademarks, trade or product names and logos referred herein are the property of their respective owners.
Manufacturer: Shenzhen Qiyu Electronic Co., Ltd. Support: service@maxdigital.com
Website: www.maxdigital.com/thomson Made in China
V2.0

EN I 03

目录	
1.序言	01
2.配件	01
3.产品介绍	01
4.注意事项	01
5.面板介绍	02
6.操作说明	03
7.LED灯指示说明	04
8.主要技术参数	04
9.简单故障的解决方案	05

1. 序言
尊敬的用户:非常感谢您购买我们的产品!为了使您的播放器充分发挥作用,请在使用前仔细阅读本说明书,掌握本系统的连接方法和操作要点。我们在设计、制造工艺、操作人性化等方面进行了多方面的探索,满足您的需求。请妥善保管本手册,以备将来参考。打开包装,请仔细确认以下附件,为避免遗失请放在一起。


2. 配件
使用说明X1 Type-c充电线
遥控器X1

3. 产品介绍
1.先进的蓝牙功能,可与任何蓝牙功能设备进行配对连接(适用于蓝牙功能产品)。
2.支持TWS连接。
3.支持高品质MP3音乐文件。
4.强劲喇叭,3D数字音响技术,音质震撼。
5.可连接有蓝牙功能的外置音频设备。

4. 注意事项
首先,感谢您使用我们的数字音频产品!在使用前,请阅读本说明书以正确使用本产品。为了更好的服务,本手册的内容可能会因产品性能和功能的变化而发生变化,恕不另行通知。为了保持更好的性能,不要在太冷、太热、多尘或潮湿的地方使用,应注意避免以下情况:
1. 潮湿或水环境 2. 加热器或高温工作环境
3. 直接暴露在阳光下 4. 易脱落
5. 请勿自行拆卸组合音响,否则保修无效
警告: 请注意产品的防水,不得有滴水、飞溅现象。盛装液体的物品,如花瓶,不能放在设备顶部,以防发生事故。
2. 为避免火灾、触电等事故,请检查充电电压是否与本设备要求完全一致。


中文 I 01

5. 面板介绍
按钮和孔位的介绍:共有1个按钮和孔位,定义如下:



1. 开关机 2. 指示灯 3. Type-C充电口

遥控器



1. 开关机 2. 模式 3. 音量+ 4. 上一曲 5. 下一曲 6. 音量-
7. 3D模式 8. EQ模式 9. 播放/暂停 10. TWS模式 11. 静音模式

6. 操作说明
蓝牙模式
1. 长按电源键开关机,开机默认进入蓝牙模式,并等待配对,短按两下进入TWS连接。
2. 打开设备上的蓝牙功能,设备将开始搜索蓝牙设备。
3. 从找到的设备列表中选择"ON"选择配对。
4. 成功与设备配对后,蓝色灯点亮。
5. 开机后无蓝牙连接,5分钟后自动关机。
注意:蓝牙播放由您的设备和遥控器上的按钮控制。

7. LED灯指示说明
1. 蓝灯:开机蓝灯点亮快闪,等待连接蓝牙设备,慢闪或长亮连接设备成功。
2. 红灯:充电时红灯长亮,充满灯灭,快闪低电提示,3-5秒后自动关机。

中文 I 02

8. 主要技术参数

输出功率	40W-60W
电源	7.4V/(6000mAh-8000mAh)
扬声器频率	80HZ-20KHZ
蓝牙版本	5.0
蓝牙范围	10米以内

9. 简单故障的解决方案

问题	解决方案
音量低或失真	1. 检查音量并调整到合适的大小。 2. 检查音频质量是否正常。
指示灯不亮	1. 检查设备是否通电是否正常。
音乐断续	1. 移动设备和蓝牙设备之间障碍物,请清除障碍物。 2. 超过有效连接距离。
配对失败	1. 检查手机是否处于配对状态。 2. 音箱已与其他设备配对成功,先解除其它设备的配对。 3. 删除手机上的原有设备名称并重新配对。

制造商: 深圳市秋雨电子科技有限公司
网址: www.maxdigital.com/thomson
服务热线: service@maxdigital.com
中国制造 V2.0

中文 I 03

目次	
1. はじめに	01
2. 部品	01
3. 製品特徴	01
4. 注意事項	01
5. パネルの紹介	02
6. 操作説明	03
7. LED 指示説明	04
8. 技術パラメータ	04
9. トラブル解決策	05

1. はじめに
THOMSONをご依頼いただき、誠にありがとうございます。プレーヤーをフルに機能させるためには、ご使用前にこの説明書をお読み、本システムの接続方法と操作のポイントをお把握ください。私たちは設計、製造技術、操作の便利など多方面の探索を行い、お客様のニーズを満たしていきます。包装を開け、紛失しないように以下の部品をご確認ください。万一、部品欠落あるいは他の使用問題があれば、お気軽にアマゾンTHOMSON直営店にお問い合わせください。

2. 部品
取扱説明書X1 リモコンX1 Type-cケーブルX1


3. 製品特徴
1. 任意のBluetooth機能デバイスとペアリング接続できるBluetooth機能。
2. TWS機能。
3. 高品質MP3音楽ファイルをサポートします。
4. 強力なパワーホーン、3Dデジタル音響技術、音質が震撼しています。
5. Bluetooth機能を備えた外部オーディオデバイスに接続できます。

4. 注意事項
この取扱説明書は、予告なく製品の性能や機能の変化によって変更される場合があります。良い性能を維持するためには、要する、換する、はこりが多く、湿気が多い場所では使用せず、次のような状況を超えるようにご注意ください。
1. 高温または水中環境
2. 高温動作環境
3. 日光に直接さらされる環境
4. 平らでない場所や滑りやすい場所に置いて使用すること
ご注意: 火災、雷電などの事故を避けるために、充電電圧が本装置と一致しているかどうかをおチェックください。

5. 面板介绍
ボタンとジャックの概要: ボタンとジャックは各1つがあり、次のように定義されています。


日本語 I 01

5. 面板介绍
按钮和孔位的介绍: 共有1个按钮和孔位, 定义如下:



1. 電源 2. 提示ライト 3. Type-C充電ジャック

リモコン



1. オン/オフ 2. モード 3. 音量+ 4. 前の曲 5. 次の曲 6. 音量-
7. 3Dモード 8. EQモード 9. 再生/一時停止 10. TWSモード 11. 静音モード

6. 接続説明
Bluetoothモード
1. 電源スイッチを長く押し、電源を入れてデフォルトでBluetoothモードに入り、ペアリングを持って、2回短く押しTWS接続に入ります。
2. デバイスのBluetooth機能をオンにすると、デバイスはBluetoothデバイスの検索を開始します。
3. 見つかったデバイスのリストから"ON"を選択してペアリングを選択します。
4. デバイスとのペアリングに成功すると、青のランプが点灯します。
5. 電源投入後にBluetooth接続がないため、5分で自動的に電源が切れます。
注: Bluetooth再生は、デバイスとリモコンのボタンによって制御されます。

7. LED指示説明
1. 青色: 電源を入れて青ランプが点滅し、Bluetoothデバイスに接続するのを待って、スローフラッシュまたはロングフラッシュ接続デバイスが成功しました。
2. 赤色: 充電中に赤信号が点灯し、ランプが点滅し、フラッシュ低電力の提示があり、3-5秒後に自動的にシャットダウンします。

日本語 I 02

8. 技術パラメータ

出力効率	40W-60W
電源	7.4V/(6000mAh-8000mAh)
スピーカ周波数	80HZ-20KHZ
Bluetoothバージョン	5.0
Bluetooth範囲	10メートル

9. トラブル解決策

トラブル	解決策
音量が低い/かきみ	1. スピーカーの音量をチェックして適切なサイズに調整します。 2. スピーカーの音質が正常かどうかをチェックします。
指示灯が点灯しない	設備の電源が正常かどうかを確認します。
音楽切断	1. 移動設備とBluetoothデバイスの間に障害があることを確認します。 2. 有効接続距離を超えています。
Bluetoothペアリングができない	1. 携帯電話がペアリングされているかどうかをチェックします。 2. スピーカーは他のデバイスとのペアリングに成功しました。まず他のデバイスのペアリングを解除します。 3. 携帯電話の既存デバイス名を削除して再ペアリングします。

メーカー: 深圳市秋雨电子科技有限公司 お問い合わせ: www.maxdigital.com/thomson
サービスデスク: service@maxdigital.com Made in China
V2.0

日本語 I 03