

User Manual

Device Setup

1. Connect your device

Connect one end of the USB cable into your device and the other end into the power adapter. Plug your device into the HDMI port on your TV, then plug the power adapter into a nearby outlet. Turn on your TV, then select the appropriate HDMI input.

2. Complete the on-screen setup

Using your Remote, follow the on-screen instructions.

- Choose a language from the list.
- Select your Wi-Fi network from the networks displayed on the screen.

Note: If your Wi-Fi network is password protected, have your Wi-Fi network password handy to connect your device to the Internet. If your network is hidden, select the “Join Other Network” tile from the list. If required, enter your network password using the on-screen keyboard.

Registering your device

If you purchased your device online using your account, it is already registered to you.

If you received your device as a gift or it is not yet registered, please follow the on-screen instructions to register your device.

Product Specifications

Model Number: LDC9WZ

Electrical Rating: 5.0V = 1.8A

Operating Temperature: 0-35°C

FCC Compliance

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with

the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications that are not expressly approved by the party responsible for compliance could make the device no longer comply with the FCC Rules.

The output power of the radio technology used in the Products is below the radio frequency exposure limits set by the FCC. This device should be installed and operated with at least 20cm between the radiator and your body.

Information on your Device is on file with the FCC and can be found under the Display Grant section of <http://transition.fcc.gov/oet/ea/> after searching on the FCC ID for your Devices, which can be found on the side of the device and the battery compartment of the remote.