


# XO-9378-WG User Manual

## ONE、 Product sketch map



①、 Play / pause / switch machine key;

②、 Last song / volume down key;

③、 Next song / volume key;

④、 Headset

⑤、 Charging socket (USB socket);

⑥、 MIC port;

## **TWO、 Button function definition**

### **① Play / pause / switch machine key;**

Switch tone, English tone switch, music play / pause, answer / reject calls, hang up the phone number, at the end of the redial

### **② Last song / volume down key;**

**Last song / volume down**

### **③ Next song / volume key;**

**Next volume, volume plus**

## **THREE、 Button function instructions**

### 1、 Switch mode and pairing mode entry

Press the switch button for 3 seconds, turn on the machine, enter the pairing mode directly, the red and blue lights flash alternately. The Bluetooth search device for Bluetooth devices such as mobile phones can be turned on. Click on the Bluetooth device name to connect your cell phone to your Bluetooth headset. When Bluetooth headset is on, press switch button and Bluetooth headset is switched off. Enter the pairing mode, Bluetooth headset and mobile devices such as connection, success, shutdown, etc., will be prompted with corresponding tips.

### 2、 Bluetooth headset switch in English and Chinese

In pairing, double-click the switch key to toggle the tone in English and Chinese

### 3、 The caller refused calls and hang up

Mobile phone equipment and headset connected successfully and in the connection state, if there are calls, long refused to press the switch button, press the switch button to answer the call, in the process of short press the switch button hang.

### 4、 At the end of number redial

Mobile phone equipment with Bluetooth headset connection and in the connection state, double-click the switch button at the end of May, the redial.

### 5、 Play / pause music

When the Bluetooth headset and the mobile phone are in a connection state, press the switch button to play the music, and press the switch button again to stop playing again.

### 6、 Last song / volume down

When Bluetooth headset and mobile devices are connected and play music, press the last song / volume key to reduce the volume, and press the last song / volume key to play a song.

## 7、Next volume/volume plus

When Bluetooth headset and mobile devices are connected and play music, press a / volume key, press volume, press one song / volume key to play the next song

## FOUR、Description of Bluetooth headset status

Press and press the switch button for 3 seconds, enter the pairing mode, the red and blue lights are flashing, and after the connection is successful, the blue light is slow to flash. When the red light flashes in the process, the battery is too low. At this point, the power indicator is red and accompanied by a voice prompt that the battery is too low. When the headset is charged, the red light is on and the red light goes off when the charge is complete.

## Bluetooth headset electrical performance parameters

state	parameter
working voltage	3.0V~4.2V
Pair state current	1.5mA~14.2mA
Standby current (connected to Bluetooth)	0.46mA~8.53mA
Play music current	19.8mA~25.4mA
Call current	22.7mA~25mA
Charging current	100mA
ShutDown Current	1.5uA

### **FCC Statement**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.