

**FCC ID : 2ALCFXO-9833**

**Specifications:**

Powerbank:

Input:5V/2A

Output:5V/2A

Battery: 8000mAh/29.6Wh.

Wireless Output:compatible with 5W

Efficiency:  $\geq$  63%. FOD/NTC included.

**Features:**

1. Powerbank;
2. Wireless charging pad;
3. Phone stand;

**LED Indication:**

\*Power bank part: when the powerbank is connected to the power source,the powerbank is being charged ,the charging 4pcs LED indicator will flash in Blue, when the powerbank is full charged , the 4pcs LED will all light in Blue.

\*Charging your device by USB cable, the 4pcs LED indicator will light in Blue, when the device is fully charged, the 4pcs LED indicator will turn off.

\*Press the wireless charger button once to turn on the wireless charger function, the LED below the front mesh will light on in Blue, Place the enabled device on the surface of the wireless charging pad. If the phone or other device just support 5W, the LED will light in red.

**How to use**

**1. Charging the powerbank:**

Using a charge AC adapter (5V/2A or more),connect the cable.the powerbank is being charged.

**2. Wireless charging :**

Press the wireless charger button once to turn on the wireless charger function .the wireless charger LED indicator will light in Blue, place wireless charging supported mobile device on the wireless charging pad, the LED will turn in RED.

Press and hold the button 2 seconds to turn off the wireless charger function.

### **3. Use Powerbank:**

You can also charging your phone or other devices with a USB cable.

### **4. Bluetooth Setup:**

Press and hold power button to turn ON the speaker ,LED Indicator will flash BLUE when in pairing mode.Turn on the Bluetooth function on mobile device, Select “XXX” pairing name.LED will turn solid BLUE if successfully paired, Speaker will Remark:automatically pair if the mobile device has been paired before.

#### **Playing Music:**

Short press “Power Button” key to pause music.

A second short press will resume playing music again.Long press “Previous track/Vol-” , the speaker will play the previous track.

Short press to reduce speaker volume.Long press “Vol+/Previous Track” , the speaker will play the next track.

Short press to increase speaker volume.

#### **Call Function:**

Short press “Power Button” to answer a incoming call, press again to end call.

Long press to reject the call.

#### **Remark:**

If the powerbank is being charged, can not use cable to charge other device, also can not use wireless charger. No output current when the powerbank is being charged.

**NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:**

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.