

Jug Bluetooth speaker manual

PRINTED ON 150G PAPER
FOLD AND PLACE ON THE BOTTOM OF THE BOX

-  = DIE LINES (DO NOT PRINT)
-  = FOLD LINES (DO NOT PRINT)




Jug Bluetooth speaker

 WITH PORTABLE POWER BANK



USER MANUAL

SPEAKER FUNCTIONS 5.1



(A)  Press to skip to previous track. Press and hold to decrease volume.

(B)  Press and hold to turn on/off. Press to pause/play music or answer incoming calls or end phone calls.

Press **(B)** button twice to call back the last person you talked to.

(C)  Press to skip to next track. Press and hold to increase volume.

(D)  LED light indicates if device is paired and charging status.



IMPORTANT NOTES 1

- Please read this manual carefully before use.
- Remove power bank speaker from the growler body before washing.
- Please charge speaker with power adapter (Output: DC5V-1A).
- Charge in full before first use.
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this device.
- This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
- USB Cable included for charging only.

SPEAKER FUNCTIONS 5.2

(E)  Color-changing strobing lights.

(F)  To charge your power bank speaker, connect the micro-USB to the charging port.

(G)  Speaker


(H)  Microphone (see page 5.1 for phone calls instructions).

POWER BANK FUNCTIONS


(F) To charge your devices with the power bank speaker, connect the USB cable to the USB port.



PRODUCT CONTENTS 2



Micro USB charge cable




Jug Bluetooth speaker

POWER RECHARGING 6

Connect the USB cable included to charge your power bank speaker through a computer USB port or power adapter.

Low Power Warning: When voltage is lower than 3.5V, one beep will sound. Leave for at least 8 hours for full charge. When charging, LED lights indicate the battery charge, when power bank speaker is fully charged, all blue LEDs will be illuminated.



*Power adapter not included

TECHNICAL INFORMATION 3


Working Voltage	3.3-4.2V
Charging Power	5V/1000mA
Bluetooth Version	BDR+EDR
Recharge Method	Micro USB
Battery Capacity	5000mAh
Rated Power	3W
Bluetooth Range	<25 feet
Bottle Material	PP (BPA Free)
Product Size	122.0mm(L)*90.5mm(W)*35mm(H)
Product Weight	2 lb
USB Cable Length	12" (30mm)
Model Number	XO-9379

CONNECTING YOUR DEVICE 4

• Turn on the Bluetooth speaker by pressing and holding **(B)**.

• Turn your Bluetooth device on search mode. Find device titled "RUMBLE SPEAKER" and select.

• Once a connection with media device has been established, the flash will slow, remaining blue.



POWER ON/OFF



 @mannahydration
#mannahydration

The **Bluetooth**® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by MANNA™ is under license. Other trademarks and trade names are those of their respective owners.

WWW.MANNAHYDRATION.COM
NEW YORK, NY 10018
MADE IN CHINA

