


Tahoe Metal & Fabric Waterproof Speaker

Instruction Manual



Functions:

1. Micro-USB input port
2. ON/OFF Button

What's included:

- 1 x Waterproof Bluetooth Speaker
- 1 x USB to Micro-USB Charging Cable
- 1 x Instruction Manual

Tech Specifications

- Waterproof rating: IPX5
- Playing time: up to 8 hr at max volume
- Charging time: up to 5 hr
- Pairing Name: "Tahoe Speaker"

Instructions:

(Be sure to fully charge the speaker before using for the first time).

1. **Charging the Speaker**
 - Connect the provided charging cable to a power source and to the micro USB port on the speaker (1).
 - The LED indicator light will glow red when charging and turn off when fully charged.*
2. **Bluetooth® Setup:**
 - Press and hold ON/OFF Button to turn ON the device, LED Indicator will then flash BLUE when in pairing mode.
 - Turn on the Bluetooth function on mobile device, Select "Tahoe Speaker" pairing name.
 - LED will slowly flash BLUE when successfully paired.
2. **Music Controls:**
 - Short press the ON/OFF Button to play or pause music.
 - Short press the ON/OFF Button to answer incoming calls.
3. **Pairing Two Tahoe Metal & Fabric Waterproof Speakers**
 - If two speakers are purchased they can be paired to each other.
 - For the initial pairing process, make sure you're not connected to a single Tahoe Speaker. If you're connected via Bluetooth, please disconnect and forget this device in your mobile phone. Now turn off Bluetooth.
 - Turn on Both speakers simultaneously. Press the On/Off button on one of the speakers and they will pair automatically.
 - Once the Speakers have been paired to each other a BLUE LED light will flash on both speakers.
 - Now turn on the Bluetooth function on the

mobile device, Select "Tahoe Speaker".

- Only one pairing name should appear.
- You are now connected to both Speakers.

SAFETY PRECAUTIONS:

- WARNING-When using this product, basic precautions should always be followed:
 1. Read all the instructions before use.
 2. Never store or use this product in temperatures below 32°F(0°C) or above 115°F(45°C).
 3. The unit's full performance is achieved only after 2 or 3 completed charge and discharge cycles.
 4. To reduce the risk of injury, close supervision is necessary when the product is used near children.
 5. Do not use the device in excess of its output rating. Overload outputs above rating may result in a risk of fire or injury.
 6. Do not use the device if damaged or modified.
 7. Damaged or modified batteries may exhibit unpredictable behavior resulting in fire, explosion or risk of injury.
 8. Do not disassemble the device. For repairs, seek a qualified service professional. Incorrect reassembly may result in a risk of fire or injury.
 9. Do not expose the device to fire or excessive temperature. Exposure to fire or temperatures above 104°F may cause explosion.
 10. Ensure that qualified service professionals use only identical replacement parts to ensure product safety

FCC Statement:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.