



**BT60/蓝牙游戏耳机**  
快速入门指南



**产品参数:**

蓝牙版本: 蓝牙5.0  
频段: 2.4GHz-2.4835GHz  
工作时间: 20-30小时  
充电时间: 3个小时  
电池: 300毫安  
充电要求: DC5V/1A  
充电接口: TYPE-C  
喇叭:  $\phi 50\text{mm}$   
灵敏度: 120dB+3db  
阻抗:  $32\Omega \pm 3\Omega$   
频率响应: 20Hz-20,000Hz  
麦克风: -42dB $\pm 5\text{dB}$

**1.包装所含物品:**

①头戴式蓝牙游戏耳机  
②充电线  
③音频线  
④插拔麦克风  
⑤一转二转接线  
⑥快速入门指南

**注意事项:**

A. 请尽量避免长时间持续高音量使用, 这样会损害听力, 应使听力得到持续的保护。请尽量不要连续佩戴超过一个小时, 以保护您的听力。也更适合同歌佩戴。  
B. 避免将耳机长时间暴露在阳光下、高温下。潮湿多尘的环境会严重损坏电线, 影响正常使用。

**保修条例:**

产品的保修期为六个月, 从销售之日起, 仅限于机器零件、材料和功能的正常使用和维护。经鉴定识别出的问题和故障, 将免费维修和更换零件。


**本产品的保修不适用于:**

A. 耳机已超出保修期。  
B. 用户未按照说明指南要求, 造成耳机线材折断, 外壳破损。  
C. 未经本公司授权自行拆装, 修理, 改动结构。  
D. 因自然灾害等不可抗力(如地震, 火灾)原因造成的产品故障或损坏。  
注: 保修服务不包含产品运输费用及不提供上门服务。本保修条款解释权归ABINGO所有。


**保修反馈表 (勾选)**

A. 耳机无声音. B. 音质变差. C. 按键无法操作.  
D. 线材无人为因素发生损伤 E. 耳壳脱胶  
F. 插针接触不良 G. 其他

用户购买时间 \_\_\_\_\_ 购买的经销商 \_\_\_\_\_  
问题出现时间 \_\_\_\_\_ 用户联系方式 \_\_\_\_\_



**BT60/Wireless Gaming Headset**  
Quick Start Guide



**SPECIFICATION:**

Wireless Version: 5.0  
Frequency: 2.4GHz-2.4835GHz  
Working Time : 20-30 hours  
Charging Time : 3 hours  
Battery: 300mAh  
Charging Requirements: DC5V/1A  
Charging Port: USB-C  
Speaker:  $\phi 50\text{mm}$   
Sensitivity:120dB+3db  
Impedance:  $32\Omega \pm 3\Omega$   
Frequency Response: 20Hz-20,000Hz  
Microphone: -42dB $\pm 5\text{dB}$

**1.Package Content:**

①1x BT60 Gaming Headset  
②1x USB-C Charging Cable  
③1x AUX Cable  
④1x Detachable Microphone  
⑤1x 1-IN-2 Adapter  
⑥1x Quick Start Guide

**ATTENTIONS**

A. Try to avoid prolonged and continuous use at high volume which can damage your hearing, to make continuous wear hearing protection. Try not to wear continuously more than one hour to protect your hearing and be better for intervals wearing.  
B. Do not wear the earphones while driving or cycling driving in case of affecting safe driving.  
C. Avoid placing the earphones in prolonged sun exposure, high temperature, dusty and humid environments which will damage the wires a lot and affect the normal use.

**EARPHONES BREAK-IN & TIPS**

A. Select the suitable ear caps, wear it correctly and comfortably, to reduce the noise.  
B. Choose high-quality music, use thirty percent of volume to play 12 hours.  
C. Use sixty percent of volume to play 12 hours.  
D. Use the normal volume to play 72 hours.  
E. Use the eighty percent volume to play 24 hours.  
F. After the above steps the earphone break-in can exert 90%.

**IMPORTANT INSTRUCTIONS (RESPONSIBLE FOR YOUR HEARING)**

SOUND	noise level (dB)	EFFECT
Whisper	30	Very quiet
Quiet office	50-60	Comfortable hearing levels are
Vacuum Cleaner, Hair Dryer	70	Intrusive, interferes with
Food Blender	85-90	85dB is the level at which
Garbage Truck, Cement Mixer	100	No more than 15 mins of
Power Saw, Drill, Jackhammer	110	Regular exposure to sound
Rock Concerts (varies)	110-140	Threshold of pain begins


**WARRANTY**

This product is covered under warranty for a period of six months from the date of sale limited to normal use and maintenance of the machine parts, materials and functions. Problems and failures verified upon further identification, will be provided free repair and replacement parts.

**Limited to the following:**

A. Earphone is beyond the warranty period.  
B. User does not follow the instructions so that the earphone wire and earplug broken.  
C. Without the authorization to dismount, repair, alteration structures.  
D. Due to natural disasters and other force majeure (such as earthquakes, fires) product failure or damage causes.

Note: The warranty does not include product transport costs and does not provide on-site maintenance service.

 **ABINGO reserve all rights to clarify this warranty interpretation.**

**WARRANTY FEEDBACK FORM (TICK OFF)**

A. No sound B. Sound quality is bad C. Buttons can not be operated  
D. Wire damage occurred by artificial factors E. Earplug degumming  
F. Poor pin contact G. Others \_\_\_\_\_

Buying Time \_\_\_\_\_ Dealers of sale \_\_\_\_\_  
Time of problems \_\_\_\_\_ User's Contact info \_\_\_\_\_  
**Shenzhen Yoro-Style Electronics Co., Ltd**

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.