


User Manual

Product Name: MPOS

Model Name :MP45

MOBILE PAYMENT TERMINAL



• INSTRUCTIONS •

DEVICE KNOWLEDGE

The package including the device, instructions and charge cable.



The Device




Instructions



Charge Cable

Since the product is continually updated, the actual content may be slightly out of specification

DEVICE DIAGRAM



Back of device for contactless card reader area

CHARGE THE BATTERY

The device is built-in Lithiumion battery. Look at the battery status indicator (red) and status indicator (blue) at the upper-right corner of the screen. The device battery capacity is 250 mAh, about 2 to 3 hours per charge. After charging full, the endurance of device can support more than 600 times transaction.

SET UP

Press and hold power button for 1 second to turn your device on, after the screen lights on, it displays self-checking information and main interface. 30 seconds (user set) without operation, the system to be in the sleep state, you can wake up the device by pressing power button or mobile client has relevant orders issued ,the device will wake up automatically. 30 minutes (user set) without operation, the device will be shutdown automatically.

USE DEVICE COLLECTION

① Setup and login




* 需手机连接网络状态

② Connect to the mobile phone



③ Please input the amount receivable, then confirm it and click OK, swipe the card.



④ Swipe the card (According to the client prompts)



IMPORTANT

1. Please check on the network connection status of mobile phone before login.
2. Please swipe the card smoothly and quickly through the reader with the magnetic strip facing the thick side of the reader.
3. Do not plug IC card in the transaction process.
4. Do not use the device in extremely heat, cold or humid conditions.
5. Please turn off the power before cleaning, use dry cloth to wipe the device to avoid water and oil into it.
6. If the device has error, please contact with customer service immediately, do not disassemble the device.

CERTIFICATE OF QUALITY

Inspector:

Date:



SUCCESSFUL TRANSACTION

Cashier should check the bank account before the transaction, press the password after confirm the amount, if input error, you can press clear button and re-input.



SIGNATURE

To generate deals credentials



E-Signature



Electronic Receipts

WARRANTY TERMS & CONDITIONS

Dear customer

Since the date of purchase within one year, if the product has error and confirmed belong to occur under normal use (conform to the specifications provided by the operation and use of codes), please take the warranty card and purchase invoice back to the customer service of our company, we will fix it for free.

Please attention to the below clauses, the warranty card will be automatically invalidated.

- Due to failure of parts that are not original to the product or due to damage caused by abuse, misuse or any external cause.
- The fault caused by the maintenance, modification, removes without authorized personnel.
- Due to your own transportation accident, falls, collisions, water damage caused by the errors and damage
- Due to the earthquake, fire, flood, thunder and other disasters, environmental pollutions, improper voltage caused by the errors and damage.
- Due to improper storage (put the product in high temperature, high humidity, near the place of harmful drugs or corrosive), improper maintenance by the errors and damage.
- Sented with invoice and product, the warranty card number is not consistent with the device serial number.
- The Information of warranty card has been changed, such as the purchase date, seller name, machine number, etc.
- The product was not sold by the authorized distributors.

Warning Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.