

60mm

80mm

Manual Instruction

Bluetooth Headphone

BT30



BT30

SPECIFICATIONS

| | |
|-------------------|----------------|
| Bluetooth version | 4.1 |
| Operation range | Up to 10m |
| Profile support | HFP/A2DP/AVRCP |
| Driver size | 2" φ40mm |
| Battery capacity | 3.7V/300mAh |
| Products size | 185*140*60 mm |
| Microphone | -38db±/3dB |
| Frequency | 20Hz~20KHZ |
| Weight | 155g |
| Charging time | 2 hours |
| Playing time | Up to 10 hours |
| Standby time | Up to 30 days |
| Main material | ABS |

ACCESSORIES

| | |
|--------------------|----|
| USB charging cable | 1x |
| 3.5mm audio cable | 1x |
| Instruction Manual | 1x |

PARING

1. Keep the headphone and the device within 1 meter when pairing.
2. Enter pairing mode by holding the On/Off button for approx. 3 seconds until the LED light flashes blue.
3. Open Bluetooth in settings on your device and select "Casque BNP Paribas" from the list.
4. Some devices require a pin code. In this case, enter "0000".
5. If required, select "Casque BNP Paribas" from the Bluetooth device list to complete the connection.
6. Once successfully paired, the LED light will flash blue once every few seconds.

BT30

PLAYBACK/CONTROLS

1. Once paired, you can play music from your phone or music player.
2. Press "-" or "+" to fast forward or rewind.
3. Press "-" or "+" for at least 3 seconds to adjust Volume Up or Down.
4. Press Play/Pause to play or pause.

Note: Controls will not be available during charging.

CALLS

1. When there is an incoming call, Press Play/Pause once to answer. Press this button again to hang up.
2. Press "+" and "-" for at least 3 seconds to adjust the volume level down or up.

POWER ON

Press and hold On/Off button to turn the headphones on. The LED will flash blue when the headphone is active.

NOTE: The headphone will activate when charging.

POWER OFF

Press and hold On/Off button to turn off the headphone. The LED indicator will go out when the headphone is off.

60mm

80mm

Manuel d'Utilisation

Casque Bluetooth BT30



BT30

CARACTERISTIQUES

| | |
|-----------------------------|-------------------------|
| Version Bluetooth | 4.1 |
| Portée maximale | Jusqu'à 10m |
| Prise en charge des profils | HFP/ A2DP/ AVRCP |
| Taille du pilote | Taille du pilote 2* φmm |
| Capacité de la batterie | 3.7V/ 300mAh |
| Taille Produits | 185*140*60 mm |
| Microphone | -38dB+/-3dB |
| Fréquence | 20Hz ~20KHz |
| Poids | 155g |
| Temps de charge | 2h |
| Durée d'écoute | Jusqu'à 10h |
| Autonomie en veille | Jusqu'à 30 jours |
| Matériau principal | ABS |

ACCESSOIRES

| | |
|-------------------------|----|
| Câble de chargement USB | 1x |
| Câble audio 3,5mm | 1x |
| Manuel d'instruction | 1x |

CONNEXION BLUETOOTH

1. Gardez le casque d'écoute et l'appareil à moins d'un mètre lors de l'appairage.
2. Pour accéder au mode d'appairage, maintenez le bouton marche/arrêt enfoncé pendant environ 3 secondes jusqu'à ce que le voyant lumineux clignote en bleu.
3. Ouvrez Bluetooth dans les paramètres de votre appareil et sélectionnez "Casque BNP Paribas" dans la liste.
4. Certains appareils nécessitent un code PIN. Dans ce cas, entrez "0000".
5. Si nécessaire, sélectionnez "Casque BNP Paribas" dans la liste des périphériques Bluetooth pour terminer la connexion.
6. Une fois appariée avec succès, la lumière LED clignotera en bleu une fois toutes les quelques secondes.

BT30

LECTURE/CONTRÔLES

1. Une fois appariés, vous pouvez écouter de la musique à partir de votre téléphone ou de votre lecteur de musique.
2. Appuyez sur "-" ou "+" pour avancer ou reculer rapidement.
3. Appuyez sur "-" ou "+" pendant au moins 3 secondes pour régler le volume vers le haut ou vers le bas.
4. Appuyez sur Play/Pause pour lire ou mettre en pause.

Remarque : Les commandes ne seront pas disponibles pendant la charge.

APPELS

Lorsqu'il y a un appel entrant, appuyez une fois sur Play/Pause pour répondre. Appuyez de nouveau sur ce bouton pour raccrocher. Appuyez sur "+" et "-" pendant au moins 3 secondes pour régler le niveau de volume vers le bas ou vers le haut.

MISE EN MARCHÉ

Appuyez sur le bouton On/Off et maintenez-le enfoncé pour allumer le casque. La touche DEL clignote en bleu lorsque le casque d'écoute est actif.

REMARQUE : Le casque est actif lors de la charge.

ARRÊT

Appuyez sur le bouton On/Off et maintenez-le enfoncé pour éteindre le casque. Le voyant DEL s'éteint lorsque le casque d'écoute est éteint.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction