
Label & label location



The permanent label is on the manual, and the temporary label is as shown in the figure.