

正面：98\*98mm

反面：98\*98mm



**In the Box**

Large Medium Small  
Different Size Ear Tips and HiFi Wings  
Medium Memory Foam Tips

Nanobuds Pro 2.0 and Charging Case

USB-C Cable

**A Closer Look**

LED Indicator  
Call Microphone  
Environmental Noise Reduction microphone (Clear Calling)  
Touch Sensor  
Charging Contacts  
Note: To maintain reliable charging please clean the contacts from time to time with a cotton bud dipped in rubbing alcohol

**Charging**

Place the earbuds into the case to charge:

- Charging (indicator breathing red every 3S)
- Fully charged (indicator breathing blue every 3S)
- The LEDs turn off after about 60S to conserve power

The LED indicator will flash when charging:

- 0-25%
- 25-50%
- 50-75%
- 75-100%
- 100%

Connect the USB-C cable into the charging port to charge the case. The case's indicator will flash momentarily to indicate a low battery.

**Powering On**

For the first use, place earbuds into the case then remove from case. This will activate earbuds.

**To turn on**, place earbuds into the case then remove from case. **To turn off**, place the earbuds into the case.

If the LEDs do not turn on when the earbuds are removed from the case, charge the case then try again. In the event that the earbuds do not pair together, perform the Manual Reset function.

**Bluetooth Pairing**

The AL Nanobuds Pro 2.0 have automatic pairing technology. Once removed from the case, they will automatically turn on and pair to each other within a few seconds.

After the earbuds have paired to each other, to connect the earbuds to your smartphone, go to settings then select the Bluetooth page. Look under 'available devices' and connect to 'AL Nanobuds Pro 2.0'.

**Touch Button Functions**

**Left Earbud:** Pause/Play: Press Once; Decrease Volume: Press Twice; Answer Call: Press Once; Decline Call: Press & Hold 2 Sec; Hang Up Call: Press & Hold 2 Sec; On Call Mic, Mute On/Off: Press Once

**Right Earbud:** Pause/Play: Press Once; Increase Volume: Press Twice; Low Latency On/Off: Press & Hold 2 Sec; Next Selection: Press Triple; Answer Call: Press Once; Decline Call: Press & Hold 2 Sec; Hang Up Call: Press & Hold 2 Sec; On Call Mic, Mute On/Off: Press Once

\*Low Latency Mode reduces wireless Bluetooth only for better gameplay.  
\*Answering a second call will put first on hold. When on hold triple press L or R to switch call.

**Bluetooth Multipoint (two devices at once)**  
To connect a second device turn off Bluetooth on first connected device. Now connect your second device. Turn Bluetooth back on on first device. Nanobuds Pro 2.0 will reconnect to first device and both will be connected.

**Manual Reset**

**Soft Reset**  
To perform a Soft reset simply drop the earbuds back in the case and hold the touch button, the LED will go off. Let go after 2S and the earbud will be reset without losing any pairing information. In unlikely event that you need to fully reset the earbuds and clear their pairing information you can do a Hard reset as follows:

**Hard Reset**

1. Forget the earphones in your phone (important).
2. Take ONE earbud out of the case. If the LED is flashing purple wait for it to go red/blue/red/blue. Now Press and Hold the earbud touch button for 12S. The LED will change to Red for 5S and the earbud will reset.
3. Put it back in the case and do the same operation for the other one.
4. Finally take them both out together the earbuds will flash purple while they look for each other. Then when they pair together the Primary will go Red/Blue/Red/Blue (the Secondary LED will turn off).
5. The earphones are now ready to pair to your phone.
6. Reconnect the earbuds to your phone. You should see them in your phones pairing list as AL Nanobuds Pro 2.0.

**Notes**

\*To use Siri or Google Assistant, you must have a phone that is compatible with one of those two voice assistants (iOS or Android, respectively).

\*You must be within Bluetooth® range to use Siri or Google Assistant via your Wireless Earbuds.

Your Wireless Earbuds will not work with Siri or Google Assistant if the assistant is not first enabled within the settings on the phone. For more information, see your phone's user manual.

**FIRST**

FCC ID: ZALN9-TW95RH3

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FOLLOW US ON

#myalclassing