

Find more about Declaration of Conformity, please click the below link to download: [Http://files.iclever.com/BTH15-DOC-EN.pdf](http://files.iclever.com/BTH15-DOC-EN.pdf)

Um mehr über die Konformitätserklärung zu erfahren, klicken Sie bitte auf den folgenden Link: [Http://files.iclever.com/BTH15-DOC-DE.pdf](http://files.iclever.com/BTH15-DOC-DE.pdf)



Wireless Headphones

Model: BTH15



User Manual


Contents

English User Manual	01
Benutzerhandbuch	11
Guide Utilisateur	20
Manual de Usuario	29
Manuale Utente	38
中文说明书	47


Package Contents



1 x iClever BTH15
Wireless Headphones



1 x Storage Bag



1 x User Manual




1 x 3.5mm Audio Cable




1 x USB Type-C Cable

Product Diagram




On / Off





1. If the headphone is folded, just unfold it. Then it will be auto on, the colorful lights will be also on, and the headphone will enter the pairing mode.

2. When the headphone is folded as shown below, it will be auto off.



Note: If there is an abnormal situation, press and hold the MFB button for 3-5s to turn the headphone on and enter the pairing mode.

Bluetooth Pairing

1. In the power-on state, the colorful lights are on; Bluetooth enters the pairing state, and the red and blue lights flash alternately.

2. Turn on the Bluetooth of the mobile phone. Then find and select the "iClever-BTH15" Bluetooth pairing name in the device list for Bluetooth pairing connection.

Light Mode Switching

Short press the "Light Mode Switch Button" to turn on/off the light.

Volume Limit Gear Switching

1. Press and hold the "+" & "-" buttons at the same time to switch the volume limit to the safe volume of 85dB, and the voice broadcast will be "Safe Volume".
2. Press and hold the "+" & "-" buttons at the same time to switch the volume limit to the normal volume mode, and the voice broadcast will be "Normal Volume".

Operation of Buttons

Volume Up	Short press the "+" button.
Volume Down	Short press the "-" button.
Next Track	Press and hold the "+" button for 2 seconds.
Previous Track	Press and hold the "-" button for 2 seconds.
Play / Pause	Press the MFB button once.
Answer / End A Call	Press the MFB button once.
Reject A Call	Keep pressing the MFB button for seconds.
Activate Siri	Press the MFB button twice.

Clear The Pairing List	After the Bluetooth is turned on, in any state, press and hold the "multi-function button" and "-" button at the same time for 5 seconds to clear the pairing list in the headphone.
-------------------------------	--

Voice Prompt

Power On	Power on
Power Off	Power off
Pairing	Pairing
Successful Pairing	Connected
Disconnection	Disconnected
Low Power	Battery Low

How to Charge the Headphone

Connect the Type-C cable to the Type-C port on the headphone, and a 5V power outlet (power adapter is not included). The indicator light will glow red to indicate charging. When the headphone is fully charged, the indicator light will change from red to blue.

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the

equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.


This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Packungsinhalt



1 x iClever BTH15
Funkkopfhörer



1 x Aufbewahrungstasche



1 x Benutzerhandbuch




1 x 3,5mm-Audiokabel





1 x USB Kabel, Typ C

Produktbilder




Ein / Aus





1. Ist der Kopfhörer zusammengeklappt, klappen Sie ihn einfach auseinander. Dann schaltet er sich automatisch ein, die bunten Lichter leuchten und der Kopfhörer geht in den Kopplungsmodus.

2. Ist der Kopfhörer zusammengeklappt, wie unten gezeigt, schaltet er sich automatisch aus.



Hinweis: Liegt eine abnormale Situation vor, halten Sie die MFB-Taste 3-5 Sekunden lang gedrückt, um den Kopfhörer einzuschalten und den Kopplungsmodus aufzurufen.

Bluetooth-Kopplung

1. Ist der Kopfhörer eingeschaltet, leuchten die bunten Lichter; Bluetooth geht in den Kopplungszustand über, und die roten und blauen Lichter blinken abwechselnd.

2. Schalten Sie das Bluetooth des Mobiltelefons ein. Suchen Sie dann den Bluetooth-Kopplungsnamen "iClever-BTH15" in der Geräteliste und wählen Sie ihn für die Bluetooth-Kopplungsverbindung aus.

Umschalten des Lichtmodus

Drücken Sie kurz die "Lichtmodus-Umschalttaste", um das Licht ein-/auszuschalten.

Umschalten der Lautstärkebegrenzung

1. Halten Sie die Tasten "+" und "-" gleichzeitig gedrückt, um die Lautstärkebegrenzung auf die sichere Lautstärke von 85 dB umzuschalten. Die Sprachübertragung erfolgt in „sicherer Lautstärke“.
2. Halten Sie die Tasten "+" und "-" gleichzeitig gedrückt, um die Lautstärkebegrenzung auf die normale Lautstärke umzuschalten, und die Sprachübertragung erfolgt in "normaler Lautstärke".

Bedienung der Tasten

Lautstärke erhöhen	Kurz die Taste "+" drücken
Lautstärke senken	Kurz die Taste "-" drücken
Nächster Titel	Halten Sie die Taste "+" 2 Sekunden lang gedrückt
Vorheriger Titel	Halten Sie die Taste "-" 2 Sekunden lang gedrückt
Wiedergabe / Pause	Drücken Sie die MFB-Taste ein Mal
Anruf annehmen / beenden	Drücken Sie die MFB-Taste ein Mal
Anruf abweisen	Halten Sie die MFB-Taste für Sekunden gedrückt
Siri aktivieren	Drücken Sie die MFB-Taste zwei Mal

Kopplungsliste löschen	Halten Sie nach dem Einschalten von Bluetooth in jedem Zustand die "Multifunktionstaste" und die Taste "+" gleichzeitig 5 Sekunden lang gedrückt, um die Kopplungsliste im Kopfhörer zu löschen
-------------------------------	---

Sprachansage

Einschalten	Einschalten
Ausschalten	Ausschalten
Kopplung	Kopplung
Erfolgreiche Kopplung	Verbunden
Unterbrechung	Getrennt
Niedrige Leistung	Niedriger Batteriestand


So laden Sie den Kopfhörer auf

Verbinden Sie das Kabel Typ C mit dem Ladeanschluss Typ C des Kopfhörers und einer 5V-Steckdose (Netzteil ist nicht im Lieferumfang enthalten). Die Anzeigeleuchte leuchtet rot, um den Ladevorgang anzuzeigen. Ist der Kopfhörer vollständig aufgeladen, wechselt die Anzeigeleuchte von Rot zu Blau.

Contenu du colis



1 x Écouteurs sans fil
iClever BTH15



1 x Sac de rangement



1 x Manuel d'utilisation



1 x Câble audio 3,5 mm



1 x Câble USB Type-C