88mm

Table of Contents
1 Introduction
5 Technical Specifications 5 6 FAQ 6 7 Customer Service 6

1.Introduction

Thank you for choosing the Tribit XFree Move Bluetooth Stereo Headphones. The Tribit XFree Move is designed with both style and substance, with stunning music drivers and a sleek matte exterior to boot. This user manual will allow you to operate these Bluetooth Stereo Headphones at its best. Please familiarize ourself with the Bluetooth capabilities of your device before using

USER MANUAL

hese headphones. Safety Rules

- Please follow the rules depicted in this manual closely to ensure your safety. Before using this Bluetooth Stereo Headphones, we would strongly encourage you to read through this user manual.

 2. Be aware of any edges, uneven surfaces, metal parts or
- accessories and that may nose as a safety hazard, so, as
- accessories and possible injury or damage.

 Do not attempt to modify, repair or dismantle this Bluetooth Stereo Headphones. Doing so may result in accidental field electrical shocks, or damage to the headphones. Please be advised that the following are not covered under Tribit's warranty quarantee. Bluetooth Stereo Headphones.
- Do not use the Bluetooth Stereo Headphones in an
- vironment with hazardous elements.

2.Package Contents



X USB Charger Cable X Audio Cable 1X User Manual

Nevt

3. Headphone's Overview Required Action Click "-"button for volume down. Volume down Click "+"button for volume up. Volume up click"MFB" button to play and pause music Low battery warning (The red LED will flash) Plug the charger to the port of the device. Charging Click the "MFB" button while the ncoming call. uble click the "MEB" button to transf Transfer call voice the call voice between the mobile phone and device while ongoing call. 4.1.General Functions Redial last phone uble click the "MFB" button in the connected Required Action Press the "MFB" button for 3 seconds to turn on/off the device, indicated by a blue LED light and a beep. ress the MFB button for 1-2 seconds to eject call when the call is ringing pairing mode, press the "MFB" to enable multipoint and double press the "MFB" disable the Multipoint. Multi-point In off mode, Press the "MFB" button and hold for 8 seconds. (The Blue and Red LED indicators will flash alternately with two beeps. connection Enter pairing Press and hold the"+" and "-" button for 5 Factory reset nds when in pairing mode to clear the n pairing Mode use a mobile phone with Bluetooth function or other Bluetooth Pairing

USER MANUAL

Master Device and to perform pairing action (detail refer to the chapter about pairing).

Press the "-" and hold to go to the previous track

Press the "+" and hold to go to the next track.

2

4.2.Pairing to Mobile phone or other device

use your Bluetooth Headphones, you must first pair your He ired to a specific mobile phone; they will remain paired and autor tically recognize each other whenever they are within range.

USER MANUAL

Pairing to a phone and an entertainment system:

• Turn on your phone and ensure its Bluetooth function is activated

Turn on the Bluetooth Stereo Headphones, enabling it to pairing

USER MANUAL

- Search for your Bluetooth devices on your phone by
- following the phone's instructions. Refer to your phone's r manual for more information
- After a few seconds; the phone will list the device as a discovered device. Pair your phone to the Bluetooth
- Headphones according to your phone's requirements.

 Your phone will request for a passkey or PIN; enter 0000 as your PIN or passkey
- Your phone will confirm the nairing press Yes/Ok Your phone will confirm the pairing, press Yes/Ok.
 Finally, select to connect with device from your phone.
 You can play music; watch TV/movie and play games with your phone, and receive all the audio from the device on your Bluetooth Stereo Headphones. You can also control the device from the operational buttons on the Bluetooth Stereo Headphones. E.g. volume up and next music.
- Pairing to a computer and an entertainment system:

 If there is no Bluetooth function supported by your mputer.use a Bluetooth adapter to enable the Bluetooth
- function on your computer.

 Turn on the device go to the paring mode. Open the Bluetooth software (such as BlueSoleil) installed on your computer, and select "Search your Bluetooth devices" function Refer to user manual of the
- Bluetooth software for more information.

 After a few second the "device name" will list in Bluetooth software of your computer as a discover device. Select this icon and click right button of mouse to select "pairing" item, then select "connect with audio device" with same operation.

 Open your media player software to play music watch TV/ novie and play game, to enable audio to be played back on 4.3. Charging your device

The device is convenient to connect to AC charger or a USE charger with Micro USB port marked with. Insert one termina of your charger to AC main or USB port of PC and other terminal to Micro USB. While charging, the red LED light constantly.

When charging is completed, the blue LED turns on. ______

- Warning:
 You must select a qualified charger from a regular
- You must charge the Bluetooth Headset if it has been not used for more than 18 months.
- Make sure that your device is fully charged for at leas 6 hours before initial use.

10 m

20mW

Output 2011W Signal-To-Noise ≥90dB

20Hz-20KHz

5.Specification			i.e. phone.
	Parameter	Value	3. How can I know if the Bluetooth Stereo Headphones has been fully charged?
	Bluetooth	Bluetooth V4.1	Ans: When the indicator LED turns from red to blue when it is charging, it has been fully charged.

取扱説明書

USER MANUAL

ns: When the indicator LED turns from red to blue when it is charging, it has been fully charged.

The headphones cannot be connected to the second phone. sp. Please set the Headphones to pairing mode and press the "MF8" to enable multipoint mode Connect the Headphones to phone A, Restart the Headphone to pairing mode connect the Headphones to point the Headphones to pairing the second process the second pairing the second process the second proc Bluetooth Profile A2DP1.2 AVRCP1.4 HSP1.2 HFP1.6 CVC6.0 Noise and Echo reduction ing mode and connect the Headphones to phone B, and then use phone A paired device list to reconnect to the

Charging Time

charging.

Dimension (L×W×H)

18-month limited warranty For FAQS and more information, please Email to: support@tribitaudio.com

≤3%

about 2 hours

1. Why is there no power even when the Stereo Headphones

2.There is no sound during playback.

Ans: Check the connection between your device with phone or computer. If the connection is not established, please

device is paired and connected to your intended device

reconnect again. Make sure the Stereo Headphone

is powered on?

Ans: Ensure the battery is being charged up to 6 hours for first time using. The LED is lighted when it starts

180×70×162mm

USER MANUAL

about 14 hours (Varies by volume level and audio)

Changes or modifications not expressly approved by the party sible for compliance could void the user's authority to perate the equipment.

his equipment has been tested and found to comply with the limits or a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the

USER MANUAL

取扱説明書

nstructions, may cause harmful interference to radio ommunications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the

following measures: - Recrient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from nat to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1)this device may not cause harmful interference and (2) this device must accept any nterference received, including interference that may cause undesired operation.

58mm



目次 1 製品紹介 2 パッケージ内容 3 各部の名前 4 使い方 5 製品仕様 6 よくあるご質問 7 アフターサービス

1.製品紹介 このたびはTribit Xfree moveワイヤレスヘッドフォンをお買い上げいただきまし て誠にありがとうございます!本製品をより効果的にご利用いただくために、。 使用前にこの取扱説明書をよくお読みの上でお使いください。お読みになったあ

必ずその説明書に記載されている使い方に従い、お使いください。

-) 鋭利な縁側、平らでない表面、金属パーツ、付属品、及びその包装で怪我す ることを十分で注音ください。 3) 本製品に対する改造、修理、分解などをしないでください。火災、感電、及 び故障の原因となります。個人の改造による故障はアフターサービス保障範囲内
- になりませんので、予めご了承ください。 腐食性や発揮性のある液体で本製品を洗浄しないでください。
- 初回使用前に、ヘッドフォンを最低6時間充電してください。

2.パッケージ内容



1*USB充電ケーブル 1*音声ケーブル

取扱説明書 取扱説明書 3 各部の名前 4.使い方 操作 電源OFFの状態からMFBボタンを3秒ぐらい長押し 電源ON (LEDインジケーターが青色で点滅し -プJの音が聞こえます。)

電源OFFの状態からMFBポタンを8秒ぐらい長押し する。(LEDインジケーターが赤青で点滅し、2回 「ビープ」の音が聞こえます。) ベアリングモード! 入る Bluetooth機能付きのスマホやデバイスをヘッド フォンとヘアリングする。(詳しくは「スマホ/ハ ソコンとペアリングする」にご参考ください。) ペアリンゲ - 」を長押すと、前の曲になります。 曲戻し 」を長押すと、次の曲になります。 2

「+」を短くおリックすると、ボリュームアップに -」を短くおリックすると、ボリュームダウンに ります。 ボリュームダウン 再生の状態からMFBボタンを3秒ぐらい長押しす る。(LEDインジケーターが消灯し、「ビーブ」の 電源OFF o。(LED1 ノンソ きが服とまます。) MFBボタンを短くおリックすると、再生/一時停 再生/一時停止 バッテリー残量不足 EDインジケーターが赤色で点滅します。 充電 雷話を受ける 着信中にMFBボタンを一回押すと、電話に出ます。 電話を切る 通話中にMFBボタンを一回押すと、電話を切りま 電話/ヘッドフォ! の切り替え 通話中にMFBボタンをダブルクリックして、電話で話す/ヘッドフォンで話すの切り替えになります。 直前の着信に電話を 掛ける 接続された状態で、或いは音楽の再生中でMFBボタンをダブルクリックして直前の着信に電話を掛けま MFBボタンを1~2秒長押しして着信を拒絶します。 着信を拒絶する ペアリングでモードMFBボタンを一回を押すと多数 の端末に接続機能がONになり、ダブルクリックする とOFFになります。 多数の端末に接続機能 ペアリングされた状態で「+」と「-」を同時に5秒 長押しして初期化になります。

スマホとペアリングする ■電源OFFの状態からMFBボタンを3秒ぐらい長押しし、ヘッドフォンがペアリ ングモードになります。 ■スマホのBluetooth接続画面でヘッドフォンを検索してください。詳しい操作 方法はお使いのスマホ取扱説明書にご参考ください。 数秒後、検索されたリストにヘッドフォン「Tribit Bluetoothヘッドフォン」 が表示されます。クリックしてペアリングする。 パスキーやPINが必要であれば「0000」を入力してください。 「はい」をクリックして、ペアリングが完了になります。 ◆ヘッドフォンを付けて、スマホで音楽、テレビ、ゲームが楽しめます。ヘッ ドフォンのボタンででボリュームアップや曲送りの操作ができます。 ソコンとペアリングする パソコンにBluetooth機能がなければ、Bluetoothアダプタが必要になります。 接続される前にBluetooth機能が確かに使えることをお確かめください。 ■電源OFFの状態からMFBボタンを8秒ぐらい長押しする。ヘッドフォンがペア ングモードになります。 Bluetoothソフトウェア取扱説明書にご参考ください。 の名前が出ます。クリックしてペアリングが完了になります。 ・ヘッドフォンを付けて、パソコンで音楽、テレビ、ゲームが楽しめます。 ヘッドフォンを充電する す。付届されたUSB充雷ケーブルを使い、ヘッドフォンをACアダプタやパソコ 充電完了すればインジケーターが青色に占灯します。

取扱説明書

取扱説明書

パソコンにあるBluetoothソフトウェア(例えばBluesoleilなど)を開き、「デ バイスを検索する」機能をクリックしてください。詳しい操作方法はお使いの • 数秒後、検索されたリストにヘッドフォン「Tribit Bluetoothヘッドフォン」

ッドフォンをACアダプタやUSBチャージャーと接続すれば簡単に充電できま ンのUSBボートに接続してください。充電中、LEDインジケーターが赤色に点灯

正規ルートで販売された良質チャージャーをお使いください。 ヘッドフォンが18ヶ月間以上使用されていない場合は、使用する前に充電を 1.てください.

初回使用前に、ヘッドフォンを最低6時間充電してください。 5.製品仕様

項目

RF Range

Buletoothバージョン Buletooth V4.1 Buletooth仕様 A2DP1.2AVRCP1.4HSP1.2HFP1.6 受信距離 10メートル 20mW >90dB 約14時間(音量と再生する内容によって多少 異なります) 連続再生時間 充電時間 約2時間 6.よくあるご質問 電源が入らない

ヘッドフォンが充電されていることを確認してください。初回使用前に、ヘッドフォンを最低6時間充電してください。充電開始されると、LEDインジケ

ーターが赤色に点灯します。 音声が聞こえない ヘッドフォンとスマホやパソコンが確かいにペアリングされていることをお 確かめください。ペアリングされていない場合は、再度ペアリングを行って ください。

ヘッドフォンが充電完了であることどうやって分かるの

取扱説明書

充電中、IFDインジケーターが赤色から青色になれば、充電完了になります。

ヘッドフォンが二台目のスマホに接続できない ヘッドフォンをベアリングモードにして、MFBボタンを短く押して、多数の端 末に接続機能をONにざる、まずー台目のスマホと接続して、ヘッドフォンを 再起動してからもう一度ペアリングモードに入り、二台目のスマホとペアリ ングしてください。そして既にペアリングされた一台目の接続リストから ヘッドフォンを選択し、再度接続してください。

7.アフターサービス

18ヶ月間品質保証 製品に対してご不明なところがあれば、弊社にご連絡してください。