User Manual

Production Description:

The Wireless earphone is a high quality stereo Wireless earphone which possesses wireless music and calling function.

Appearance vogue, beautifully designed, easy to carry, suitable for household, outdoor travel and other places, enjoy music anytime and anywhere. Get rid of cable tie, combined with perfect sound let movement more freedom, happiness.

Function Features:

【Wireless Play】 Support pairing Wireless devices to play music such as mobile phone, tablet, TV.

【Hands-free calls 】 Support for hands-free calls function, built-in high sensitive microphones, making phone calls have carefree to enjoy.

【Voice Prompt Coming Calls】 It will prompt the phone number when you have a coming call, it is more convenient.

【IOS Battery Display】 IOS mobile phone real-time display the earphone battery, let you know the earphone battery.

【Smart Power-off】If not connected Wireless mode, it will turn off automatically after 8 minutes, don't worry about waste of electricity for standby.

【Rechargeable Lithium Electricity】 The built-in rechargeable lithium battery, environmental protection, economical and practical.

Intelligent Charging The voice prompt please charge when the battery is low, when full charge it will automatically cut off power to avoid battery charging too much to damage to the battery.

① MULTIFUNCTION KEY ② + ③ - ④ Micro USB Charging Ports ⑤ Status indicator lamp ⑥ Built-in Mic

Function Definition of Product Buttons and Slot:

- 1 MULTIFUNCTION KEY: Long press to turn on (voice prompt to power on) and the indicator lamp lights up, long press to turn off (voice prompt to power off) and the indicator lamp extinguished. When connect to the Wireless, short press to pause play, short press again to start playing. When have a call, short press for answering the telephone, after the call short press for hang up, long press can refuse to answer the phone, continue press two times will redial the last time phone number you dialed.
- 2 +: Long press for turn up the volume, short press for move next song.
- ③ -: Long press for turn down the volume, short press for move previous song.
- ④ 【Micro USB Charging Port】: You can use the special charging cable from the standard package or the universal USB port charging cable of the mobile phone for charging.

Wireless Pairing Operation Method:

Long press the call key 3 seconds to boot, the blue and red light flashing, it is the state of the Wireless pairing. At this time search the corresponding Wireless device name on the phone, click the device name on the mobile phone for the Wireless pairing, hear "Connect successfully" means the pairing is successful.

Charging Method of Use:

Insert the end of the charging cable to native Micro USB socket, the other end of the USB plug into the standard 5 v charger interface, the indicator light turns red when charging, the red light will extinguish when full of.

Low Battery:

When there was a low voltage power, the machine will prompt "Low battery", and then will automatically shut down, please recharge in time at this time. If it is not to be used for a long time, charging one time every month at least, it can protect the battery and extend battery life.

Auto Power off Function:

If not connected Wireless and without any operation, this machine will automatically turn off after eight minutes.

FCC STATEMENT:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

This device may not cause harmful interference, and

This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.