


GEEBOX M2

BLUETOOTH SPEAKER

QUICK START MANU

快速使用指南



Note : GEEBOX M2 automatically starts Bluetooth pairing after power on, open BT function of your mobile phone, click 'GEEBOX M2' will success pairing. If they already paired successfully before, BT will connected automatically just after GEEBOX power on.

注意事项 : GEEBOX M2在开机伊始便会自动启动蓝牙配对寻找模式，届时请打开手机蓝牙，查找GEEBOX M2便可配对成功。如已经配对成功，下次便可自动连接无需重新配对。

LED Status Definition/指示灯状态

| | White 白色常亮 | Blue Blink 蓝色闪烁 | Blue 蓝色常亮 | Red Blink 红色闪烁 |
|---|------------------|----------------------------------|------------------------|-----------------------|
| ⚡ | AUX in AUX 插入 | Power on & BT paring 开机-蓝牙配对中 | BT connected 蓝牙连接成功 | N/A |
| • | Charging 充电中 | N/A | Battery Full 充电电量满 | Power < 20% 电量<20% |

Warning/警告

- ⌘ GEEBOX M2 is splashproof, please do not dripping or splashing during charging.
- ⌘ GEEBOX M2具有防溅水功能，但请不要将其浸入水中或者在充电的时候溅水。
- ⌘ Please do not touch passive radiators.
- ⌘ 请不要触碰两侧被动振膜。



GEEBOX微信公众号/GEEBOX WeChat account
GEEBOX官网/ GEEBOX website www.geebox.cn

WARNIN: Chang or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

No naked flame sources, such as lighted candles, should be placed on the apparatus

This device complies with FCC's radiation exposure limits set forth for an uncontrolled environment

- Attention should be drawn to the environmental aspects of battery disposal
- The use of apparatus in tropical climates
- **CAUTION**
Danger of explosion if battery is incorrectly replaced.
Replace only with the same or equivalent type.
- A warning that batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine, fire or the like.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

⎓: 直流输入，M2为5V/2A DC voltage , Input rating 5V/2A,

圆内数字代表产品的正常环保使用年限。

⑩: The circle number represents the normal environmental protection service life of the product.

☒: 该产品不能与其他生活垃圾一起处理或者丢弃，您需负责所有电子或者电气废弃物的处置，并将其放置到指定的手机店里面对有害废弃进行回收，确保人类健康和环境安全圆内数字代表产品的正常环保使用年限。

This product must not be disposed of or dumped with your other household waste. You are liable to dispose of all your electronic or electrical waste equipment by relocating over to the specified collection point for recycling of such hazardous waste, through this to ensure safety of human health and environment.

Key Definition/按键定义

⚡: Make Bluetooth pairing/connected or disconnected.
使蓝牙开始配对/连接或者断开。

+/-: Vol + after short press or Play next after long press.
短按增加音量，长按播放下一首。

—: Vol - after short press or Play previous after long press.
短按减少音量，长按播放上一首。

⏸: Pause/Play during music playing or Answer incoming call by M2 after short press.
在播放音乐时，短按使音乐暂停/播放。有来电时短按使用M2音箱接听电话。
Reject incoming call or Switch calling Mic/Speaker to phone after long press.
在来电时长按挂点电话。或者在通话过程中长按由M2接听变为手机接听。

Warranty/保修联

Client Information/用户信息

Name/姓名 : _____ Phone Number/电话 : _____

E-Mail/邮箱 : _____ Post Code/邮编 : _____

Address/地址 : _____

Product Information/产品信息

S/N : _____

Retailer Information/销售商信息

Address/地址 : _____ Phone Number/电话 : _____

Purchase Date/购买日期 : _____

Invoice Information/发票信息 : _____

Only for China:

GEEBOX遵守国家三包规定：7天可退换，15天可换，一年内保修。

如由非正常操作、维护、保管，非授权维修或不可抗力引起的音箱损坏不属三包范围。