

Product Name: miniS

Model: KD100

Operating Steps of StereoSpeakers:

- 1st. step: Turn on two speakers simultaneously, and after power on, speakers red light and blue light flicker alternately.
- 2nd.step: Double click one of the speakers button, red light and blue light will flicker alternately very fast, which means they are starting pair Bluetooth, after pair successfully, there will be a notification tone.
- 3rd step: Turn on device Bluetooth, searching speakers and to pair, Bluetooth speaker is discovered as MiniS, after connecting successfully, there will be a notification tone.
- 4th step: Playing music or video with voice, enjoy them.

Remarks: While using the two speakers for the second time, they will reconnect automatically to each other.

Button Function:

- Press the button of any one of the speakers over 3 seconds, then two speakers will power off simultaneously. And if want to turn on two speakers, need to separately press button on two speakers over 3 seconds, after power on, they will reconnects automatically to each other.
- While playing music via Bluetooth: press button for a short time is playing music, and press shortly again is pausing music.
- While there is an incoming call: press the button for a short time is to answer the phone, press it for the long time is to answer the phone privately, press it for a short time again is to hang up the phone.
- While there is an incoming call: Directly press for a long time is to hang up the phone.

Attentions:

- Avoid hearing impairment, please adjust the volume according to the distance between speakers and ears, and avoid damaging hearing.
- Avoid contact water and other liquid.
- Please charging speakers with attached original charger station, which is safer for products. And if charging with other charger, manufacture will not take the responsibility for any results caused by charging products with non-original charger which attached with products.
- Please don't disassemble speakers, because you can't assemble it back. And manufacture will not take responsibility for any damage which caused by disassembling speaker.
- Keep speaker away from fire or other high temperature environment, which might result into damage to battery.

In the box:

- MiniS wireless stereo portable blue tooth speakers

2. USB connected charging station
3. Magnet metal discs
4. User Manual

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.