# Sports Business Bluetooth 2 IN 1 Wireless Headset Y100

user's Guide

Shenzhen Zhanjie Wenda Electronic Co.,Ltd.

Package Contents

Ears hanging earphone X 1
Mono Business Bluetooth Earphone X 1
Charging cable X 1

earbuds
speaker

connector
charging port
multifunction button
volume +/-   LED indicater light

earbuds
speaker
microphone

as the direction of arrow
lean 5

Charging

1. Insert the USB charging cable into the earphone charging hole
2. The red light is on when charging , charging is complete and the blue light is on

Instructions

1. Power on / off:
Power on : when the earphone is in the power off case, long press multi-function keys for about 3 seconds, blue lights flash three times and a voice prompt.
Power off : when the earphone is in the power on case, long press multi-function keys for about 3 seconds, red light flash three times and have voice prompts .

2. Initial pairing:
A. Long-press power button for 5 seconds , red and blue light is flashing alternataly , which shows the earphone start to pair device during 60 seconds .
B. Turn on the bluetooth of the mobile phone , then search for the " Y100 " , choose it and pair automatically (If need password , please input " 0000 ")

3. Answer / hang up the phone
When there is a call, press the multi-function key to answer. After completing the call, press again the multi-function key to end the call.

4. Reject calls
Press the multi-function key for about 2 seconds to refuse

5.Play/stop music
Playing music state ,
short press answer button

6.Redial
click the button twice

7. Previous track/ next track
Previous song : long press volume +
Next song : long press volume -

8.Volume up / Volume down
Volume up : click "volume +" shortly
Volume down : click "volume -" shortly

·pairing with two mobile phone at the same time

1.Pairing the mobile A according to the previous pairing step
2.Turn off the earphone and turn off the Bluetooth of mobile A that has been paired.
3.Long- Press the earphone multifunction key to enter the pairing state and pair withthe mobile B.
4.Turn on the Bluetooth function of Phone A and click on "Y100" again
5.After bluetooth earphone connect with two mobile phone It means multi-point connection function is completed .

Product specifications

Bluetooth version: V4.1, Class 2
Support Agreement: HFP, HSP, A2DP, AVRCP
Multi-point connection: Yes (connect two phones a t the same time)
Talk time: about 4 hours (the longest)
Music Play: about 3 hours (the longest)
Charging time: about 2 hours
Transmission distance: 10M (open space)

Power on	long press multi-function keys for about 3 seconds blue lights flash three times and a voice prompt.
Power off	long press multi-function keys for about 3 seconds, red light flash three times and have voice prompts
pairing	Long-press power button for 5 seconds ,red and blue light is flashing alternataly , and voice prompt .
Answer calls	press the multi-function key
Hang up calls	press again the multi-function key to end the call

Power on	blue ligh flash 3 times
Power off	red ligh flash 3 times
Standby(connect with mobile phone)	A blue ligh flash per 5 seconds
Incoming call	A blue ligh flash per 5 seconds
On the phone	A blue ligh flash per 5 seconds
Charging	red light keeps on
Full charged	Blue light keeps on

LED lights indicate instructions

Refuse calls	Press the multi-function key for about 2 seconds
Play / pause	short press answer button
Previous track	long press volume +
Next track	long press volume -
Volume down	click "volume -" shortly

safety warning

1. To ensure safety, please read this manual before using the Bluetooth earphone .

2.Do not closing sharp metals, hard objects, and other electronic products in order to avoid damage or interference to the product .This product built-in lithium battery, if the product is damaged, for your safe, do not continue to use.
3.Product failure, please send to the place of purchase, agents or the company for testing and maintenance. Please do not dismantle, repair or repair the product by Unauthorized third parties, to avoid the human factors, resulting in abnormal operation of the product or dangerous.In the event of any of the above, the Company will not be warranted.
4.Do not place the product in high temperature or too low environment (0 ℃ below or 40 ℃ above)for long time , extreme temperature easily lead to the product can not operate,deformation, reduce the product charge and shorten the product life.
5.Do not use it in rain, thunder or typhoon ..... and other weather conditions.Use it in these environments can lead to damageto the product and increase the risk of electric shock.
6.Please place the product in the places where children, pets can not touch, swallowing small accessories may lead to suffocation and other serious consequences.
7.Please avoid placing the product in a wet place or in water and avoid ignition or flammable chemicals to avoid danger.
8.using the standard USB specification and charge the product with a certified charger.
9.If you do not use this product for a long time, please charge the product every month to maintain proper power and voltage to avoid damage to the battery. Continuous charging time should not exceed 5 hours, to avoid damage the battery.

10.to avoid hearing damage , please do not listen to music
11.with earphohne for a long time with a large volume . Please do not use headphones while driving a vehicle to avoid danger .

Warranty and after-sales service

1.This product is manufactured after the strict quality inspection, the company provides warranty period for the product from the date of purchase
(one year, the battery six months).During the warranty period and Under normal operating conditions, and a natural damage due to defects in the material or manufacturingprocessthe , our company will be responsible for the repair or replacement of the same type of product (natural disasters, other force majeure conditions or man-made damage is not covered by the warranty).If the warranty period or the man-made damage is caused, the Company will take the inspection and maintenance expenses depending on the damage.
2.Where the product for repair or return the goods for some reason, the customer must produce the original Proof of purchase (receipt, invoice or stamped with a shop card guarantee card), without certificate, will not be guaranteed.
3.This warranty is guaranteed only for the original purchaser.
4.The Company will not be warranted for the user's own dismantling,or repair by unauthorized third parties.

Need more help?

Customer Service Tel: + 86-755-89505536

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.