

CPP-4502

New square light up speaker

Dear customer:

Thank you for purchasing cpp-4502 New square light up wireless speaker.

Please read this user guide carefully before operation and

Save these instructions for future reference.

Packing included

1.Portable speaker-----1pc

2.Usb line -----1pc

3.User manual-----1pc


Features:

Active suspension lighting effect

Captivating sound Glowing design

Designed for modern life

Features:



Specifications:

Output power 3W

Discharge Current :5V/1A

Battery :300MAH 3.7V

Charging Current:200MA


Product size:75*75*40mm

Music play time :1- 2hours

Talk time:up to 4 hours

Standby time :up to 20 hours

Speaker output frequency range :20Hz-20KHz



Function Keys:

- 1.ON/OFF/Pause/play
- 2.press”M” to change light up style.
- 3.short press pick up phone call/long press reject phone call
- 4.previous song/long press decrease volume
- 5.next song/long press increase volume

1.ON/OFF

Slide ON/OFF switch to the right to power on.

2.Bluetooth connection

Follow the operating instructions of your Bluetooth device For paring with the speaker. Typically this is done by going to The “Bluetooth””set up”or “connect”menu and selecting the Option to search for Bluetooth devices.

When turned on the light will blink ,use cell phone

Or computer or other device search device name “**CPP-4502**”click To connect.

2. when you play music

- 1.short press “play/pause key to pause music or Pause music to answer a call.A second short press second Will resume playing music again
- 2.Short press “Vol-/previous song”,the speaker will play the previous song;
- 3.Short press “Vol+/next song”,the speaker will play the next song;
- 4.Long press “Vol-/previous song”,reduces speaker volume
- 5.Long press “Vol+/next song”,increase speaker volume and You will hear a prompt when maximum volume is reached.

4. Hands free phone call operation

- 1.Short press the “phone”key to answer;
Long press the “phone”key to reject the call.
- 2.when on an active call.short press “phone” to hang up.
- 3.When the speaker is in standby/music model,long press the “play/pause key
To re-dial the last call.
- 4.sounds from speaker in Bluetooth mode,press“play/pause” for one second ,the call will switch to mobile phone;
- 5.sounds from mobile phone in Bluetooth mode,press”play/pause”for on second,
The call will switch to speaker.

5.Charging

Connect the Micro charging cable to speaker’s Micro USB port ,insert the other end to the USB port if a 5V changer red light if illuminated when changing,and will switch off when full charge is reached.

Warm Tips

- 1.In order to avoid damage to your hearing and prolong the speaker’s use-life ,please don’t listen to music for long time in high volume environment.
- 2.When a fault occurs ,please immediately turn off the power switch ,unplug the USB plug, Prevent speaker and other components damaged.
- 3.over use of battery will affect the Bluetooth distance and use-life ,please charge in time.

FCC STATEMENT

1.This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1)This device may not cause harmful interference, and
- (2)This device must accept any interference received, including interference that may cause undesired operation.

2.Changes or modifications not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment.

FCC Radiation Exposure Statement:

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without RF striction.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.