




Manuel of remote control



Installing the Batteries:

The controller requires 2AAA-sized batteries (Not included) to operate, Remove the compartment door on the under side of the speaker and insert the two batteries according to the polarities displayed in the compartment.

Pairing the controller

1. Long press the  Button, The LED indicator will quickly flash Blue.
2. Set your mobile device to search for Bluetooth devices. When your mobile device finds the controller, select VR BOX from the list of found devices.
3. After a successful pairing, the LED indicator will turn off.

Setting up the controller:

Move the switch on the side of the controller to the IOS or Android setting, corresponding to your paired mobile device's operating system.

Once paired, you will be required to assign the controller's buttons to your device's virtual keyboard.

Press the @ button + A to assign, The LED indicator will flash to confirm.

Repeat for buttons B, C, and D

Once configured, the controller will be in relative model and your mobile device will now register the controller as a physical keyboard.

To further configure the controller, please consult the keyboard menu in your phone's operating system as you may be able to make changes there.

The Bluetooth controller can be used in a number of different modes, To change modes, press @ and one of A, B, C or D buttons at the same time.

NOTE: The following modes are default for the controller, but maybe different based on the app being used, certain apps may also allow ou to reassign the buttons on the controller or may not have functions corresponding to the button assignments below.

Must Mode:

Press @ +A button for music mode.

Press A to play/pause music playback.

Press B to exit /esc music app.

(Both IOS and Android) Tap the rocker to the left/right to skip to previous /next tracks.

(IOS only) Tap the rocker up/down to skip to previous/next tracks.

Press C/ D to adjust volume.

Press the shoulder 1 button to mute volume.

Press the shoulder 2 button to play/pause playback.

(IOS ONLY) with the camera app open, press the C or D button to take a phone.

Game Mode:

Press @ +B button for game mode.

Use the rocker for controlling movement .

The buttons can typically be re-assigned within the app.

VR Mode:

Press @+C button for VR Mode.

Use the rocker for controlling movement in games /VR environments.

Mouse Mode (Android only)

Press @ +D to switch to mouse mode.

Use the rocker to control the mouse on your phone's screen.

Mouse Mode (cont'd)

Press A for confirm selection and B for exit or cancel.

Press C/ D to adjust volume.

Shoulder 1 for cancel and Shoulder 2 for confirm.

Installing Your Phone to the Headset

NOTE: If you phone is equipped with a protective case or sleeve, you may need to remove it to properly install to the headset.

1. Release the visor door on the headset by pressing the OPEN button on top.
2. Insert your phone into the cradle so that the metal clip braces against the back of your phone and the screen is facing toward the two lens on the side.
3. (Optional) if you would like to use the earphones, insert the 3.5mm auxiliary connector into your phone's headphone jack, volume is controlled with the volume wheel on the underside of the headset.
4. Close the visor door so that it snaps shut.

READ CAREFULLY AND KEEP THIS MANUAL

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, Pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation, This equipment generates, Use and can radiate radio frequency energy and ,if not installed and used in accordance with the instructions,may cause harmful interference to radio communications, However , There is no guarantee that interference that interference will not occur in a particular installation .if this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on ,the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment..

This device complies with part 15 of the FCC Rules, Operation is subject to the following two conditions:

1. This device may not cause harmful interference ,and
2. This device must accept any interference received, including interference that may cause undesired operation.

The device had been evaluated to meet general RF exposure requirement, the device can be used in portable exposure condition without restriction.

Rain/Moisture Warning

Don't expose the unit to extreme temperatures (heat or cold), open Flames, humid conditions, or wet conditions.

Don't submerge in water.

Don't open this product or attempt to repair the unit yourself should it not be working.