

Open the package to read the usage guide.

TRANSMITTER USE GUIDE

WARNING

Read this guide carefully before using the product. If in doubt, consult a qualified technician.

SPECIFICATIONS


Frequency: 433.92 MHz

Modulation: OOK

RECORDING OF TRANSMITTERS


To record the transmitter, please consult the controller board manual.

BUTTONS



BATTERY REPLACEMENT

After the replacement, discard the battery in an appropriate place.



WARNING:

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION.

NOTE: THE **GRANTEE** IS NOT RESPONSIBLE FOR ANY CHANGES OR MODIFICATIONS NOT EXPRESSLY APPROVED BY THE PARTY RESPONSIBLE FOR COMPLIANCE. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.