E -2345-	<section-header><section-header></section-header></section-header>	 Product Diagram Image: Image: Ima	 Adjust FM Frequency Press the MFB for about 2 seconds, the display flashes means it entered FM frequency adjust mode. Rotate the MFB to increase or reduce frequency. Transmit the music/navigation of your Bluetooth-enabled smart device to car stereo via FM signal. Unique display screen, display car voltage when plugged in. Answer phone calls during driving. Type-C 36W & QC 3.0 for charging dual device faster. Bluetooth Frequency: 2.402 ~ 2.480GHz Effective Bluetooth Range: 5 meters FM Frequency: 88.1-107.9Mhz QC 3.0 Output: 5V/3A 9V/2A 12V/1.5A PD 36W Output: 5V/3A 9V/3A 12V/3.0A PPS 3.3-11V 3A 	<section-header><section-header><section-header><section-header></section-header></section-header></section-header></section-header>	 The signal of any FM transmitter sometimes can be interfered with by the surrounding radio or a similar frequency signal thus causing noise, this is normal. If the noise is too loud, please try another blank FM station. Make/Answer a Call The transmitter can make or answer a call after successfully connecting to your phone via Bluetooth. Reject a call: Long press the MFB for about 2 seconds. Answer a call: Press the MFB once. Hang up a call: Press the MFB once. Hang up a call: Press the MFB once. Next song: Press the MFB once. Switch Between Bluetooth Mode/USB Mode Long press the side light control button to switch BT mode/USB mode to play music. Music Source The product plays music from the last connected device and will memorize it next time. Site of the side light control button to suitch BT mode/USB mode to play music. Music Source The product plays music from the last connected device and will memorize it next time. Site Site and will memorize it next time. Music Source and Site an	Troubl 1. About a. Turn dc level and transmitte b. Signal another a Then adju frequency 2. Canno a. Select b. Turn up transmitte c. The vol Ask the oi d. Broken 3. No chaa a. Check the cigare not rustec b. Unplug c. Check i 4. Can't p Please m 5. The au a. Make s turned on b. Isthet t same as t
	EN	- 2 -	- 3 -	- 4 -	- 5 -	

 Croubleshooting About noise Turn down the volume of the car speaker to its 1/3 evel and prioritize turning up the volume of the FM ransmitter or smart devices. Signal interference: Change your car radio into nother any unused and empty one (88.1-107.9MHz). Then adjust the FM transmitter to the same requency. Cannot hear the person you called Select T92 to answer the call via car speaker. Turn up the volume of your phone or FM ransmitter. The volume on the other end of the calls is too low. Ask the other side of the phone to speak up. Broken Mic. Contact the seller. Sho charging Check whether the product is in good contact with he cigarette port and whether the cigarette holder is tor trusted. Unplug and retry again. Check if the cigarette holder is powered normally. 	 Correct Disposal Of This Product Waste Electrical & Electronic Equipment) This making shown in the product or its literature, indicates that it should not be disposed of with other bousehold wastes at the end of its working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of waste and recycle it responsibly to promote the sustainable reuse of material resources. Household users should contact either the retailer where they purchased this product or their local government office for details of where and how they can take this item for environmentally safe recycling. Buiness users should contact their suppliers and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal. 	NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: - Reorient or relocate the receiving antenna. - Increase the separation between the equipment and receiver. -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -Consult the dealer or an experienced radio/TV technician for help. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
Please make sure the volume is not set to 0. 5. The audio of the car can't receive sound.		This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this
 Make sure that the product FM launch has been urned on. Is the transmission frequency of the product the same as the reception frequency of the car's? 		device must accept any interference received, including interference that may cause undesired operation.
- 6 -	- 7 -	