


COMPONENTS:

- 1.Digital Display.
- 2.Radio Station + / switch (12/24 hours) / prev song(BT connect mp3 player)
- 3.Switch FM/AM/BT
- 4.Radio Station - /switch (12/24 hours) / next song(BT connect mp3 player)
- 5.Time setting / Store / Playing pause
- 6.On/Off Power / Volume Adjusting
- 7.AUX
- 8.Microphone for talking



INSTRUCTION FOR USE Power by 3 pieces of AAA batteries.

RADIO OPERATION:

- 1.Press the On/Off Power Knob (no.6).
- 2.Turn the Knob (no.6) to adjust the volume to be suitable, adjust from 0 to 15.
- 3.Press (no.3) to switch to AM or FM stations or Blue tooth function.
- 4.Scan Station:
 - A-Manually Turn: Press (no.2) or (no.4) to adjust the station.
 - B-Scan Station:Press and hold (no.2) or (no.4) for 2 seconds to scan stations.
- 5.Store Channel: it can store 40 channels from P01 to P40 for either AM and FM station.

Scan station to get a channel, press and hold (no.5) till it show the number in the [] at the right of LCD, then press (no.2) or (no.4) to choose the number to store, then press (no.5) to set it.

Press the (no.5) and press again to find your desired channel stored.

BLUE TOOTH OPERATION:

- 1.Press the On/Off Power Knob (no.6).
- 2.Press (no.3) to switch to blue tooth mode.
- 3.Blue Tooth pairing: operate the Blue Tooth, then use the mobile to find the blue tooth equipment named: JP-8830BT, to press to connect, it will show ON on the LCD to complete it.

After this operation, the blue tooth will connect the same mobile next time using.
- 4.Play the music: after connecting, press (no.5) to play and pause the music, turn the (no.6) to adjust the volume from 0 to 15. Press (no.2) to play the previous music, and press (no.4) to play next music.
- 5.Talking: When a call come in, press (no.5) to answer the calling, press and hold (no.5) to reject it. Or when calling finished, press any button to hang up. A call come in when listen the radio or AUX music, it will automatically switch to Blue Tooth talking, press (no.5) to answer the calling, press and hold (no.5) to hang up after calling finished, then return to radio or AUX music.

AUX-IN:

Use 3.5mm input jack, when put in the AUX equipment, it show Aud on the LCD, when AUX operate, press (no.3), it will add AUX to the AM/FM/BT switch.

SETTING TIME:

- 1.Press and hold (no.5) when it closed to set the time, and the LCD show 12H with flicker.
- 2.Press (no.2) or (no.4) to switch 12 hours or 24 hours.
- 3.Press (no.5), the hour number flicker, then press the (no.2) or (no.4) to adjust the hour.

Press (no.5) again, the minute number flicker, press the (no.2) or (no.4) to adjust the minute.

Finally press the (no.5) to complete.

Warning Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.