


Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
-- reorient or relocate the receiving antenna.  
-- increase the separation between the equipment and receiver.  
-- connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
-- consult the dealer or an experienced radio/tv technician for help.

**WARNING:** The batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine, fire or the like.  
**CAUTION:** Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.  
**Correct Disposal of this product.** This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.  
No naked flame sources, such as lighted candles, should be placed on the apparatus.  
Attention should be drawn to environmental aspects of battery disposal.  
The product is designed to use in moderate climates operating temperature

## INDEX

English	-----
中文简体	-----
中文繁體	-----
日本語	-----
한국어	-----
Русский	-----



## What's Inside



### NOTE :

For the best fit and the most immersive music experience, start with the largest size ear tip and then work your way down.

1. Multi-function button
2. Earbud status LED
3. Microphone
4. Earbud charging contacts
5. Case battery LEDs
6. Type C charging port - to charge the portable case
7. USB charging port - to charge your smart device



## SETUP

### CHARGING YOUR EARBUDS

To charge the earbuds, place them into the portable case. The red LEDs show that they are charging. When fully charged, the LEDs turn blue, and then turn off.



### CHARGING YOUR PORTABLE CASE


Plug the small end of the USB cable into the USB type C port, located on the right side of the case. When all 4 LEDs are lit, it's fully charged.



## CONNECT BOTH EARBUDS

### STEP ONE – TURNING ON EARBUDS

Your earbuds will automatically turn on when taken out of the charging case. If you want to turn them on manually, you can press and hold the multi-function button for 3 seconds on both earbuds.



### STEP TWO – CONNECTING THE EARBUDS TO EACH OTHER

When you take the earbuds out of their case, they will automatically connect to each other about 5 seconds, and the LED of left earbud will flash blue and red colors once connected, this puts them into sync mode. If they don't connect, press and hold the multi-function button for power it on.


### STEP THREE – CONNECTING TO A DEVICE

Enable Bluetooth on your device. From the Bluetooth menu, select "@audio AIR." When the device and Audio AIR are connected, you will hear a tone. This means pairing is complete.



## CONNECT ONE EARBUD

Connect only one earbud for mono sound. This is a great option if you want to hear your surroundings as well as your music.




### STEP TWO – PAIRING MODE

Take either left or right earbud out of the case, wait until the LED flashes blue color rapidly. This will indicate that your earbud is in pairing mode with your device.

### STEP THREE – CONNECTING TO A DEVICE


Enable Bluetooth on your device. From the Bluetooth menu, select "@audio AIR." When the device and the earbud is connected, you will hear a tone. This means pairing is complete.



## TURNING OFF YOUR EARBUDS

### STEP ONE – TURNING ON THE EARBUD

Your earbud will automatically turn on when taken out of the charging case. If you want to turn it on manually, you can press and hold the multi-function button for 3 seconds.



### STEP TWO – PAIRING MODE

Take either left or right earbud out of the case, wait until the LED flashes blue color rapidly. This will indicate that your earbud is in pairing mode with your device.

### STEP THREE – CONNECTING TO A DEVICE

Enable Bluetooth on your device. From the Bluetooth menu, select "@audio AIR." When the device and the earbud is connected, you will hear a tone. This means pairing is complete.



## OPERATION

### MUSIC

Play or pause	Press either multi-function button once.
Next Song	Quickly double-press left multi-function button
Previous Song	Quickly double-press right multi-function button

### CALLS

Pick up a call	Press left earbud multi-function button once
Decline a call	Press and hold left earbuds multi-function button
End a call	Press left earbuds multi-function button once
Take 2nd incoming call	Press the phone keypad once
Decline 2nd incoming call	Press the phone keypad once

## TROUBLESHOOTING

### Having issues with your earbuds? Try working through the steps below.

1. Turn off Bluetooth on your device
2. Take earbuds out of your case
3. Press and hold multi-function button for 3 seconds on both earbuds to turn them off
4. Press and hold multi-function button for 3 seconds on earbuds to turn them on
5. Turn on Bluetooth on your device
6. Pair to "@audio AIR"

Wireless Earbuds  
Manufacturing date: 2017-08-18  
FCC ID: 2AXXX-XXX-XXXXXX  
DC Input: 5V ± 1000mA  
Made in China

Bluetooth  
CCLXXXYYZZW  
XXX-XXXX

### LED INDICATORS

#### EARBUDS CHARGING IN CASE


Flashing red	Low battery
Solid red	Charging
Solid blue	Fully charged

#### TRAVEL CASE

1 LED, 1st flashing	Low battery, 0-25%
2 LEDs, 2nd flashing	Battery capacity 25-50%
3 LEDs, 3rd flashing	Battery capacity 50-75%
4 LEDs, 4th flashing	Battery capacity 75-99%

### USING THE BACKUP BATTERY

Plug your device's USB charging cable into the travel case, and then into your smart device. With a full battery, your travel case can recharge your earbuds up to 25 times, or provide one full charge for a typical smart phone.



Activate iOS Siri  
Activate Google voice  
Check battery level of earbuds  
Check battery level of travel case  
Turn off earbud

Quickly triple-press left earbuds multi-function button  
Look at smart phone  
Shake the travel case to light the LEDs  
Press and hold multi-function button for 3 seconds

NOTE  
Some features may work differently depending on your phone or service carrier.

HELP  
Still have questions? We've got answers and we're standing by. Give us a shout, we're here to help.

SUPPORT  
The following is a set of resources to ensure you get the most out of your Audio AIR Earbuds.

WEB: mobile.net