

SIZE: 148X210CM

148CM

210CM

1. Pairing with Bluetooth

- Turn on the power button to the Grandmaster mode.
- Press the **BT** button on the top of the device to enter the pairing mode.
- Search for the **GM3766** on your mobile phone and connect it to the device.
- It is suitable for all kinds of mobile phones that have Bluetooth function and wireless connectivity.

2. TWS function

Press the **BT** button on the top of the device. Hold the **BT** button on the top of the speakers to activate the TWS connection. Then connect your mobile with any pair of 3.5mm's. The other will be affected in the same way.

3. Voice prompt

Press prompt at anytime you want.

4. FM function:

- Turn on the unit, then press the **FM** button to switch to FM mode.
- Adjust the volume knob to the maximum volume.
- Adjust the frequency knob to the frequency you want to receive.
- As there are preset the **FM** buttons to reach the preset frequency station.

The radio signal and station will be affected by the conditions in your area.

5. Switching functions (Mode button)

Bluetooth mode
 Bluetooth mode
 AUX mode
 USB mode (Auto mode)
 FM mode (Auto mode)

6.LED light indicator

Long Press the **BT** button to turn on/off the LED light.

7. Charge

Press the **BT** button to start charging.

Charging light will be on when the charging unit has off, when it fully charged.
 How many times was slightly, according to the system.



INSTRUCTION MANUAL

GRANDMASTER BLASTER
50B3E76K


Technical specifications:

Bluetooth V5.3
 Transmission distance: 10 meters
 Battery capacity: 200mAh
 Charging time: 2h
 Charging type: USB-C
 Speaker size: 30mm x 20mm x 6mm
 Sensitivity: ±3dB

Button instructions:

Long Press for about 2 seconds to turn on/off.
 Short Press for about 1 second to turn on/off.
 Hold button

CE
 Short Press to increase the volume
 Short Press to decrease the volume
 Short Press to mute
 Short Press to stop call or Bluetooth mode
 To the music, hold the power button for 3 seconds to enter the sound field or call, to change call to use the better sound (swimming)



5. One with high quality sound
 2. With LED light effects

Features:

- Bluetooth connection
- Bluetooth pairing to connect AUX
- With LED light effects
- Hands-free function

CE
 Long Press to start charging unit
 Short Press to stop charging unit
 Long Press to start call or Bluetooth mode
 To the music, hold the power button for 3 seconds to enter the sound field or call, to change call to use the better sound (swimming)

BT
 Long Press to start charging unit
 Short Press to stop charging unit
 Long Press to start call or Bluetooth mode
 To the music, hold the power button for 3 seconds to enter the sound field or call, to change call to use the better sound (swimming)

BT
 Long Press to start charging unit
 Short Press to stop charging unit
 Long Press to start call or Bluetooth mode
 To the music, hold the power button for 3 seconds to enter the sound field or call, to change call to use the better sound (swimming)

BT
 Long Press to start charging unit
 Short Press to stop charging unit
 Long Press to start call or Bluetooth mode
 To the music, hold the power button for 3 seconds to enter the sound field or call, to change call to use the better sound (swimming)

Technical specifications:

Bluetooth V5.3
 Transmission distance: 10 meters
 Battery capacity: 200mAh
 Charging time: 2h
 Charging type: USB-C
 Speaker size: 30mm x 20mm x 6mm
 Sensitivity: ±3dB

Button instructions:

Long Press for about 2 seconds to turn on/off.
 Short Press for about 1 second to turn on/off.
 Hold button

CE
 Short Press to increase the volume
 Short Press to decrease the volume
 Short Press to mute
 Short Press to stop call or Bluetooth mode
 To the music, hold the power button for 3 seconds to enter the sound field or call, to change call to use the better sound (swimming)

Features:

- Bluetooth connection
- Bluetooth pairing to connect AUX
- With LED light effects
- Hands-free function

CE
 Long Press to start charging unit
 Short Press to stop charging unit
 Long Press to start call or Bluetooth mode
 To the music, hold the power button for 3 seconds to enter the sound field or call, to change call to use the better sound (swimming)

FCC Statement
 Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy which, if not properly shielded, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the radio or television receiver on and off, the user is encouraged to take one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the radio or television receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) this device must accept any interference that may cause unintended operation.

Any change or modification is not expressly approved by the party responsible for compliance and voids the user's authority to operate the equipment.

The device has evaluated to meet general R.F. exposure requirement. The device can be used by its portable exposure without restriction.