









air
Vibes Sport

WIRELESS SPORTS EARBUDS

FOR ITEM
V40057W2-BLK
SKU#2199136

<p>In the Box</p>  <p>Micro USB Charging Cable</p>  <p>AirVibes Sport Truly Wireless Earphones With Charging case</p>  <p>Interchangeable Ear Tips</p>	<p>Take a Look</p>  <p>Eartip LED Indicator Light Charging Port Microphone Power/Action Button</p>  <p>Case Charging Port (On Rear) Charging Case Earphone Dock</p>	<p>Charging</p>  <p>● = Charging ○ (Off) = Charged</p> <p>Input: DC 5V 1A MAX</p>  <p>●●●●● = Charging ●●●●● = Charged</p>
------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

Powering On/ Bluetooth Pairing



(When the earbuds are not in the charging box)
Press & hold both power buttons simultaneously for 2-3 Seconds


(When the earbuds are in the charging box just take them out and they will power on automatically.)

Once your earphones are powered on the LED Indicator Lights will alternately flash red and blue. After approximately 1-2 seconds, The LED Indicator lights will flash blue slowly, This means both earphones are paired together.

(If both earbuds do not pair together after 10 seconds, tap the power button on either earphone to force them to pair.)


Check your phone's Bluetooth settings menu. Make sure that Bluetooth is turned ON. Connect with the device listed as TWS Sport Earbuds.

Controlling Your Earphones




One Click: Play/Pause/Answer Incoming Call/End Call
Triple Rapid Clicks: Activate Siri/Google Voice Assistants
Hold 2-3 Seconds: Reject an Incoming Call
Hold 3-4 Seconds: Power Off (When Not Receiving a Call)

Play music



“+”: Short Press: Next Song, Press & Hold: Volume Up
“-”: Short Press: Previous Song, Press & Hold: Volume Down

Wearing Your Earphones



Choose Whichever Size Eartip Is Most Comfortable

FCC Statement FCC ID: 2AMD8-BLK-57W2

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in the portable exposure condition without restriction.

BATTERY WARNING:

- The device is equipped with an integrated lithium battery. The battery cannot be replaced. Do not attempt to remove the battery from the device.
- Do not dispose of in fire or expose to excessive heat.
- Do not crush, puncture, incinerate, or short circuit external contacts.
- Please recycle or dispose of the battery properly. Contact your local recycling facilities and/or the manufacturer for further information.

© 2023 Sakar International
195 Carter Drive,
Edison, NJ 08817

Keep Manual and All Relevant Information for Future Reference

air
Vibes Sport

If You're Having Trouble, We're Here to Help!

To Obtain Warranty Service and Troubleshooting Information, Call us 24/7 at 1-800-592-9541