


60x95(mm)



**BMBH085A**

For More Information Please Visit [www.xmpow.com](http://www.xmpow.com)

### 1 Device and Accessories

- User Manual x 1
- USB Charge Cable x 1
- Ear Caps ( M Size-On Ear )

### 2 Instructions

- Microphone for Calls / Gaming
- LED Light Indicator
- Micro USB Charging Port (cable included)

### 3 Operating the Earphone

#### Using the " " Buttons

- Hold 1-2s ----- Power ON
- Hold 4-5s ----- Power OFF
- Hold 1-2s ----- Pairing Mode

#### Pairing to a Bluetooth Device

- Make sure the Bluetooth on the mobile device you are trying to connect the earphones to is on.
- Hold the " " button for 1-2 seconds to enter pairing mode. The red and blue indicators will start flashing.
- In your devices Bluetooth list, search for 'MPOW A1', click on it, and your devices will pair.
- The earphone will automatically power off after 5 minutes without being paired to a device.

#### Play / Pause / Answer Call / Hang Up call

#### Press " " Buttons

- Short Press --- / Answer / Hang up
- Short Press --- / Play / Pause
- Hold 1-3S ----- Reject an Incoming Call
- Double Click -- Re-dial the last phone number

#### Activating Voice Control / Your Devices Personal Assistant

To activate voice control, simply hold the power button for 4 seconds, and you will hear your phone's notification that voice control is activated. You can now ask your personal assistant whatever you want, from the microphone on your earphone.

**NOTE**  
If a call comes in while you are listening to music or streaming a video, the audio /video will be paused, and you will hear your phones ringtone through the earphone. Once the call is ended, your entertainment will resume.

#### Next Song / Volume Up / Previous Song / Volume Down

#### Press " " Buttons

- Long Press ----- Next Song
- Short Press ----- Volume Up

#### Press " " Buttons

- Long Press ----- Previous Song
- Short Press ----- Volume Down

\* & \* Simultaneously press them for 4 seconds to delete the pairing list .

#### Charging the Earphone

Output: DC 5V

This earphone has a built-in, non-removable lithium battery. We highly recommend that you fully charge the headphone before the first use.

- To charge, connect the charging cable to the charging port, and then to a USB charger.
- A red light will flash indicating the earphone is charging.
- The red light will turn off once the earphone is charged.

#### Fast Charging

It can be frustrating to forget to charge your earphone. For those moments, our Fast Charge technology gives you 1.5 hours of play time with only 10 minutes of charging.

**NOTE**

- Our earphone, applied with quick-charge battery, can be charged very quickly. It's charging temperature is 50°F-113°F.
- Please fully charge it if it was going to be laid idle for a long time and place it in a cool and dry place.
- Please recharge it each 2 months for storage.
- Please fully charge it for the first use.

#### 4 LED Behaviour

Work Status	Indicator Light Status	Voice Prompt
Power on	Blue indicator light is on for 1 second * 1s	Power on
Power off	Red indicator light is on for 1 second then all of the light off * 1s *	Power off
Pairing	Red and blue indicator lights flash simultaneously *	Pairing

#### 5 Specifications

Connected	Blue Indicator light flashes once every 10 seconds	Connected
Low battery warning	Red Indicator light flashes 3 times	Battery Low
Charging	Red indicator light is on all the time when charging, and is off when fully charged	

Operation Range	33 feet
Talking Time	8-10 hours
Playing Time	8-10 hours
Charging Time	1.7 hours
Charging Voltage	DC 5V
Battery Capacity	3.7V/140mAh

**NOTE**  
Actual play and talk times will ultimately depend on the phone / mobile device you are using, the listening volume, as well the frequency of the use of the different buttons and toggling between functions.

#### 6 Limited Warranty

MPOW Technology Co, LTD, warrants to you that the Product (excepting components provided in / with the Product) will be free from defects in workmanship and materials for a period of ONE year from the date of retail purchase by you (the "Warranty Period").

During the Warranty Period, the Product (excepting components), will be repaired or replaced at MPOW's option, without charge for either parts or labor OR at MPOW's sole option, the price of the Product may be refunded, subject to depreciation based on your purchase price for the Product pro-rated over the remaining balance of the Warranty Period.

Any warranty service or replacement of parts will not extend the Warranty Period.

**This Limited Warranty does not cover defects which are a result of:**

- Damage caused by accident, unreasonable use or neglect (including the lack of reasonable and necessary maintenance);
- Damage during shipment (claims must be presented to the carrier);
- Damage to, or deterioration of, any accessory or decorative surface;
- Damage resulting from failure to follow instructions contained in your owner's manual;
- Damage resulting from the performance of repairs by someone other than an authorized MPOW service center;
- Deterioration of component parts, the nature of which is to become worn or depleted with use, such as batteries and headphone ear pads.

#### 7 FCC Statement

**Operation is subject to the following three conditions:**

- This device may not cause harmful interference.
- This device must accept any interference received, including interference that may cause undesired operation.
- This device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure condition without restriction.

**NOTE**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or a technician for help.

**Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.**

**This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:**

- this device may not cause harmful interference, and
- this device must accept any interference received, including interference that may cause undesired operation.

**Bluetooth**

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by MPOW Technology, LTD is under license. Other trademarks and trade names are those of their respective owners.

**WARNING!**

- The product can ONLY be charged by 5V Adapter/USB Port, otherwise it will cause heat and fire.
- The BMBH085A is not a toy, please supervise your children when using the equipment.
- To avoid potential risks and protect products, please do not charge it at a temperature lower than 50°F or higher than 113°F.

**MPOW TECHNOLOGY CO.,LTD**  
Copyright © MPOW Inc. All rights reserved.  
[www.xmpow.com](http://www.xmpow.com) | [support@xmpow.com](mailto:support@xmpow.com)  
Phone Number : 1-844-869-3583

**FCC ID: 2AMH2-BMBH085A**  
This device complies with Part 15 of the FCC Rules.  
**MADE IN CHINA**