



## Welcome to Iris.

Thanks for purchasing the Smart Hub, the heart of the Iris system. Connect an array of Iris-compatible smart products to your Hub so you can easily access and control them all from the Iris app or web portal. Control temperature, locks, lights and more from your favorite brands right from your mobile device.

## Getting started only takes a few easy steps.

1. Create an Iris account through the [irisbylowes.com](http://irisbylowes.com) web portal, iOS app or Android app.
2. Once logged in to your account, select the "+" icon to add a Hub.
3. Follow the pairing steps.

For more information about your new device or tips on how to set it up, visit our support page at [irisbylowes.com/support](http://irisbylowes.com/support).



### Where to place your Hub:

Place your Smart Hub in a central location of your home. This will help ensure a strong signal can reach the various areas of your home. Your Hub connects to your home Wi-Fi.

### Smart Hub Technical Specifications

Input: 100-240V, ~50/60Hz, 0.5A

Output: 12V 1.5A

Wireless RF Protocol:  
Z-Wave, Zigbee, 4G, 2.4G Wi-Fi  
and Bluetooth

Features: LED ring, built-in  
speaker, backup battery included

\*\*To get 4G service, subscribe  
to Pro-Mon or add the cellular  
backup add-on service plan.

