

OUTSIDE LEFT

How To Find The Serial Number

To find your device's serial number, follow the steps below.

1. Via the Find My app:
 - a. Open the Find My app, tap the Items tab, and tap your KeySmart iPro.
 - b. Scroll to the bottom of the Item Detail card. The serial number is displayed below Manufacturer.
2. On the device:
 - a. Disassemble the KeySmart iPro. The serial number is printed on the underside of the plate.

Warranty

KeySmart iPro is designed to make your life easier. That's why every KeySmart iPro is covered under warranty for a one full year against defects in materials and workmanship. To learn more, visit getkeysmart.com/warranty.

Use And Care

The KeySmart iPro is water-resistant but not waterproof. We encourage you to bring your KeySmart iPro along on most of your wild adventures, but deep-sea explorations (and the like) are not recommended. It is not recommended that you expose the KeySmart iPro to extreme hot or cold temperatures.

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference; (2) this device must accept any interference received, including interference that may cause undesired operation. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

OUTSIDE RIGHT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC RF exposure statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

KeySmart iPro contains small parts that could be harmful to young children and pets.

Legal

Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards. Apple Find My, Apple Watch, Find My, iPhone, iPad, iPod touch, Mac, macOS and watchOS are trademarks of Apple Inc. IOS is a trademark of Cisco and is used under license.

KEY|SMART

FRONT

Hello,

before you add keys to your KeySmart iPro let's get it connected to the Apple Find My app.

1

Quickly press and release the Find My button. Your KeySmart iPro will beep once and the LED will flash green.

2

Open the Apple Find My app on your iOS device, tap the "+" and select "Add Other Item" from the menu.

3

The KeySmart iPro will appear on screen. Tap to connect and set a custom name and icon for your keys.

Charge Before Use

Before using your KeySmart iPro for the first time, make sure to fully charge the battery.

While charging, the indicator light will be orange. When the battery is fully charged, the indicator light will be green.

INSIDE LEFT

What's included



How To Assemble Your KeySmart iPro

Scan the QR code or go to getkeysmart.com/instructions and follow the instructions to add up to 14 of your existing keys.



How to Use the Flashlight

Press the Flashlight button to turn on and release to turn off. Double-click the Flashlight button to turn on the flashlight for 10 seconds. The flashlight will turn off automatically if pressed for more than 3 minutes to preserve battery life.

Features of the Apple Find My app

KeySmart iPro is a special edition that works exclusively with the Apple Find My network. The Apple Find My network provides an easy, secure way to locate compatible personal items on a map using the Find My app on your iPhone, iPad, iPod touch, or Mac, or using the Find Items app on Apple Watch. Simply pair your compatible product with the Apple Find My app to view it right alongside your Apple devices.

KEY|SMART

INSIDE RIGHT

If your item ever goes missing, you can put it in Lost Mode to display a message and contact information to anyone who might find it. The Find My network is encrypted and anonymous, so no one else, not even Apple or the maker of your personal item, can view its location.

Requirements

To use the Find My app to locate this item, the latest version of iOS, iPadOS, or macOS is recommended. The Find Items app on Apple Watch requires the latest version of watchOS.

Privacy

The Apple Find My network uses advanced encryption to ensure that no one else, not even Apple or KeySmart can view the location of your KeySmart iPro.

How to Enable or Disable the Apple Find My network

If you would like to disable your KeySmart iPro from accessing the Find My network, follow the steps below.

1. To switch between modes, press and hold the Find My button for 3 seconds.

How to Perform a Factory Reset

If you would like to unpair your KeySmart iPro from your Find My account so that it can be paired to a different Find My account, follow the steps below.

1. Open the Find My App, tap the Items tab, and tap your KeySmart iPro.
2. Scroll to the bottom of the Item Detail card, tap Remove Item, and follow the onscreen instructions.
3. Press the Find My button 5 times in quick succession and hold the button on the 5th press.
4. The KeySmart iPro will play a tune and perform the factory reset.

KEY|SMART

BACK

Thank you for using

KeySmart iPro K5431



For instructions in French, German, and Spanish go to
Pour obtenir des instructions en français, rendez-vous sur
Eine deutsche Anleitung finden Sie unter
Para obtener instrucciones en español, vaya a

getkeysmart.com/instructions

Curv Group, LLC

860 Bonnie Ln, Elk Grove Village, IL 60007, USA
f KeySmart @ keysmart KeySmart