

CONTENTS

Vehicle

Transmitter

USB Charging Cord (Included)

3.7V 700 mAH Rechargeable Battery Pack (Included)

Battery

All batteries included.

Vehicle
1 x 3.7V Lithium (Included)

Transmitter
2 x AA.15V (Included)

TRANSMITTER

- 1 ON/ OFF Switch
- 2 Open battery compartment cover at the bottom of the transmitter. Close it after batteries installed.
- 3 Insert 2x1.5V AA battery with correct polarity, as shown inside battery compartment. Close the cover and fasten the screw.

Vehicle

- 1 Use a screw driver to open the battery compartment.
- 2 ON/ OFF Switch
- 3 Connect the battery pack with the plug from battery compartment. Close the cover and fasten the screw.

VEHICLE - ON/ OFF

Turn on the switch of the vehicle. Please be sure to confirm that the switch in the rubber packing was switched over.

TRANSMITTER - ON/OFF

Switch on transmitter and LED light turns on.

TURNING ALIGNMENT

Steering Adjuster Axle R

Steering Adjuster Axle L

Turn the steering axle adjuster at the bottom towards "L" when the vehicle drives to the right unintentionally. If it turns left unintentionally, turn the adjuster towards "R".

REMOTE INSTRUCTION

Forward

Backward

Turn Left

Turn Right

After Play

- 1 Switch OFF the Vehicle after play.

- 2 Switch OFF the Transmitter after play.

Battery Safety Information:

- Insure that battery polarity is correct.
- Use only batteries of the type recommended (or equivalent).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Rechargeable batteries are to be removed from the product before being charged.
- Rechargeable batteries are to be recharged by Adult only.
- Remove used-up batteries immediately.
- Do not recharge non-rechargeable batteries.
- Do not short-circuit terminals.
- Dispose of batteries safely. Do not dispose of batteries (or products containing non-rechargeable batteries) in fire, as batteries may explode or leak.

This device complies with the Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or experienced radio/TV technician for help.

