材质:70G书写纸 展开尺寸:85*360mm 成型尺寸:60*85mm 成型方式:风琴褶 印制方式:双面印制 颜色:2C

Charging

LED on Charging Case



LED for low battery warning

Four LEDs will blink 3 times to display practical battery level whenever you open/close lid. Then LEDs for battery level will glow solid for 10s.

Low battery warning(carry case): If battery level is under 25%. LED will blink white three times then turn off and re-blink three times. The process will repeat in 1 minute.

Battery level display

LEDs Remaining battery level						
• • • • 50%-75% • • • • 25%-50%	LEDs	Remaining battery level				
• • • • 25%-50%	• • • •	75%-100%				
	• • • •	50%-75%				
。。。。 0%-25%	• • • •	25%-50%				
	0 0 0 0	0%-25%				

Four LEDs will blink 3 times with draw marquee effect then glow solid to display practical battery level, when charging.

Battery level display in charging

LEDs	Remaining battery level				
÷ 0 0 0	0%-10%				
• • • • •	10%-25%				
• • 💠 •	25%-50%				
• • • *	50%-75%				
	75%-100%				

Caveats

- 1. Never disassemble or modify your headset for any reasons to avoid any damages and danger.
- Do not store the headset in extreme temperatures. (under 0°C or over 45°C).
- 3. Avoid using the indicator close to the eyes of children or animals.
- 4. Do not use this headset during a thunderstorm to avoid irregular function and increased risk of electricshock.
- 5. Do not use harsh chemicals or strong detergents to clean the headset.
- 6. Keep the headset dry.

Factory Setting

If earphones do not function well, please refer the following steps to reset factory: take earbuds out from the case. Power off the earphones then touch both panels for about 15s (LED will blink red and white three times twice). Ater that, put them back to the case. Delete connectivity record on cellphone before processing another pairing (All connecitvity records relating to the earbuds will all be removed).

Audio only outputs from single earbud

It's really rare. Please reset GT1 Pro, remove connectivity record on your cellphone and re-connect the earphones to your cellphone.

Other cases in charging

LED glows solid white for 1 minute when earbuds are topped up.

Carry case cannot charge earbuds, if its battery drains. LEDs on carry case will turn off once the case is topped up. If you charge it once again, LEDs will not give any notice, which does not mean the case is not charged.

Daily maintenance

Please do not shower with earbuds. Do not wear them in rainy day. Do not leave them in washing machine or other extreme situations. Clean them with dry cloth after use in pursuing a longer service life.

Hazardous substances and their 10 contents in the item

		Hazardous Substances									
	Part Name	Pb	Hg	Cd	Cr (VI)	PBB	PBDE	DIBP	DEHP	DBP	BBP
	Main body	X	0	0	0	0	0	0	0	0	0
	Battery	0	0	0	0	0	0	0	0	0	0
	Eartips	0	0	0	0	0	0	0	0	0	0
	Accessories	0	0	0	0	0	0	0	0	0	0
	Charging cable	X	0	0	0	0	0	0	0	0	0

This form is made by SJ/T 11364 regulation. O: means that hazardous substance content in the homogeneous materials of this part is within the limits of (EU) 2015/863 regulation

X: means that hazardous substance content in ,at least, one certain homogeneous material of this part is beyond the limits of (EU) 2015/863 regulation ,but there is no mature alternative in the industry at present, it still conforms to the FU ROHS Directive in the scope of exemption.

Notes: Please arrange using time properly as your hearing may be damaged by using the device for a long time.

Tips

- 1. Before using the headset, please read the manual carefully and keep it for future references.
- 2. The headset need to be fully charged prior to first-time use.
- 3. If the headset is left unused for over two weeks, please recharge it periodically.
- 4. Please use the chargers made by qualified manufacturer.
- 5. If the headset cannot be found by your phone, please check whether it is in pairing mode; if left unconnected for a long while, the headset will exit pairing mode, please re-enter the mode: if a procedure error of your phone occurs, reboot it; if a procedure error of the headsetoccurs, reboot or reset it.

Franchiser: Shenzhen FOCUSPOWER Internation Supply Chain Co., Ltd.

Address: 3th Floor, E-Inter-Dynasty Building, Zhongxing Rd. Bantian St.

Longgang District, Shenzhen City, Guangdong, . Web: www.focpower.com

E-mail: support@focpower.com














Product Overview



What's in the Box

Eartips × 3 Pairs Wireless earphones × 1 Pairs Charging case × 1 Pcs Charging cable × 1 Pcs Manual × 1 Pcs

Basic Parameters

Operation range: 10m(with no obstacle) Battery capacity: 43mAh(single earbud) Charging time: approx. 1.5hr Calling time: approx. 3.5hr Standby time: approx. 150hr Input parameter: 5V = 100mA Battery type: li-ion Bluetooth version: 5.0

Charging Case Input parameter:5V== 500mA Output parameter:5V== 150mA Charging time: approx. 3.5hr Standby time: approx. 4 months Battery capacity: 800mAh Battery type: li-ion

How to wear



Please keep Mic outside when calling



When calling, adjust Mic towards mouth to gain better talking experience.

How to Charge


Prior to using, please peel off sticker from the pogo pins and top up the earphones.



Basic Operation

Power-on

Take out earphones from the case to power on them. Or touch both panels for 1.5s to power on earphones (LED glows solid white) when they are not in the case.



Power-off

Put earphones into the case to power off them. Or touch both panels for 4.5s to power off earphones (LED glows solid red for 2s).




Pair and connect

Stereo Mode

Auto pairing: take out both earbuds from the case On cellphone, search for FOCUSPOWER-F10 Pro and tap to connect.

If you fail to build connection, please pull earbuds back into the case and repeat the above steps. Once connected, earbuds will auto reconnect to the last device in connectivity records whenever

(Bluetooth faculty needs to be turned on).




Manual pairing: manually power on two earbuds and they will auto pair with each other when LED blinks white prmptly. Then LED on the right earbud will blink white slowly and now you can tap it on cellphone to connect.

Mono Mode

Auto pairing: take out one earbud from the case to power on. Its LED will soon blink slowly then search for FOCUSPOWER-F10 Pro on cellohone and tap to connect.

Manual pairing: manually power on one earbud. Its LED will soon blink white slowly then search for FOCUSPOWER-F10 Pro R/L on cellphone and tap to connect.

Functions



FCC ID:2AMQ6-F10PRO

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try correct the interference by one or more of the following measures:

Reorient the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into and outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.