


项目：T016
品名：中英文说明书
料号：
版本：B

更新日志：
2024-07-05 增加CMIIT ID：24J44P2FK661

图档识别



--- 裁切线
- - - 压痕线
—— 标注线

图档比例：1: 1

技术要求

- 1.尺寸：55x80mm
- 2.材质：70g书写纸
- 3.印刷：专色印刷
- 4.工艺：风琴折+对折
- 5.公差：±1mm
- 6.备注：英文为首页


注：所有材料必须符合ROHS规定。

资料确认

品牌： 电子：
市场： 品质：
软件： 包装：



东莞市猎声电子科技有限公司
Dongguan Liesheng Electronic Co., Ltd.



产品介绍

耳机重置:

1. 将两只耳机放入充电盒内，保持充电电量充足。
2. 长按充电按键3s。
3. 充电盒指示灯亮起闪烁4s后恢复出厂设置。
4. 清除手机配对记录，按配对步骤，重新完成蓝牙连接即可。

常见异常:

1. 耳机一边有音一边无声，尝试将两只耳机放入充电盒内取出，以上步骤操作后还无法解决，尝试重置步骤。
2. 耳机无法充电，检查充电电量是否充足；用干布或者棉签清理充电接触部位。
3. 耳机无法和手机自动连接，检查充电电量是否充足，充电导致耳机无法关机，无法和手机断开连接。

包装内容物

耳机，充电盒，充电线，说明书，耳机配件包。

佩戴耳机

将耳机轻轻塞入耳道，调整耳机达到最佳佩戴状态。

通话时，将耳机麦克风向前倾斜可使通话更清晰。

充电

插入充电线可同时对耳机和充电盒充电。充电盒未充满电时指示灯闪烁，充满电后指示灯熄灭。

充电盒电量低于20%时将耳机放入盒内，充电盒指示灯闪烁4s后熄灭。

温馨提示：充电盒电量耗尽后，无指示灯，不能给耳机充电。

首次开机使用，请先去除左右耳机充电触点处的隔离膜，将充电盒及耳机充电。

开机

耳机在充电盒内，取出耳机自动开机。

关机

放入充电盒中，耳机自动关机。

连接配对

同时将两只耳机从充电盒取出，打开设备蓝牙搜索“HAYLOU Mori Pro”并点击完成连接。如果连接失败，将耳机放回充电盒，重复上述操作。首次连接后，耳机开机可自动连接上一次配对设备（蓝牙需开启）。

单耳/双耳自由切换，两只耳机连接成功后即可双耳连接。将任一耳机放回充电盒关机，另一只耳机进入单耳模式，重新取出即可自动恢复双耳模式。

功能说明

请下载Haylou Sound APP

请扫描Haylou Sound APP二维码

注意事项

警告

1. 请勿自行拆卸拆开、维修或改装耳机，否则可能会导致起火甚至造成财产损失。
2. 请勿将设备置于温度过低或过高（0°C以下或45°C以上）的环境中。
3. 使用产品指示灯时，请避开儿童或动物的眼睛。
4. 请勿在雷雨天天气下使用本产品，雷暴可能导致设备工作异常，并增加触电的危险。
5. 请勿使用酒精或其他挥发性液体擦拭本产品。
6. 请勿将本产品与液体接触。

注意

1. 使用前请仔细阅读本产品使用说明书并妥善保管。
2. 首次使用时，请先将本产品充满电。
3. 如果产品长期超过2个月不使用，请对其进行充电。
4. 必须选择正规厂家生产且经过国家CCC认证的充电器。
5. 长时间连续使用耳机有损听力，请合理控制使用时间及音量。
6. 使用耳机时请避免对外界声音的感知力，请不要在可能威胁到安全的环境中佩戴耳机。

产品中有有害物质的名称及含量

部件名称	有害物质
铝 漆 磷 六价铬 多溴联苯 多溴二苯醚	RoHS (REACH) (PBB) (PFOS) (PFOA)
耳机主体	○ ○ ○ ○ ○ ○ ○ ○ ○ ○
电 池	○ ○ ○ ○ ○ ○ ○ ○ ○ ○
充 电 盒	○ ○ ○ ○ ○ ○ ○ ○ ○ ○
充 电 线	○ ○ ○ ○ ○ ○ ○ ○ ○ ○

注表格依据SJ/T 11364的规定编制。

○ 表示该有害物质在所列部件的所有材料中的含量均符合GB/T 26572规定的限量要求以下。

X 表示该有害物质至少在该部件的某一材料中的含量超出GB/T 26572规定的限量要求。

Haylou蓝牙耳机售后服务

Haylou蓝牙耳机售后服务严格按照《中华人民共和国消费者权益保护法》、《中华人民共和国产品质量法》、《中华人民共和国三包规定》等法律法规，售后服务如下：在三包有效期内，您可凭购物凭证退换货并享受免费的维修、更换、退货的服务。

1. 自您购买之日起7日内，本产品出现故障，经由Haylou客服中心确认为产品质量问题的，可享受维修、更换、退货服务。
2. 自您购买之日起15日内，本产品出现故障，经由Haylou客服中心确认为产品质量问题的，可享受维修或更换的服务。
3. 自您购买之日起12个月内，本产品出现故障，经由Haylou客服中心确认为产品质量问题的，可享受维修的服务。

非保修条例

1. 使用造成非正常磨损损坏如：刮痕、颜色改变、自然老化现象、物理性损坏、摔落造成损坏、人为导致损坏。
2. 未经授权拆修、设置、维修、改装、滥用、误用、修改、改动、不正确的使用导致本产品配件或零件、液体损坏、液体污染。
3. 超过三包有效期后。
4. 因不可抗力造成的损坏。
5. 不符合《售后服务政策》系列性能故障的情况。
6. 因人为原因导致本产品及其配件产生产品性能故障（如）系列性能故障。

Overview

How to Use

- Double click the left/right MFB Play/pause music
- Triple click left MFB Skip track backward
- Triple click right MFB Skip track forward
- Press and hold the left MFB for 2s Turn on/off low latency mode
- Press and hold the right MFB for 2s Switch between noise cancellation modes
- Double click the left/right MFB Answer/hang up a call
- Press and hold the left/right MFB for 1.5s Reject a call

How to Wear

Gently insert the earphone into the ear canal, adjust the earphone to the most comfortable wearing state.

When calling, adjust Mic towards mouth to gain more clear call.

How to Charge

Plug in the charging cable to charge the earphones and the charging case at the same time. The charging indicator light will be flashing slowly when the charging case is not fully charged. The indicator light goes out after fully charged.

When the battery level of the charging case is below 20%, put the earphones into the case, and the charging case indicator light will flash slowly for 4s before turning off.

Warm reminder: When the charging case is out of power, there is no indicator, and the earphones can't be charged.

Power-on

Take the earphones out from the charging case, they will automatically power on.

Power-off

Put the earphones back into the charging case, they will automatically power off.

How to Connect

Take out both earphones from the charging case at the same time. Turn on device Bluetooth and search for "HAYLOU Mori Pro", then click to connect.

If connection fails, put earphones back into the case and try again. After connection, earphones will automatically re-connect to the last paired device whenever power on (Bluetooth needs to be turned on).

Switch between mono and stereo mode: Pick up two earphones to auto enter stereo mode and push one back to enter mono mode. Or you can pick it up again to resume stereo mode.

请下载Haylou Sound APP

Please download Haylou Sound APP to experience more.

Restore Factory Settings

1. Put both earphones into the charging case and ensure the charging case has sufficient power.
2. Press and hold the charging case button for 3s.
3. The earphones will restore factory settings after the charging case indicator quickly flashes 4 times.
4. Clear phone pairing records and follow the steps to pair again.

*If the operation fails, please repeat the above steps, or log in to the official store, contact customer service to view the reset operation video.

Package List

Earphones, charging case, charging cable, user manual, ear tips.

Product model: T016

Basic Parameters (earphones)

Operation range: 10m (open space with no obstacles)

Battery capacity: 50mAh (single earphone)

Charging time: approx. 1.5h

Playback time: approx. 2hr

Input parameter: 5V = 50mA

Battery type: Li-ion polymer

Bluetooth version: V5.4

Basic Parameters (charging case)

Input parameter: 5V = 500mA

Output parameter: 5V = 200mA

Charging time: approx. 2hr

Battery capacity: 400mAh

Battery type: Li-ion polymer

The above data comes from Liesheng Lab, and the actual usage is affected by factors such as environment, operation and signal.

Caution

Warning

1. Do not disassemble, repair or modify the product for any reason, as this may cause fire or even completely destroy the product.
2. Do not repair the product to environments where the temperature is too low or too high (below 0°C or above 40°C).
3. Keep the indicators away from the eyes of children and animals while using the earphones.
4. Do not use this product during thunderstorms.
5. Thunderstorms may cause the product to malfunction and increase the risk of electric shock.
6. Do not wipe and clean the earphones or their case with alcohol or other volatile liquids.
7. Avoid any contact with liquids.

Note

1. Please read this user manual carefully before using the product and please properly store it.
2. When using for the first time, please fully charge this product.
3. Please charge the product, in case it has not been used over two weeks.
4. Please use certified charge.
5. Continuous use of earphones for a long time is harmful to hearing, please control the use time and volume reasonably.
6. Do not wear earphones in any situations with potential risks as wearing them may reduce your perception to the outside world.

FCC Requirement

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates noise and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Consult the dealer or an experienced radio/TV technician for help. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure condition without restriction.

Warranty Period

12 months after you purchase this item. (or you may require your local shopper for more details.)

Free Service

Supporting any defects caused by quality issues occur within the warranty period, please take this warranty card and purchase receipts to your distributor for free exchange service.

Free exchange service will not be accessed under following circumstances:

1. Damages caused by unauthorized disassembly.
2. Defects or physical damages caused by leaking or dropping off.
3. Damages by act of God.

Supporting your item within any damages or defects except the above circumstances, please return to us or your distributor for free repairing.

CE ENEC RE RoHS

FCC ID: 2ANQ6-T016

Manufacturer: Dongguan Liesheng Electronic Co., Ltd.
Address: Room 10073, No. 156, Humen Avenue, Humen Town, Dongguan City, Guangdong Province, China
Web: www.haylou.com