


HAYLOU


HAYLOU Lady Bag
ANC True Wireless Earbuds

User Manual


01 Package List




earphones



Operation guide




use manual




Charging Cable


02 Button Functions



MFB
LED
Mic




Charging contacts




Reset button
LED
Type-C charging port

03 Wearing Method




Gently insert the earbud into the ear canal, adjust the earbud to the most comfortable wearing state. It is recommended to choose suitable size of ear tips to ensure ANC effect.



When calling, adjust Mic towards mouth to gain better talking experience.


04 Basic function

For first time use, please remove the isolation film on the charging contacts of both earbuds. Then fully charge the charging case and earbuds.




Remove isolation film

Plug in the charging cable to charge the earbuds and the charging case at the same time. The charging indicator light will be solid white when the charging case is not fully charged. The indicator light goes out after fully charged.




05 Charging

Take out to auto power on when the earbuds are in case.




The earbuds will auto power off when put in the charging case.



06 How to Pair

Take two earbuds out from the charging case simultaneously, then open device Bluetooth and search for "Haylou MoriPods ANC", finally click it to complete the connection. Put the earbuds back to the charging case and repeat the above operation if the connection fails. After the first connection, the earbuds can be automatically connected to the last paired device (Bluetooth needs to be turned on).



Switch between mono and stereo mode: It is stereo mode after two earbuds are successfully connected. Put one back into the case to power off, the other will enter mono mode. Or pick it up again to resume stereo mode.

07 Factory Setting

- Put the earbuds back into the charging case and keep the charging case fully charged. Then long touch the earbuds MFB buttons for 10s until the earbuds LEDs flash 3 times;
- Clear phone pairing record and complete the connection again.

Common abnormals:

- One of the earbuds is mute:
Try to put the mute earbud into the charging case and then take it out;
If the problem is still not solved after the above operation, try the reset steps;
- The earbud cannot be charged:
Check whether the charging case has sufficient power;
Wipe the charging contacts with a dry cloth or cotton swab;
- The earbud cannot automatically disconnect from the mobile phone:
Check whether the charging case has sufficient power. The earbud will not power off if the case is out of power and will not disconnect from the mobile phone.

08 Basic Parameters of Headphones

Product name: Haylou Lady bag
Product model: Haylou T87

Basic Parameters(earbuds)
Operation range: 10m (open space with no obstacle)
Battery capacity: 34mAh (single earbud)
Charging time: approx. 1.5hr
Talk time: approx. 3hr (In ANC-OFF state)
Standby time: approx. 25hr (In ANC-OFF state)
Input parameter: 5V = 90mA
Battery type: li-ion
Bluetooth version: V5.2

Basic Parameters(charging case)
Input parameter: 5V = 500mA
Output parameter: 5V = 200mA
Charging time: approx. 2hr
Battery capacity: 300mAh
Battery type: li-ion

* The above data is obtained from Haylou's internal laboratory tests under specific conditions and is for reference only. It may vary in actual use depending on user habits and environment.

09 Caveats

Warning

- Do not disassemble, repair or modify the product for any reason, as this may cause fire or even completely destroy the product.
- Do not expose the product to environments where the temperature is too low or too high (below 0°C or above 45°C).
- Keep the indicators away from the eyes of children and animals while using the headphones.
- Do not use this product during thunderstorms. Thunderstorms may cause the product to malfunction and increase the risk of electric shocks.
- Do not wipe and clean the headphones or their case with alcohol or other volatile liquids.
- Avoid any contact with liquids.

Note

- Please read this user manual carefully before using the product and please properly store it.
- When using for the first time, please fully charge this product.
- Please charge the product, in case it has not been used over two weeks.

10 Warranty Card

Warranty Period 12 months after you purchase this item. (or you may inquire your local shopper for more details.)

Free Service
Supposing any defects caused by quality issues occur within the warranty period, please take this warranty card and purchase receipts to your distributor for free exchange service.


Model Number	
Date of Purchasing	
User's Name	
User's Phone	
User's Address	
Shop's Name	
Shop's Address	
Comments	

Free exchange service will not be accessed under following circumstances:
1. Damages caused by unauthorized disassembly.
2. Defects or physical damages caused by leaking or dropping off.
3. Damages by act of God. Supposing your item is within any damages or defects except the above circumstances, please return to us or your distributor for free repairing.

Manufacturer: Dongguan Liesheng Electronic Co., Ltd.
Address: Room 401-410, Building 1, No.86 Hongtu Road,
Nancheng District, Dongguan City, Guangdong, China
Web: www.haylou.com

04 Basic function

For first time use, please remove the isolation film on the charging contacts of both earbuds. Then fully charge the charging case and earbuds.



Remove isolation film

Plug in the charging cable to charge the earbuds and the charging case at the same time. The charging indicator light will be solid white when the charging case is not fully charged. The indicator light goes out after fully charged.

