




How to Charge



Plug charging cable to charge the earbuds and the charging case at the same time.

When the charging case is not fully charged, the LED flashes red quickly.


After fully charged, the LED lights up white for a long time.

+

Power-on

Power-off

- Put the earbuds back into the charging case, if the charging case has power, the earbud will automatically power off. if the charging case has no power, the earbud will maintain the current state.
 The earbuds power off outside the charging case: they will automatically power off if not connected to the device within 3 minutes.





X1S



User Manual

- Double on any MFB
 Call time / For incoming call time / Hang up a call

• Press and hold 2s on any MFB Call time, Reject a call

Restore Factory Settings

Audio only Outputs from Single Earbud

- It's unusual indeed, please refer to the following operation steps if the situation occurs:

 1. Put the earbuds back into the charging case, and then take them out again to connect.

 2. Refer to the reset steps to reconnect the Bluetooth device.

Other Charging Problems

- When the charging case is out of power, the earbuds cannot be charged and keep the original connecting status.

 The LED flashes solid white when the charging case is fully charged.

Package Overview

- - Earbud model: X1S Earbud name: True Wireless Earbuds

 - Basic Parameters(earbuds)
 Operation range: 10m (open space with n
 Battery capacity: 30mAh(single earbud)
 Charging time: approx. 2h
 Playing time: approx. 5h
 Standby time: approx. 60h
 Input parameter: 5V = 50mA
 Battery type: Ii-ion
 Bluetooth version: V5.3

Basic Parameters(charging case)
Input parameter: 5V == 500mA
Output parameter: 5V == 100mA
Charging time: approx. 1.5h
Battery type: Ii-ion

Please do not shower with earbuds. Do not wear them in rainy day. Do not leave them in washing machine or other extreme situations. Clean them with dry cloth.

- Warning

- above 45°C).

 3. Keep the indicators away from the eyes of children and animals while using the earphones.

 4. Do not use this product during thunderstorms. Thunderstorms may cause the product to malfunction and increase the risk of electric shocks.

 5. Do not wipe and clean the earphones or their case with alcohol or other volatile liquids.

 6. Avoid any contact with liquids.

- Note

 1. Please read this user manual carefully before using the product and please properly store it.

 2. When using for the first time, please fully charge this product.

 3. Please charge the product, in case it has not been used over two weeks.

 4. Please use certificated charger.

 5. Do not wear earphones for a long term to protect your hearing.

 6. Do not wear earphones in any situations with potential risks as wearing them may reduce your perception to the outside world.



料号: 版本:A 更新日志: 图档识别

标注线 图档比例: 1: 1

裁切线

压痕线

技术要求

1. 尺寸: 55x80mm

项目: Haylou X1S

品名:英文说明书

2.材质: 70g书写纸

3.印刷: 专色印刷

4.工艺: 风琴折

5.公差: ±1mm

6.备注:

注: 所有材料必须符合ROHS规定.

资料确认

品牌:	电子:
市场:	品质:

软件: 包装:



东莞市猎声电子科技有限公司 Dongguan Liesheng Electronic Co., Ltd.