材质:128g 铜版纸,规格:65×62mm(折后),双面彩印,三折(参照样品),绿色部分色号与 8406011892 同,US 版,(中国美国共用)SANWA GSKBW064E-SET_manual_表面_特色1色(PANTONE 320C)+BK

2.4G Wireless Keyboard & Mouse

Manual/取扱説明書/使用说明书





2.4G Wireless Keyboard & Mouse GSKBW064E-SET FCC ID : 2AMSUW064E

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna. - Increase the separation between the equipment and

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. - Consult the dealer or an experienced radio/TV technician

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

1. Specification:

Keyboard					
Key number-Pitch	103 Keys-18mm	Key stroke	1.9±0.20mm		
Key display	English	Charging time	2 hours		
Key switch	Pantograph	Battery life	Approx.48 hours		
Size-Weight	W365×D127.4×H14.42mm·338g				

Mouse					
Reading method	Optical sensor system (Blue LED)				
Buttons	2 buttons, wheel button (scroll), count switch button 800·1200·1600 count per inch				
Resolution					
Charging time	3 hours	Continuous use time	Approx. 40 hours		
Continuous standby time	Approx. 400 hours				
Possible time for use	Approx. 35 days #When operating the mouse about 5% while using the computer for 8 hours a day. #This is our calculated value without considering natural discharge, etc., and is not guaranteed. #Performance will gradually decrease depending on the trial period. Please note.				

Size-Weight W60.5×D109.4×H30.9mm-Approx. 61g

 キー数・キーピッチ
 103キー・18mm
 キーストローク
 1.9±0.20mm

 キー表示
 英語
 充電時間
 2時間

キースイッチ パンタグラフ 連続動作時間 約48時間

800・1200・1600カウント/インチ

ボタン 2ボタン、ホイール (スクロール) ボタン、カウント切替ボタン

充電時間 3時間 連続動作時間 約40時間 連続待機時間 約400時間

使用可能日数 ※1日8時間パソコンを使用中に、マウス操作を5%程度行う場合。 ※自然放電等を考慮しない弊社計算値であり保証値ではありません。

 键数·键距
 103 键·18mm
 键程
 1.9±0.20mm

 键位表示
 英语
 充电时间
 2 小时

※試用期間により徐々に性能が低下します。予めご了承ください。

コネクタ形状 USB Aコネクタオス

连续使用时间 约 48 小时

连续使用时间 约 40 小时

※以每天使用 8 小时电脑, 鼠标操作占 5%的比例计算

使用可能时间 ※数据为公司内部测试结果,不考虑自然放电等因素。

※使用期间内性能会逐渐下降,请悉知。

尺寸·重量 W60.5×D109.4×H30.9mm·约 61g

サイズ・重量 W365×D127.4×H14.42mm・338g

サイズ・重量 W60.5×D109.4×H30.9mm・約61g

サイズ・重量 W14.8×D18.5×H6.1mm・約2g


独立架式

尺寸·重量 W365×D127.4×H14.42mm・338g


左键、右键、滚轮按键、连接切换键

1.规格参数

読み取り方式 光学センサー方式(ブルーLED



Receiver Communication range 10m ※It depends on the usage environment.						
Interface	USB	Connector	USB A			
Size-Weight	W14.8×D18.5×H6.1	<d18.5×h6.1mm-approx.2g< td=""></d18.5×h6.1mm-approx.2g<>				
2. Method of Charging Keyboard Power LED (red light) Normal Charging time: Approx. 2 hours when hillghts up in green. MicroUSB Connector USB cable included						
Mouse	LED (red light) Normal charging tir		Notebook PC			
	Approx. 3 hours **Lights out when fin	Lo:				





接收器								
传输范围	10m※因使用环境不同有所差异。							
接口类型	USB	接口形状	USB A 型					
尺寸·重量	W14.8×D18.5×H6.1mm·约 2g							
2. 充电方法键盘								
电源 LED (亮柱灯) 正常充电时间:约 2 小时 ※充电为绿色时,充电完成。 连接充电端口 AC 充电器等 附属 USB 线								
鼠标	LED(亮红灯) 正常充电时间:约3/ ※充电结束后灭灯	NB O	笔记本电脑					
microl	连接充电端口	US	BA端口					

3. Keyboard and Mouse Setup • With the computer turned on (after Windows has started completely), connect the USB connector of the receiver to the USB port of the computer. 2The "Add New Hardware Wizard" will annear on the screen The required drivers will be installed automatically in a few minutes. *After the "Add New Hardware Wizard" disappears from the screen, the installation will continue for a while (about 1 minute). Please wait until the operation of the hard disk has stabilised. The USB receiver has now been recognised. 4. Keyboard Pairing Method This product is shipped pre-paired at the factory. If the unpairing causes and the keyboard does not work, please reset it by the following method. •Turn on the keyboard power with the receiver unplugged. ②Press and hold the "Esc" and "Q" keys at the same time, the power LED flashes green. **3**Connect the receiver to the computer. When the LED stops flashing,

③必要なドライバーは数分で、順次自動的に インストールされます.







3.キーボード・マウスのセットアップ

the pairing is complete.

●パソコンの電源が入っている状態(Windows) が完全に起動した後)で、パソコンのUSBポート にレシーバーのUSBコネクタを接続します。 ②「新しいハードウェアの追加ウィザード」の USB Aポートに 画面が現われます。



the USB A port

※「新しいハードウェアの追加ウィザード」が画面から消えた後もしばらく(約1分程度 インストールは続いています。ハードディスクの動作が安定するまで、お待ちください **④**以上でUSBレシーバーの認識完了です。

4 キーボードペアリング方法

本製品は工場出荷時にペアリングが完了した状態で出荷されています。 万一、ペアリングが解除されキーボードが動作しなくなった場合、以下の 方法で再設定をおこなってください。

●レシーバーを抜いた状能で、キーボードの雷源をONにします。

♠「Fsc」と「O」を同時に押します。雷源I FDが緑色に占減します。 Sレシーバーをパソコンに接続します。LEDの点滅が止まるとペアリング

3. 键盘与鼠标的设置

●在电脑开机状态 (Windows 完全启动后),将 接收器的 USB 接口连接到电脑的 USB 端口。 2出现"添加新硬件向导"的画面。

 新所需的驱动程序在几分钟内自动按顺序安装。 ※当"添加新硬件向导"的画面消失后, 安装会持续一段时间(约1分钟)。 请等待硬盘运行稳定。 ●完成对 USB 接收器的识别。



4. 键盘配对方法

本产品出厂时已完成配对。 如果配对解除导致键盘停止工作,请按照以下说明重新设定。

●在拔出接收器的状态下,打开键盘电源。

2 同时按住 "Esc" 和 "O" 键, 电源 LED 闪烁绿灯,

❸接收器连接到电脑,当 LED 停止闪烁时,配对完成。

GSKBW064E-SET_manual_ 裏面 _ 特色 1 色 (PANTONE 320C)+BK

5.主なボタンとLED表示

電源ランプ ■充電中:赤色点灯

Fn | 🛍 | Alt |

」 ■充电中:红灯

■使用中(电池电量不足时):红灯

■开关 ON:绿色 LED 亮 2 秒

Fn 功能键

5.主要按键和 LED 显示


ファンクションキー

■使用中(電池残量が減った時):赤色点灯 ■満充電:緑色点灯

 $T_{Tab|E_{\overline{M}}}$ Q W E_{L} $R_{\overline{A}}$ $T_{\overline{A}}$ $Y_{\overline{A}}$ U I O P

CapsLock A S D F G H J K L : "

■使用中:消灯



NumLock CapsLock 電源 電源 ランプ ランプ ランプ スイッチ 充電ポート

 NumLock
 大写锁定
 电源

 指示灯
 指示灯
 电源开关
 充电接口

BackSpace Num / *

■使用中:灭灯

■満申时:绿灯

カウント切り替えボタン

充電ポート

充电接口

カウント切り替えボタンを押すと

■800カウントの場合:1回点滅

■1200カウントの場合:2回占減

■1600カウントの場合:3回点滅

赤色LEDが点滅します。

キーボード [

外した状態)

■800 DPI: 闪烁 1 次

■1600 DPI: 闪烁 3 次

键盘背面

裏面





6. Warranty Term 1 year

7. Inquiries

6. 保証期間

EN: support-en@sanwa.com

SANWA



SANWA





CN: support-cn@sanwa.com

SANWA