

# INSTRUCTION MANUAL



# Sign Up For ArcadeNet<sup>®</sup> !

- More Games to Play
- ☑ Discounts and Special Offers for Members
- ✓ Online Multiplayer and Voice Chat
- Global Leaderboards and Leagues Events






Sign Up at www.arcadenet.net

# INDEX

LEGENDS GAMER MINI FEATURES	P 2
HOW TO SET UP	P 3
HOW TO CHARGE MY CONTROL TOP	P 3
QUICK START GUIDE	P 4
HOW TO UPDATE FIRMWARE	P 4
HOW TO SIGN IN WITH YOUR ARCADENET® ACCOUNT	P 5
WHEN TO SAFELY POWER OFF LEGENDS GAMER MINI	P 6
WARRANTY INFO	P 6
FEATURED GAMES	P 7
SAFETY NOTICE, BATTERY CAUTION	P 8
FCC STATEMENT	P 8
ISED STATEMENT	P 10

# **LEGENDS GAMER MINI FEATURES**


#### CONTROL TOP



- 1. POWER
- 2. CONNECTION INDICATOR
- 3. BATTERY INDICATOR
- 4. JOYSTICK
- 5. REWIND

- 6. ATGAMES HOME BUTTON
- 7. START
- 8. CONTROL BUS
- 9. USB PORT
- 10. DC POWER PORT


#### • STREAMING ARCADE CONSOLE



- 1. PAIRING BUTTON
- 2. RESET BUTTON
- 3. MICRO USB PORT
- 4. USB PORT
- 5. HDMI PORT
- 6. ETHERNET PORT

#### **HOW TO SET UP**

- 1. Connect the Streaming Arcade Console to a TV or monitor via the included HDMI cable\*.
- 2. Use the included Micro USB AC adapter\* to power the Streaming Arcade Console.
- 3. Power on the Control Top.
- Press and hold G Home/Menu button on the Control Top for 3 seconds until the LED indicator starts quickly flashing.
- 5. Press the pairing button on the Streaming Arcade Console and the pairing window will display on the screen. The pairing button scrolls through options when briefly pushed twice in rapid succession. A single push on the pairing button selects an option.
- Press the pairing button and select [Control Deck]. Long press the pairing button to confirm the pairing.



\*Note: USB Charging and Data Cable (5ft); HDMI Cable (1ft); Micro USB AC Adapter Cable (5ft) are included.

## HOW TO CHARGE MY CONTROL TOP

Before the first use, please connect the Control Top to the provided USB charger\* (Output: 5V/2A) or a computer with the provided USB cable until it's fully charged (battery indicator light will turn off). Subsequent full charges should take approximately 5 hours.

\*Note: While some compatible USB devices may be able to supply power to the Control Top, AtGames cannot recommend any particular device. Please follow the instructions on the third party charger.

# **QUICK START GUIDE**

All screenshots shown are for illustration purposes only. Actual screens may vary.

- 1. Power on both the Streaming Arcade Console and the Control Top.
- 2. Use joystick to select and play 100 pre-loaded games. (Note: Internet connection is not required. The games can be played offline.)
- 3. Connect internet via Ethernet (Ethernet cable is not included) or Wi-Fi to play more games on ArcadeNet®.
- 4. To connect through Wi-Fi: 4-1. Select [Wi-Fi] under the [SETTINGS] page.

4-2. Select the Wi-Fi SSID you would like to connect to, and select [Connect]. If prompted, enter the Wi-Fi password using the on-screen keyboard and select [Submit] when done.







#### **HOW TO UPDATE FIRMWARE**

- 1. Power on both the Streaming Arcade Console and the Control Top.
- 2. Connect internet via Ethernet (Ethernet cable is not included) or Wi-Fi.
- 3. Go to [SETTINGS] and select [Version].
- 4. If there is a newer version, follow the instructions to download the latest firmware. Make sure the internet connection is stable during this process.
- 5. Once the firmware is downloaded successfully, select [Upgrade] and the device will reboot automatically to activate the new firmware version.

Note: If you encounter any issues on firmware update, please contact support@atgames.net.





# HOW TO SIGN IN WITH YOUR ARCADENET® ACCOUNT

- 1. Go to [SETTINGS] and select [SIGN IN].
- 2. Sign up for a new account if you don't have one yet.
- Once you have an ArcadeNet<sup>®</sup> account, you can choose either to sign in with your email or with the QR code. To sign in with your email, enter the email address and password.





- 4. To sign in with the QR-code, a smartphone is required.
- 5. Use a smartphone to scan the QR-code on the screen to launch the ArcadeNet® website. You will be directed to the login page, where you can choose either to sign in with your existing Google/Facebook account or your e-mail.



Atgames.net - Account https://auth.atgames.net	<
At@ames =	
G Continue with Google	
f Continue with Facebook	
or	
U.	
user@example.com	
Remember me	
Log in	
Sign up	
Forgot your password?	
Didn't receive confirmation instructions?	
Copyright © AtGames Cloud Holdings Ltd. All rights reserved.	

6. You will see the authorization notification once complete. Now you can close the window and return to your Legends Gamer Mini. A "Success!" message will show on the screen once signed in.





# WHEN TO SAFELY POWER OFF LEGENDS GAMER MINI

Do not power off the Streaming Arcade Console and Control Top during the following:

- · Firmware update
- · Factory reset
- · Data cleanup
- · Read/write USB drive

This could prevent irreversible data loss and/or damage to your device or USB drives.

#### WARRANTY INFO

The manufacturer warrants this product to be free and clear of defects in the materials and workmanship, under normal residential use and conditions, for a period of thirty (30) days from the original invoice date. Shipping and handling fees are to be paid for by the customer. To make a warranty claim, please submit a service request here: <a href="mailto:support@atgames.net">support@atgames.net</a>.

Standard warranty coverage for the AtGames Legends Gamer Mini does not apply to and is considered invalid due to misuse, improper maintenance, self-repair, tampering, or invasive hardware modifications of any kind, and damages or dysfunction caused by shipping or non-manufacturing related causes.

Note: Standard warranty services are valid with receipt from an authorized retailer. Purchases through third-party sellers and resellers do not fall under the standard warranty program. For warranty support, please contact the third-party seller or reseller where you purchased the product.

## FEATURED GAMES

Bad Dudes vs. Dragon-ninja Battle Shark™ Bubble Bobble™ BurgerTime Cadash™ City Connection Elevator Action™ Front Line™ Growl™ Gun & Frontier™ Joe & Mac: Caveman Ninja Joe & Mac Returns KiKi KaiKai™ Liquid Kids™ Rod-Land Secret Agent/Sly Spy Space Gun™ Space Invaders™ Tetris® Plus Tetris® Plus 2 The Astyanax The Fairyland Story™ The New Zealand Story™ The Ninja Kids™ Thunder Fox™ Violence Fight™

And many more...

#### © CITY CONNECTION CO., LTD

DATA EAST and DATA EAST logo(s) are trademarks in United States and other countries or registered trademarks in European Union and Japan of G-MODE Corporation.

© 2020 Disney. All rights reserved.

© 2020 & <sup>™</sup> Lucasfilm Ltd. All rights reserved.

Copyright © Piko Interactive LLC - All Rights Reserved.

SPACE INVADERS<sup>™</sup>, BUBBLE BOBBLE<sup>™</sup> and other TAITO branded games included in this product are officially licensed by TAITO CORPORATION to AtGames Interactive.

TAITO is the exclusive owner of the global intellectual property rights including copyrights and trademarks for all TAITO branded games included in this product.

Tetris ® & © 1985~2020 Tetris Holding. Tetris logos, Tetris theme song and Tetriminos are trademarks of Tetris Holding. The Tetris trade dress is owned by Tetris Holding. Licensed to The Tetris Company. Tetris Game Design by Alexey Pajitnov. All Rights Reserved.





## SAFETY NOTICE

- Do not submerge the device in water or expose it to extreme heat or to strong magnetic fields.
  Doing so may cause permanent damage to your device.
- · Always use a dry towel to clean the device.
- Transformers are suitable for indoor use only. Transformers and power supplies for toys are not intended to be used as toys, and the use of these products by children shall be under the full supervision of parents.

#### **BATTERY CAUTION**

- · This product contains non-replaceable battery.
- There is a risk of fire and personal injury if the battery is punctured, damaged or misused.
- · Do not dismantle, crush, incinerate or short-circuit the battery.
- · Never expose the battery to extreme temperatures or moisture.
- · Keep away from flammable materials and direct sunlight.
- · Only charge using the provided charger, cable, and/or adapter.
- · Rechargeable battery is only to be charged by an adult.
- Adult supervision of the battery while it is charging is required.
- · Allow the battery to cool down to the room temperature before charging.
- · Charge on a non-flammable surface and keep away from flammable products.
- · Discontinue charging if the battery becomes hot, swells, smokes, or gives off a strong odor.
- Battery chargers used with the product are to be regularly examined for any damage to the cord, plug, enclosure, and other parts, and in the event of such damage, they must not be used until the damage has been repaired.
- · Recycle or dispose of the battery according to the federal, state, and local laws.
- · Keep these instructions for future reference.

#### **FCC WARNING**

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- · Increase the separation between the equipment and receiver.
- · Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- · Consult the dealer or an experienced radio/TV technician for help.

#### For Control Top

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

#### **ISED STATEMENT**

- English: This device complies with Industry Canada license exempt RSS standard(s). Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) This device must accept any interference, including interference that may cause undesired operation of the device. The digital apparatus complies with Canadian CAN ICES-3 (B)/NMB-3(B).
- French: Le présentappareilestconforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitationestautorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareildoit accepter tout brouillageradioélectriquesubi, mêmesi le brouillageest susceptible d'encompromettre le fonctionnement.
   l'appareil numérique du ciem conforme canadien peut - 3 (b) / nmb - 3 (b).

This device meets the exemption from the routine evaluation limits in section 2.5 of RSS 102 and compliance with RSS 102 RF exposure, users can obtain Canadian information on RF exposure and compliance.

cet appareil est conforme à l'exemption des limites d'évaluation courante dans la section 2.5 du cnr - 102 et conformité avec rss 102 de l'exposition aux rf, les utilisateurs peuvent obtenir des données canadiennes sur l'exposition aux champs rf et la conformité.

This equipment complies with Canada radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0mm between the radiator & your body.

Cet équipement est conforme Canada limites d'exposition aux radiations dans un environnement non contrôlé. Cet équipement doit être installé et utilisé à distance minimum de 0mm entre le radiateur et votre corps.



For technical support please email: support@atgames.net



www.atgames.net PO Box 1691, El Segundo, CA 90245 All rights reserved.

\*Content and images are for reference only and subject to change. Made in China