

WARRANTY CARD

Customer's Name:
Customer's Address:
Product Serial No.:
Date of Purchase:
Expiry Date:
I accept the terms and conditions of the warranty.
Retailer's Name:
Retailer's Signature/Seal:
Customer's Signature



BOTTOM VIEW OF CARVAAN GO



RICHT SIDE VIEW OF CARVAAN GO

RP-Sanjiv Goenka Group





USER MANUAL

TOP VIEW OF CARVAAN GO



Power: press for 3 - 4 seconds to power on/off GO; press for a second or less to lock/ unlock GO. If your GO hangs or becomes slower, press for 7-8 seconds to reboot

ACCESSORIES WITH CARVAAN GO











Micro USB Cable Voltage: 220V Frequency: 50 Hz for input and 5V 1A for output

Aux Cable Connect an Aux cable to the speaker to listen to songs from GO

Earphones Strapholder





** AM station will play as per broadcast timings

 * support for micro SD card capacity less than or equal to $^{32\rm GB}$

micro SD card

3. SD SLOT: open the flap to insert your personal charge while listening to FM/MA as it will interrupt the signal

Note: It is recommended that you do not put the unit on AM frequency: 520 to 1710 KHZ

FM frequency: 87.5 to 108 MHZ next/previous station

Step 3: Press next/previous button to go to

stations are tuned

station will play for approx 3-4 seconds till all You will hear a searching sound & each FM/AM Step 2: Searching for all FM/AM signals will start.

2feb]: Press play/pause button for 5 seconds

To auto tune FM/AM stations, follow the steps:


your earphones into GO your own Bluetooth speakers), you will need to plug FM/AM. To use FM (on internal speakers of GO or between FM & AM. Your earphones act as signal to 2 FM/AM**: Press the mode button to switch

collection of songs stored on your personal micro

1 SD*: In this mode, enjoy your personal



FRONT VIEW OF CARVAAN GO



ARTISTES: 25+ artiste based stations like Lata Mangeshkar, Kishore Kumar & others; this is the default mode on first power on/reset SPECIALS: 5+ thematic stations like Romance, Ghazal, Sad etc. PLAYLISTS: 45+ playlists like Yaadein, 80s ka Tadka, Shammi Magic

RESET: Press Artistes & Playlists together for 8 to 10 seconds SLEEP: If no button is pressed for more than 90 seconds, screen light will turn off. Press any button to activate the screen



SAFETY HANDLING

1. CARE FOR PRODUCT

- a. Keep Carvaan GO away from dust and excessive heat (heat registers, stoves etc.)
- b. Prevent spillage of water or any other liquid as this can cause failure of Carvaan GO or could prove to be a potential fire hazard
- c. Clean the unit with a dry cloth only
- d. Do not walk on or pinch the power cord close to the plug
- e. Do not immerse Carvaan GO into water

2. CARE FOR BATTERY

- a. Do not expose the battery to heat sources greater than 60°C
- b. Recycle or dispose the battery when essential. Please ensure proper battery handling and disposal methods
- c. Do not subject the battery pack to a mechanical shock

- d. In the event of a battery leak, do not allow the liquid to come in contact with the skin or eves. If contact has been made, wash the affected area with water and seek medical
- e. For prolonging battery life, avoid discharging the battery completely

3. OTHERS

- a. Use attachments / accessories as specified on the box
- b. Please contact an authorized service center for any repair/ servicing requirements or call the toll free no. 1800-102-7799
- 🙎 Waste electrical products should not be disposed of with household waste. Please follow disposal and recycling instructions issued by the concerned local authority.



Use Saregama Carvaan app to browse/ search songs or create playlists.

To use the app, press the Artistes/ Specials/ Playlists mode button. Turn on the Bluetooth of your mobile phone. Open the Carvaan app > Choose GO > Bluetooth Settings page

BATTERY

Full battery charge time: Approximately 2 hours Battery usage: Approximately 7 hours once the battery is fully charged

CONNECTING GO TO BLUETOOTH SPEAKERS

Step 1: power on your Bluetooth speakers

Step 2: press the Bluetooth mode button for 3 - 4 seconds to turn on Bluetooth on GO

Step 3: turn the dial left/right or press previous/next button to select the

Step 4: press Play/Pause to connect GO to the selected speaker

Step 5: once connection is established, the song plays on the selected Bluetooth speaker

Step 6: to disconnect, press the Bluetooth mode button & press play/pause button on the connected speaker

Step 7: press the Bluetooth mode button for 3-4 seconds to turn off

CONNECTING GO TO CAR SPEAKERS: follow all the steps above. If you are prompted for a PIN / passkey on the car display screen, enter '0000' to pair GO with the speakers of your car

Remember: If you turn on Bluetooth on GO, but do not connect or playout for more than 30 minutes, GO will automatically turn off Bluetooth to help conserve battery



WARRANTY OVERVIEW

Carvaan Go comes with a 6 month Warranty, excluding accessories. This includes servicing/ repair or replacement of damaged parts.

The warranty does not apply and does not cover the following:

- · Liability for loss of data/content loaded in the product due to misuse or tampering.
- · Damage caused due to force majeure events; events caused by fire, water, electrical disturbances etc., events beyond the control of Saregama; acts of negligence or mishandling, usage for commercial, business, industrial, educational or rental purposes

For any feedback, grievances or suggestions email us at feedback@saregama.com or call us on the toll free no. 1800-102-7799

WARRANTY TYPE

Only Carry-in Warranty is provided. Such Carry-in Warranty service requires that the Product be brought by the Customer, at his/her sole cost and responsibility, to the Authorized Dealers along with the original invoice.

Once the Product is serviced/ repaired/ replaced, the Customer shall be responsible to pick-up the Product from the concerned Authorized Dealer.

IMPORTANT LINKS

Station List & Song List: www.saregama.com/carvaango/songlist Detailed Warranty: www.saregama.com/carvaango/warranty Download 'Saregama Carvaan' App from the Apple/ Android store.





FCC Warning

a, § 15.19 Labeling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

b. § 15.21 Changes or modification warning.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

c, § 15.105 Information to the user.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.