

## Oclean W1 Quick Guide

### ■Nozzle

It can be 360 degrees rotation. When replacing nozzle, pull it out vertically. When inserting it, insert it to bottom until it is close to the device body.

### ■Mode switch button

Short press the button can switch the different mode.

### ■Mode indicator light

Light 1 : Standard mode

Light 2 : Sensitive mode

Light 3 : Massage mode

### ■Water tank

Pull down the water tank with a little force. It can irrigate about 120 times when it has full water.

### ■On-Off button/charging indicator light

Holding the ON/OFF button to irrigate. Release button to stop irrigate.

The charging indicator light is in a breathing flashing state when charging, the charging light is on constantly when fully charged.

The power light flashed in red when battery is low.

### ■Charging port

Charge with the magnetic charging cable. It can be fully charged in 3 hours.

## Using Steps

1. Make sure there is power in the device, it needs to charge firstly if no power.
2. Refill the water tank, insert the nozzle into the device body, Put the nozzle intermittently close to the slit between teeth (The distance between nozzle and slit is about 2CM) ,Press and hold the power button to start cleaning. Slowly move to the next zone.
3. Release the spray button after cleaning.

Download the Oclean App for more setting

Oclean WeChat official Account

Oclean APP

## FCC statement

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### FCC Radiation Exposure Statement

This device complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.