Oclean Smart Sonic Electric Toothbrush
User Manual

Important Safety Notice

This product is recommended for use by persons over 12 years of age.
The product can only be used with Oclean replacement heads. We will not be responsible for any consequences resulting from the use of non-certified third-party brush heads.
This product is for personal cleaning only and is not recommended for medical purpose or multi-user use.
This product is for indoor use only. Do not place the toothbrush under direct sunlight for a prolonged period of time. It is recommended to be placed in the dry well-ventilated areas with normal temperature.
Please keep the body dry before charging, dry it with a soft cloth, and clean the charging base with a dry cloth regularly to prevent the stain from building up.

Brush head
When replacing the brush head, please pull out or insert it vertically, and do not rotate left or right

It is recommended by dentists to change the brush head every two to three months.

Touch screen
Support up and down swipe actions. Please touch with your finger pulp

ON/OFF button
Once the toothbrush turns on, a short press on the button when it is running will pause its operation; a short press again within 15 seconds will resume the operation; No operation for more than 15 seconds will black out the display and hibernate the toothbrush

Wireless charging base
The wireless charging base is used together with the silicone bracket

Use for the first time: Tap the on/off button to turn on the toothbrush and enable Bluetooth. The toothbrush will then remain in standby mode; Bluetooth will also be in always-on mode.

Brushing program: Without any settings, the toothbrush will run for 2 minutes by default following "Standard Daily Cleaning Program", where the toothbrush will alert the user of the need to change the brushing area by changing the vibration pattern every 30 seconds, and will automatically stop running after 2 minutes of operation.

Charging the toothbrush: Dry the body before charging, and then place it on the wireless charging base for charging. You can determine the charging status with the indicator light on the

wireless charging base and its battery level with the battery percentage shown on the Oclean electric toothbrush display. Please do not leave the toothbrush on the wireless charging base for a for a prolonged period of time for repeated charging. After fully charged, please remove the toothbrush from the wireless charging base in time and recharge it when the toothbrush alerts you its low battery status.

Install the app: After scanning the QR code to download the Oclean APP, please search and connect your toothbrush in the app; Note：Attempt to connect the toothbrush in "System Settings - Bluetooth Settings" in your phone will not work.

Wireless charging base
Lay flat when charging, and do not place metal other than toothbrush on the charging base. During charging, please mount the wireless charging protective sleeve on the charging base and then place the toothbrush in the slot of the wireless charging base.

Wall mount
The toothbrush comes with a wall mount for space-saving storage

Note

Installation of the bottom of the wall mount
When placing the toothbrush on the wall mount, make sure it is facing up.

If you need more detailed product usage information,
please follow the Olean Official Account

Thanks for using Oclean Smart Sonic Electric Toothbrush.

This is a smart sonic electric toothbrush product. Please read the user manual carefully to get started quickly. It can be used with the matching app. See below to learn more about brushing teeth with this toothbrush.

Attention should be paid for those with the following conditions of oral sensitivities

Those who have recently undergone periodontal surgery or are undergoing treatments.

Individuals with other symptoms in the mouth including those with unstable dentures or have persistent heavy bleeding from the gums.

Other individuals with sensitive and fragile oral issues.
This product is not recommended for use with the above group or consult a professional dentist before use.

This product is not suitable for people with disabilities, mental illness or lack of relevant experience and knowledge [including children (0-12 years old)]. Unless used under the supervision of their guardians.

Instruction for use

Turning the product on for the first time
To use the toothbrush for the first time, please short press the "On" button, and it will turn on the toothbrush, and Bluetooth will also be in always-on mode. You can download and install the "Oclean App", and connect and set the toothbrush in the app. App installation and toothbrush setup
Scan the QR code to complete the app installation, which will allow you to set various functions for your toothbrush, such as: Turning on/off the "change brushing area alert after 30 seconds ", turning on/off the "Automatic Frequency Reduction Tooth Guard" function and etc. In addition, you can also customize your own brushing program and push the customized program directly to your toothbrush.

Touch the screen to setup the toothbrush
The toothbrush setup can also be made via the touch screen without connecting to the app. You can choose between four modes: Cleaning, Massage, Whitening and Sensitive, as well as select the duration and intensity.
After receiving the pushed brushing program from the app, if any of the mode, intensity or duration changes are made via the touch screen, then the toothbrush will no longer perform the previous app-pushed brushing programs.

Timer and brushing area changing alert
The default duration of the brushing program is 2 minutes, with a momentary change in vibration status every 30 seconds to alert the user of the need to change the brushing area.

Tooth brushing report
After the brushing is done, the product display will show your brushing time, brushing scores, and tips for blind spot of tooth brushing for the bushing you have just completed.

Brushing Mode Setup
Go to settings by swiping up and down the display or swiping left and right of the screen edge - e.g.: The "Brushing Mode" setting. The toothbrush will automatically remember the settings once the setup is completed, and the subsequent operation will follow the new settings.
For the intensity settings, swipe the screen up and down to change the intensity level to "plus 1" or "minus 1", and swipe the screen edge up and down to change the intensity level to "plus 5" or "minus 5"

Swipe up and down

1. Do NOT disassemble, strike, extrude or throw the device into a fire.
2. Do NOT use the toothbrush if its battery is bulging or has expanded.
3. Do NOT subject the battery to a high-temperature environment.
4. Do NOT use the battery if it has been subjected to moisture.
5. Do NOT place metal other than toothbrush on the charging base.

New Message Icon
The new message icon will appear on the display when there is new activity message, software update notification or other alert information.

Check the Brushing Records In the App
The toothbrush must be paired with and connect to the app in order to receive the brushing data from the brushings. As the toothbrush comes with limited memory size for data storage, the brushing data can usually be stored for no more than 7 days.

Low Battery Alert
When the battery percentage is below 20%, an alert will pop up on the display of your toothbrush from time to time to indicate that the battery is running low, and you need to charge it soon. When the battery is seriously low and the percentage is lower than 1%, your toothbrush will be off and the toothbrush's motor will vibrate to alert you to charge the battery, and the screen will not be turned on either.

How to Charge

Please place the designated wireless charging base of the product on a smooth surface and connect the charging base to the plug. When power is applied, the indicator light on the base will flash After mounting the silicone protective sleeve on the surface of the wireless charging base, place the toothbrush handle in the slot of the wireless charging base. If not charged, the indicator light will not lit. When there is a foreign body on the wireless charger or when it is not being charged properly, the indicator light will flash quickly. When the toothbrush is being charged properly, the indicator light will turn on a breathing-like display effect and the battery will generally be fully charged in around 3.5 hours.

Important Charging Notice

This product adopts wireless charging mechanism, it is recommended to place this product on

the wireless charger only when it needs to be charged; when it does not need to be charged, please remove the toothbrush from the charging base. Leaving the toothbrush on the powered wireless charging base for a prolonged period of time may lead to premature depletion of the built-in battery affecting the usage experience.

Recommended tooth brushing method

Move the toothbrush slowly at 45° between the brush and gingiva line. There is no need to manually brush up and down during this process.

Hold the toothbrush handle gently, move slowly in a circular motion, and please do not apply excessive pressure.

Please gargle with clear water after brushing.

Cleaning and Maintenance

Cleaning the toothbrush body and the brush head
Rinse with tap water and air dry, and do not pull the bristles of the brush head

The instructions for class III appliances shall state that it must only be supplied at safety
Extra low voltage corresponding to the marking on the appliance.

Product specifications
Product Name Oclean Smart Sonic Electric Toothbrush
Model   Y2087
Emission power   0 dBm Max
IP Rating   IPX7
Power of the toothbrush body   1.5W
Charging   Oclean wireless charger base
Input 5V 0.3A
Operating time*   20 days (level 32 of intensity) - 40 days (level 1 of intensity)
Battery Capacity 800 mAh
Charging time   3.5 hours
Bluetooth   Bluetooth 5.0 above
* Under the cleaning mode, it is calculated at 2 minutes/time, 2 times/day working condition.

EU Regulatory

Hereby, Shenzhen Yunding Information Technology Co., Ltd. declares that this device Y2087 is in compliance with the essential requirements and other relevant provisions of
Directive 2014/53/EU.

FCC Statement

This device should be installed and operated with a minimum distance of 0mm
between the antenna and all persons. This device has been tested and found to
comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC

Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This device generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception, which can be determined by turning the device off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

--Reorient or relocate the receiving antenna.

--Increase the separation between the device and receiver.

--Connect the device into an outlet on a circuit different from that to which the receiver is connected.

--Consult the dealer or an experienced radio/TV technician for help

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a WPC device, pursuant to Part 18 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment has been tested and found to comply with the limits for a wireless power charger, pursuant to Part 18 of the FCC Rules

IC Statement

This device complies with (s)/receiver(s) that comply with Innovation, Science and Economic Development Canada'slicence-exempt RSSs. Operation is subject to the following two conditions:

(1) This device may not cause interference; and

(2) This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

(1) l'appareil ne doit pas produire de brouillage;

(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

CAN ICES-003(B) / NMB-003 (B)

E-Label

This device has an electronic label for certification information.

To access it, please go to Settings > About > Certification on your toothbrush.