
# Light Up Logo Speaker w/ Wireless Charging Powerbank

Instruction Manual: 7197-29



## Functions:

- 1. Wireless Charging Surface 2. Light-up panel
- Bluetooth LED indicator
- 4 ON/OFF Button
- 5. Wireless Charging LED 6. Wireless Charging Button
- 7. Powerbank LED indicator
- 8. Micro-USB Input
- 9. USB Output

# What's included:

- 1 x Bluetooth Speaker (7197-29)
- 1 x USB to 2Amp Micro-USB Charging Cable
- 1 x Instruction Manual

### Tech Specifications

- · Playing Time: up to 7hrs at max volume · Charge Time: 2hrs (from 0-100%)
- · Pairing Name: Light Up Speaker
- · Battery: 2000mAh
- . Micro-USB Input: 5V/2A
- · USB Output: 5V/2A
- . Wireless Output: 5V/1A 5W

#### Instructions:

(Be sure to fully charge the speaker before using for the first time).

- 1. Charging the Speaker:
- · Connect the provided charging cable to a power source and to the micro USB port(8) on the speaker.
- . The Powerbank LED indicator (7) will flash RED when charging, and will turn solid RED when fully charged.
- 2. Bluetooth® Setup:
- Press and hold ON/OFF Button(4) to turn ON the speaker, Bluetooth LED indicator(3) will flash BLUE when in bluetooth standby mode.
- Turn on the Bluetooth function on mobile device. Select Light Up Speaker pairing name, LED will turn solid BLUE if successfully paired.
- . Speaker will automatically pair if the mobile device has been paired before.
- Press and hold ON/OFF Button(4) to turn off the device

### 3. Using the Speaker:

- · Press the ON/OFF Button(4) button to pause music and again to play.
- When receiving a phone call, press the ON/ OFF Button(4) button to answer and again to hang up.
- · Long press to reject the call.
- Double press to redial the last call.
- 4. Charging mobile phones and other electronic devices:
- Connect the charging cable to your mobile phone/device using the appropriate connector
- Connect the USB A Part of the cable into the USB Output(9), Powerbank LED Indicator(7) will turn RED when charging.

- Remove the USB cable from your mobile device when it is fully charged.
- 5. Wireless Charging Function:
- . Press the Wireless Charging Button(6) to turn on the wireless charging function. The Wireless Charging LED(5) will glow GREEN
- · Place the wireless charging supported device on the Wireless Charging Surface. LED(5) will glow RED when device is charging.
- . Long press the Wireless Charging Button(6) to turn off Wireless Charging. \*\* Note: If the Wireless Charging LED is flashing an unknown object is being detected between the wireless charging surface and the phone by FOD(Foreign Object Detection). The device will not begin to charge until object is removed.\*\*

#### SAFETY PRECAUTIONS:

- WARNING-When using this product, basic precautions should always be followed:
- 1. Read all the instructions before use. 2. Never store or use this product in
- temperatures below 32°F (0°C) or above 115°F (45°C).
- 3. Do not overcharge Phone. Unit may get hot with excessive use. Remove Phone when it is fully charged. Never charge for more than 7 hours at a time.
- 4. The unit's full performance is achieved only after 2 or 3 completed charge and discharge cycles.
- Keep out of reach of children.
- 6. Do not use the device in excess of its output rating. Overload outputs above rating may result in a risk of fire or injury.

- 7. Do not use the device if damaged or modified
- 8. Damaged or modified batteries may exhibit unpredictable behavior resulting in fire. explosion or risk of injury.
- 9. Do not disassemble the device. For repairs, seek a qualified service professional. Incorrect reassembly may result in a risk of fire or injury.
- 10. Do not expose the device to fire or temperatures above 104°F may cause explosion.
- 11. Ensure that qualified service professionals use only identical replacement parts to ensure product safety.
- 12. Attachments on the back of your phone can impede the effectiveness of the wireless charger, and lead to overheating. Please remove attachments from the phone before charging on this device.

#### FCC Statement: This device complies with Part 15 of the

FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful

- interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.
- Warning:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

