

Bluetooth Transmitter Instruction

Bluetooth Power ON/OFF:

1. Power on : Press and hold the multi-function button for 3 seconds until the LED flashes blue 3 times.

2. Power off : Press and hold the multi-function button for 3 seconds to power off.

3. If the LED Indicator turns from BLUE to RED when in standby mode, turn the device off to conserve power.

4. Bluetooth Pairing.

A. Press and hold the multi-function button for 6 seconds. The LED Indicator will flash BLUE & RED, indicating pairing mode.

B. Activate the Bluetooth function on your mobile device, and select “41554” to pair. The mobile device will indicate when pairing has been successful.

Answering calls:

Short press the Play button to answer an incoming call.

Ending phone calls:

Short press the Play button to end an active call.

Volume Control

A. Short press the “+” button to increase volume.

B. Short press the “-” button to reduce volume.

Select Previous/ Next Track:

A. Press and hold the “+” button to play the next track.

B. Press and hold the “-” button to play the previous track.

WARNING

Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment.

This device must not be collocated or operating in conjunction with any other transmitter.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.